

zeevee™

Intelligent AV Distribution

ZyPer

Management Platform
User Manual

Updated, May 2020
API Release 2.1x



Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this product near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install or place this product near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of a polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. To reduce the risk of electric shock and/or damage to this product, never handle or touch this unit or power cord if your hands are wet or damp. Do not expose this product to rain or moisture.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Batteries that may be included with this product and/or accessories should never be exposed to open flame or excessive heat. Always dispose of used batteries according to the instructions.

Operating Notes

- The ZyPer Management Platform includes the ZMP web interface. The following browsers are supported:
 - ▶ Google Chrome version 55.0.2883 or greater
 - ▶ Mobile Devices: Android tablet 7.0, MS Surface Windows 10, iPad iOS 10.3.2 and higher
- Refer to the Support page on the ZeeVee web site to download the latest firmware.

Contacting ZeeVee

Support

Contact us for installation and technical support, repairs, and warranty service:

+1 (877) 4-ZEEVEE (1.877.493.3833)

support@zeevee.com

Sales

North America:

+1 (347) 851-7364 Phone

sales@zeevee.com

EMEA:

+44 1494 956677 Phone

EMEAsales@zeevee.com

Features and Package Contents

Features

- Pre-configured Linux O/S is maintenance-free and includes upgrades and support.
- Plug & Play operation will discover and enable labeling and control of any number of ZyPer4K, ZyPerUHD or ZyPerHD encoders and decoders.
- Interface allows the independent routing of video, audio and control signals.
- The feature-rich API makes ZyPer4K / ZyPerUHD / ZyPerHD the perfect add-on to existing distribution systems without the time and dollars usually required for custom programming.
- Presets enable signal routing and scheduling of saved, pre-defined source-display settings for easy duplication and recall.
- Real time system monitoring includes generating alerts for offline or disconnected ZyPer4K / ZyPerUHD / ZyPerHD devices, sources and displays.
- Auto detection/discovery of additional encoders and decoders make system scaling a snap.
- Easily create and manage video walls of any pattern or configurations up to a 9x9 array.
- Create and manage Multi-view displays with up to 9 sources. (ZyPer4K only)

New in Release 2.1

New Features

- Text Overlay in multiview windows (ZyPer4K only, requires firmware 4.0.1)
- Thumbnail stream preview in ZyPer Management Platform GUI (ZyPer4K and ZyPerUHD. ZyPer4k requires firmware 4.0.1)
- Multiview configuration now allows precise pixel placement of windows
- Multiview configuration now allows precise pixel sizing of windows
- Enable/Disable Telnet access to Management Platform
- SNMP and LLDP support
- Manually add ZyPer devices not located on same Network/VLAN as the Management Platform

New in Release 2.1

New/Updated Commands [\(See API Command Listing\)](#)

- add device
- add snmp
- delete all-configuration
- delete snmp
- preview-stream
- set decoder
- set multiview
- set multiview title
- set server telnet mode enabled | disabled
- set server ssh password
- set server telnet password
- show device user-added
- show multiviews
- show preview-streams

Deleted/Removed Commands (See API Command Listing)

- set server enhanced-logging
- set server api-password

Contents

1 Getting Started

ZMP NUC I/O Descriptions	2
Rear View	2
Top View	3
Front View	4
Installation	7
Using Windows®	7
Using OS X®	7
Sample Application Diagram	8
Management Platform Login	9
Network Configuration	10
Fixed Mapping using DHCP	10
Static IP Configuration	11

2 Basic Operation

Accessing ZyPer Management Platform	13
Home Page	14
Device Status Indicators	15
Displaying Devices By Status	17
Displaying Devices By Name	18
Joining Encoders to Decoders	19
Unlinking Encoders and Decoders	20
Video Preview Stream	22
Source Config Page	23
Configuring Encoders and Decoders	23
Deleting, Rebooting or Resetting an Encoder or Decoder	29
Sending a CEC Command	31
Sending a RS232 String Command	33
Updating Firmware	35
Creating Video Walls	37
Bezel Compensation	40
Creating a Multiview Screen	42
Creating Zones	46
Device Grid Page	49
Server Functions Page	51
Server Information	51
Setting the EDID Mode	52
Server Reboot, Restart, and Shutdown	53
Help Page	55
Users and Roles Pages	56
Adding a New User	58
Adding or Editing a New Role	59

3 Advanced Operation

Accessing the API63
 Using Telnet63
 Getting Help63
 Setting the Time Zone64
 EDID Management65
 Auto EDID Mode65
 Using Custom EDID Data.....65
 Using AJAX/JSON67
 Login Authentication.....67
 Command Request / Response.....68
 Fast-Switched vs. Genlocked Mode.....70
 API Command Listing71

4 Event Mechanism

ZMP Event Mechanism 196
 Telnet Event Session 196
 Browser WebSocket 197
 API Polling 198
 Event List 198


5 SNMP and LLDP Support

SNMP Agent SNMPv3 Account Configuration204
 SNMP Agent SNMPv2 Account Configuration205
 SNMP Client205
 SNMP Notifications206
 More Technical Information on Linux Net-SNMP Package.....208

6 Appendix


Updating the Software210
 Using Mac OS X.....211
 Using Windows211
 Using ZyPer Management Platform213
 Redundancy Configuration Instructions215
 Hardware Specifications218

1 Getting Started



ZMP NUC I/O Descriptions

Rear View



ID	Name	Description
1	Power receptacle	Connect the included power supply to this power receptacle.
2	USB ports	Connect up to two USB 3.0 devices, such as a keyboard and mouse.
3	HDMI	Connect an HDMI cable from this port on the Management Platform to an HD display. (optional)
4	Ethernet port	Connect an Ethernet cable from this port to a switch on the Local Area Network.

Side View



ID	Name	Description
5	Kensington Lock	This port accepts a standard computer laptop locking connector.

Front View



ID	Name	Description
6	USB port	Connect up to two USB 3.0 devices, such as a keyboard and mouse, to these USB ports.
7	Power On/Off	Press this button to manually power-off the Management Platform. When the Management Platform is connected to a power source, it will automatically power-on. In addition, if power is lost or the power is disconnected, the Management Platform will automatically power-on when power is restored.

Hardware Specifications (Intel NUC version)

CPU	<ul style="list-style-type: none"> Intel® Pentium® Processor J5005
Operating System	<ul style="list-style-type: none"> Linux Ubuntu 14.04
Internal Storage	<ul style="list-style-type: none"> 64 GB SSD
Graphics	<ul style="list-style-type: none"> Intel® HD Graphics 600
LAN	<ul style="list-style-type: none"> Gigabit LAN
Internal Memory	<ul style="list-style-type: none"> 8 GB DDR4
Power Supply	<ul style="list-style-type: none"> Input: 100 ~ 240 V AC Output: 19V DC, 3.42 A
I/O	<ul style="list-style-type: none"> 2 x HDMI 2.0a 4 x USB 3.0, Type- A, female 1 x RJ45 1 x 19V DC 1 x Kensington lock slot 2 x 3.5mm headset jacks (Not used)
Operating Temperature	<ul style="list-style-type: none"> 0 °C to +40 °C
Storage Temperature	<ul style="list-style-type: none"> -20 °C to +60 °C
VESA	<ul style="list-style-type: none"> VESA Bracket included Supports 75 x 75 and 100 x 100 mm
Dimensions (W x H x D)	<ul style="list-style-type: none"> 4.55 in x 2.01 in x 4.57 in (115 mm x 51 mm x 111 mm)



RoHS



Hardware Specifications (Enterprise Grade Rack Mount)

CPU	<ul style="list-style-type: none"> Intel® Xeon E3-1200 v5
Operating System	<ul style="list-style-type: none"> Linux Ubuntu 14.04
Internal Storage	<ul style="list-style-type: none"> 64 GB SSD
Graphics	<ul style="list-style-type: none"> ASPEED AST2400 BMC
LAN	<ul style="list-style-type: none"> Dual Gigabit LAN
Internal Memory	<ul style="list-style-type: none"> 8 GB DDR4
Power Supply	<ul style="list-style-type: none"> 200W Low-Noise AC-DC power supply with PFC
I/O	<ul style="list-style-type: none"> 1 x VGA (15-pin D-sub) 2 x USB 2.0, Type-A, female 2 x RJ45 (LAN) (Video Network and Management Network) 1 x RS232 (9-pin D-sub)
Operating Temperature	<ul style="list-style-type: none"> +10 °C to +35 °C
Storage Temperature	<ul style="list-style-type: none"> -40 °C to +70 °C
Dimensions (W x H x D)	<ul style="list-style-type: none"> 17.2 in x 1.7 in x 11.3 in (437 mm x 43 mm x 287 mm)
Weight	<ul style="list-style-type: none"> 8.45 lbs, (3.83 kg)



RoHS



Power Button



Status LEDs



Ethernet Port 0 = Video Port. DHCP default IP Address

Ethernet Port 1 = Management Port.

Static IP Address 192.168.20.2 Subnet Mask = 255.255.255.0

Installation

1. Connect the included power supply to the power receptacle on the ZyPer Management Platform.
2. Connect the included AC power cord from the power supply to an available electrical outlet.
3. Connect an Ethernet cable from the ZyPer Management Platform to a switch that is on the same LAN that will be hosting the ZyPer devices. Although the ZyPer Management Platform can be connected anywhere on the LAN, it is recommended that it is connected to the primary switch where the ZyPer endpoints are connected.

NOTE: If the ZyPer Management Platform does not detect a DHCP server within 60 seconds, a link-local address of `169.254.xxx.xxx` will be assigned to the ZyPer Management Platform. If you wish to use static or fixed-mapping using DHCP, then see [Network Configuration \(page 10\)](#).

Using Windows®


- a. Connect an Ethernet cable from your computer to the same switch as above.
- b. Go to the **Network** folder.
- c. Locate the icon titled “ZyPer Management Server” followed by an IP address. This is the IP address of the ZyPer Management Platform.

Using OS X®

- a. Connect an Ethernet cable from your computer to the same switch as above.
- b. Open the Terminal application.
- c. At the prompt, enter `ping zyper.local`.
- d. The IP address of the ZyPer Management Platform will be displayed.

4. Open a web browser and enter the IP address of the ZyPer Management Platform.
5. The login screen for the ZMP will be displayed.
6. Enter `admin` for both the **Username** and **Password** fields.
See [Management Platform Login \(page 9\)](#) for more information.
7. Click the **Login** button.

Sample Application Diagram



Management Platform Login

1. Directly connect an HDMI cable between the Management Platform and a Display. (Note that a USB keyboard is also required to be connect to the Management Platform)
2. After boot the login prompt will appear. At the login prompt, enter the following login name: `zyper`

After entering the login name, the password prompt will be displayed.

```
zyper login: zyper
Password:
```

3. Enter the password. The default password is `zyper`. Note that the password will not be echoed to the screen. Once the password is entered, the screen will appear similar to the following:

```
zyper login: zyper
Password:
```

4. Use the `show server info` command to find the IP Address of the Managment Platform

```
Zyper$ show server info
server(192.168.0.78);
server.gen; hostname=zyper.local, version=2.1.35811, previousVersion=1.8.34521,
  macAddress=1c:1b:0d:82:ff:1a, serialNumber=ZZM1H500032B
server.gen; uptime=0d:0h:14m:11s, freeMem=7.036GB, bootCount=19
server.gen; runningInVm=false
server.time; time=Fri Nov 22 14:03:32 2019, timezone=America/New_York
server.license; productID=031B021C-040D-0582-FF06-1A0700080009, license=JSGH-
  RLUH-0000-116F-9328-F426-4BB5-89E2-024D-8CBE-FF1C
server.license; limit=unlimited, knownDevices=20, devicesUp=9, devicesExceeded=0
server.deviceUpdates; active=0
server.activeDeviceVersions; num_4.0.0=4, num_4.0.1=5
Success
```

Network Configuration

The default configuration of the Management Platform will use DHCP with link-local addressing support. Link-local addressing allows the Management Platform to have an IP address on a network, even if the Management Platform has not been manually configured or automatically configured by a DHCP server. If a DHCP server is not detected within 60 seconds, a link-local address of `169.254.xxx.xxx` will be assigned to the Management Platform.

If you wish to use a static IP address, this can be done in one of two ways: Add a fixed mapping to the DHCP server or by directly assigning a static address to the Management Platform. Both methods are covered in this section.

Fixed Mapping using DHCP

Before continuing, make sure that the static IP address being used does not conflict with any DHCP-assigned addresses. Contact your system administrator for assistance.

1. At the login prompt, enter the following login name: `zyper`

After entering the login name, the password prompt will be displayed.

```
zyper login: zyper
Password:
```

Enter the password. The default password is `zyper`. Note that the password will not be echoed to the screen. Once the password is entered, the screen will appear similar to the following:

```
Zyper$
```

Use the [show server info](#) command to find the Mac Address of the Management Platform

```
Zyper$ show server info
server(192.168.0.78);
server.gen; hostname=zyper.local, version=2.1.35811, previousVersion=1.8.34521,
macAddress=1c:1b:0d:82:ff:1a, serialNumber=ZZM1H500032B
server.gen; uptime=0d:0h:14m:11s, freeMem=7.036GB, bootCount=19
server.gen; runningInVm=false
server.time; time=Fri Nov 22 14:03:32 2019, timezone=America/New_York
server.license; productID=031B021C-040D-0582-FF06-1A0700080009, license=JSGH-
RLUH-0000-116F-9328-F426-4BB5-89E2-024D-8CBE-FF1C
server.license; limit=unlimited, knownDevices=20, devicesUp=9, devicesExceeded=0
server.deviceUpdates; active=0
server.activeDeviceVersions; num_4.0.0=4, num_4.0.1=5
Success
```

After programming the DHCP server to assign a specific address to the Management Platform, reboot the Management Platform, using the following command, to use the new IP address.

```
ZyPer$ restart server
```

Success

Static IP Configuration

Before continuing, make sure that the static IP address being used does not conflict with any DHCP-assigned addresses. Contact your system administrator for assistance.

Using the `set server ip` command can be used to set the IP Address of the Management Platform. Refer to [API Command Listing \(page 63\)](#) for a full listing of available commands.


```
Zyper$ set server ip server static 192.168.1.26 255.255.255.0 none
reboot
```

Success

2 Basic Operation

Accessing ZyPer Management Platform

1. Open a web browser and enter the IP address of the Management Platform.
2. The login screen for ZMP will be displayed.




The screenshot shows the login interface for the ZyPer Management Platform. At the top, the title "ZyPer Management Platform" is displayed in blue. Below the title, there are two input fields: "User ID" with the text "admin" entered, and "Password" with six dots representing a masked password. A checkbox labeled "Change my password after Sign In" is located below the password field. At the bottom right of the form, there is a blue "Sign In" button.

3. Enter the required information in the **Username** and **Password** fields. The default username and password is `admin`. The username and password are case-sensitive. The "admin" password may be changed by the user at any time.
4. Click the **Sign In** button.
5. The **Home** page will be displayed. See the next section for more information.

Home Page

The **Home** page of the ZyPer Management Platform displays all available *Sources*, *Displays*, *Walls*, *Zones*, *Multiviews*, *Server Info*, *Users*, *Roles*, *Logs* and *Help*.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. The **Home** page will be displayed. The **Sources** pane displays all available *encoders*. The **Displays** pane displays available *decoders*. *Walls*, *Multiview*, *Zones*, *Users* and *Roles* will be covered in upcoming sections.



Device Status Indicators

Each Source and Display contains a status indicator border color, displaying current information about the device. This is particularly useful for devices that may be in a separate part of a building or several miles away.

Meaning	Indicator Color
OK	Green



1. Indicates that an HDMI cable is connected between the encoder and the source or between the decoder and a display or other sink device.
2. The encoder / decoder is powered.
3. The Ethernet cable is connected between the switch and the encoder / decoder.

Meaning	Indicator Color
Warning	Yellow



1. HDMI cable may not be connected between the encoder and the source or between the decoder and a display or other sink device.

Note that this indicator may also indicate a faulty HDMI cable.
2. The encoder / decoder is powered.
3. The Ethernet cable is connected between the switch and the encoder / decoder.

Meaning	Indicator Color
Error	Red




1. The Ethernet cable is *disconnected* between the switch and the encoder / decoder.
2. The encoder / decoder may not be powered.


Displaying Devices By Status

Both the **Sources** and **Displays** window contain a **Filter by status** option. There are check boxes to filter by Status (Green, Yellow, Red), Device Type (4K, UHD or HD), USB (Present, Not present). There is also an option to filter Sources or Displays by name.

1. Click the **Filter Icon**.



2. Only those devices with the selected status will be displayed. As illustrated in this example, only ZyPer4K devices are shown in the **Sources** window. ZyPerHD and ZyPerUHD sources are filtered out.




3. Select every box from the **Filter** to show all devices.


Displaying Devices By Name

Both the **Sources** and **Displays** windows contain a **Filter by name** field. Use this field to enter the name of the desired device(s) to be displayed. As text is entered, the interface automatically begins a search of the current string for each recognized device. Devices that are displayed must contain the text (in sequence) that is currently in the **Filter by name** field. Text searches are case-sensitive.

1. Click in the **Filter by name** field.



This example uses the following named sources. For more information on naming sources see [Configuring Encoders and Decoders \(page 23\)](#).



2. Type the desired sequence of characters in the **Filter by name** field to search. In this example, we want to only display the "Wildlife" source devices. To do this, we can enter part of the name, such as "Wild" or even "W" (since no other device name contains the character "W"). All text entries are *case-sensitive*.


Manually Setting Sort Order

Both the **Sources** and **Displays** windows can be sorted manually. Every device is assigned a “sort order” number. The user can change this sort order number manually.

1. Click on the device identifier. (Little “4K” or “UHD” or “HD” in upper left corner of device.)



This will bring up a Sort Order option for the selected device. The example below the device is assigned to Sort Order position 1. (Top Left of the Source window) This number can be changed to any number desired up to the number of sources.




2. Sort Order numbering runs from top left to bottom right. In the image above assuming only 5 sources, the top three would be location 1, 2 and 3; while the bottom two would be locations 4 and 5.

Joining Encoders to Decoders

“Joining” is the process of assigning an encoder (source) to a decoder (display) or a video wall. Before starting the join process, we recommend that you configure the encoder and decoder settings. Refer to [Configuring Encoders and Decoders](#) (page 23).

1. Login to the ZMP. Refer to [Accessing ZMP](#) (page 13) for more information.
2. Drag and drop the desired source on to the desired display.



3. The display icon will change to show that it has now been joined with a source. (Small chain link icon) Hover over the chain link for additional status info. Also the icon will change to match the source and name of the source will appear at the top of the icon.




4. Continue the *join* process as desired. Note that joining an encoder with a decoder that is already joined, will replace the previous *join* operation.

The join command can also be used to perform the same operation. See [API Command Listing](#) (page 63) for more information.

Unlinking Encoders and Decoders

As mentioned earlier, joining an encoder with a decoder that is already joined, will replace the previous join operation. However, there may be situations where you want to completely remove any source from being shown on a display. To do this, use the Disconnect AV feature or Disconnect Joins.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. On the **Sources** window, right-click on any Source. Select Configure Join and then Disconnect AV.



3. Drag that source onto the Display that you would like to unlink
4. Alternately you can right click on the “Chain Link” icon and select “Disconnect Joins”
5. The display icon will change to show that it has been unlinked and no longer joined with any encoder. (Yellow perimeter, small chain link icon is gone, icon returns to default and name of joined source is gone)




Video Preview Stream


It is possible to view a small thumbnail preview of the active stream in the GUI within either the encoder or decoder box. Once preview streams are enabled, you can see them by following the steps below: **(Supported on ZyPer4K and ZyPerUHD only)**

Note: It will take several seconds for the preview stream to appear once activated. There is a maximum of 20 preview streams available at any given time.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. On the **Sources** window, click on the small “4K” or “UHD” located in the upper left corner of the window. This will toggle the GUI between showing an icon and showing the preview stream.



3. Click on the gear icon in the top right corner of the ZMP to enable or disable the “Big Preview” option. When enabled, hovering the cursor over a preview stream will make the preview approximately 50% larger while you keep the cursor over the stream.




4. Note that preview stream can be viewed for both **Sources** and joined **Displays**. All other functionality remains the same. The preview stream updates about 1 time per second. (Multiviews are not available as preview streams. Clicking on preview at the decoder for a multiview will give the appearance that the multiview has failed.)
5. Important Notes: The PC/Laptop attempting to view preview streams **MUST** have access to the Internet to download a player in the background. ZyPer4K **MUST** be on firmware version 4.0.1 or newer.

Source Config Page

Configuring Encoders and Decoders

When an encoder or decoder is connected to the network, the Management Platform identifies each unit by its MAC address. This is the default setting. However, when dealing with several units, it is much easier to identify a unit by a string name. It is also possible to assign a preset image to each icon, set the network mode, RS232 settings, and more.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Source or Displays** tab at the left of the page. [Joining Encoders to Decoders \(page 20\)](#)




3. All available encoders will be displayed under the **Sources** window.



- Left-click the desired encoder name to display the context menu. In the example below, we will select the encoder named "ESPN1".
- A menu will appear with options for Summary, ID, Status, Config and Actions.



- Selecting the ID option will allow you to manually give the Source a name.




- Enter a description for the source in the **Name** field. By default, the Management Platform will use the MAC address of the encoder. This field cannot be blank. Names cannot contain spaces. In this example, we will use "ESPN1".

Naming a device can also be done using the `set device general name` command. See [API Command Listing \(page 63\)](#) for more information.


*Each encoder and decoder must have a unique name. Duplicate names are prohibited. It should be noted that assigning a name to an encoder does not actually replace the MAC address. The **Name** field provides a descriptive identifier, rather than a MAC address.*

- Click the **Config-Icon** drop-down list to select the desired icon for this source. This is optional. If no icon is selected, then the default icon will be used. In this example, we will select **ESPN**, since a ESPN is connected to this encoder.

The set device source-display iconName command can also be used to assign an icon to a device. See [API Command Listing \(page 63\)](#) for more information.



- Enter the **Manufacturer**, **Model**, and **Serial Number** of the source or display in the appropriate fields. By default, these fields are set to "Unknown". These fields must not be blank. If a custom value is provided, it must *not* contain spaces.



The **Manufacturer**, **Model**, and **Serial Number** can also be assigned using the following commands, respectively. See [API Command Listing \(page 63\)](#) for more information.

- ▶ `set device source-display manufacturer`
- ▶ `set device source-display model`
- ▶ `set device source-display serialNumber`

10. Enter the location of the source or display device in the **Location** field. By default, this field is set to "Unknown". This field must not be blank. If a custom value is provided, it must *not* contain spaces.
11. The `set device source-display location` command can also be used to set these values. See [API Command Listing \(page 63\)](#) for more information for more information.
12. Use the **Config-IP Mode** section to configure the IP setting for the encoder. By default, both encoders and decoders are set to DHCP mode and will be discovered automatically by the Management Platform. To manually configure the IP settings of the encoder, click the **Mode** drop-down list and select `static`. Once in static mode, the information in the **Address**, **Mask**, and **Gateway** fields can be edited.

The screenshot displays the 'ESP1 - Source' configuration interface. On the left, a sidebar shows the 'free' logo and a 'Sources (4)' section with a thumbnail for 'ESP1' featuring the NBC logo. The main configuration area is titled 'ESP1 - Source' and includes a close button (X). It contains several expandable sections: 'Summary', 'ID', 'Status', and 'Config'. The 'Config' section is expanded, revealing the following settings:

- IP Mode:** A dropdown menu currently set to 'DHCP'.
- IP Address:** 172.16.6.33
- IP Mask:** 255.255.255.0
- IP Gateway:** 172.16.6.1

A 'Save IP' button is located at the bottom right of the configuration area.

13. Use the **Baudrate** section of **Config** to configure the RS232 settings for the control device, such as an automation control system. Click the **Baudrate** drop-down list to select the desired baud rate of the control device.

The screenshot shows a configuration window titled "Config". Under "IP Mode", a dropdown menu is set to "DHCP". Below this, the IP Address is 172.16.6.40, IP Mask is 255.255.255.0, and IP Gateway is 172.16.6.1. A horizontal line separates the IP settings from the RS232 settings. The "Baudrate" dropdown is set to "57600". Below it, "Data Bit" has radio buttons for 7 and 8, with 8 selected. "Stop Bit" has radio buttons for 1 and 2, with 1 selected. "Parity" has radio buttons for Even, Odd, and None, with None selected.

The **Device IP** settings can also be assigned using the `set device ip dhcp` and `set device ip static` commands. When assigning **RS232** settings from the command line, use the `set device rs232` command. See [API Command Listing \(page 63\)](#) for more information.

14. By default, ZyPer4K and ZyPerUHD Encoder audio format parameters will inherit the Server Default configuration.

Force PCM - Ignore the Server Default setting and restrict the EDID to PCM audio only

Allow Compressed - Ignore the Server Default setting and allow Compressed audio on the encoder.

NOTES: For this setting to work properly, the source's audio configuration should be set to automatically determine audio, if possible. If the source is not able to automatically determine audio, it needs to be manually set to the desired auto format. Downmixing hdmi audio (sending audio out of the analog port) can only be done if the hdmi stream is PCM – not compressed.

The screenshot shows the "Audio Format:" section with three radio button options: "Server Default" (selected), "Force PCM", and "Allow Compressed".

Encoder and Decoder Status Information

You can obtain status information about an *encoder* and its source at any time, from the **Source Config** page.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Left-click the desired source name and select the **Status** option from the context menu.


▼ **Status**

State:	Up
Cable:	Connected
HDCP:	Inactive
Horizontal Resolution:	3840
Vertical Resolution:	2160
Refresh Rate:	29.999
Video Multicast Address:	224.1.1.1
Downmix Audio Multicast Address:	Unknown
Analog Audio Multicast Address:	224.1.1.4
Firmware:	4.0.1.0

Deleting, Rebooting or Resetting an Encode or Decoder

If an encoder or decoder is disconnected from the network, the Management Platform will continue to display the encoder or decoder within the ZMP until it is removed. Note that; reconnecting the encoder or decoder will cause it to once again be displayed in the ZMP.


1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Source** tab at the left of the page.



- a. Left-click on the desired encoder or decoder and select **Actions** from the context menu.



- b. Click the **Delete** button.



3. The following prompt will be displayed when deleting a *source*.

Are you sure?

Would you like to delete device Airshow4K?

Cancel


Delete

4. Click the **Delete** button to confirm the operation. Click the **Cancel** button to cancel the operation.
5. This same menu can be used to Reboot the device or set the device back to Factory Defaults by clicking the appropriate button.

Sending a CEC Command

Both the ZyPer4K and ZyPerUHD can send CEC on/off commands from within ZMP. The ZyPer4K can send additional CEC hex commands as well.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Source** tab at the left of the page.




► To send a CEC command:

- a. Left-click on the desired encoder or decoder and select **Actions** from the context menu.



- b. Click the desired **CEC On** or **OFF** button. (ZyPer4K or ZyPerUHD)




The image shows a screenshot of a web interface titled "Actions". Inside this panel, there are several buttons and a text input field. At the top are "CEC On" and "CEC Off" buttons. Below them is a "Hex:" label followed by an empty text input box. Further down are "Reboot", "Factory Defaults", and "Delete" buttons.

3. The ZyPer4K can also send Hex commands over CEC. Just type the Hex command into the box. When completed, click anywhere outside of the Hex input box to send the command.

Sending an RS232 String Command

Both the ZyPer4K, ZyPerUHD and ZyPerHD can be sent RS232 strings from the ZMP to be output on the RS232 port of the unit.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Source** tab at the left of the page.



- ▶ To send an RS232 string command:
 - a. Left-click on the desired encoder or decoder and select **Actions** from the context menu.




- b. Scroll down to the RS232 box and enter desired text. Click anywhere outside the box to send the text string command.



Updating Firmware

If there is a firmware update available for the ZyPer4K, ZyPerUHD or ZyPerHD, the update can be performed easily from within ZMP.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Source** tab at the left of the page.




► To delete an encoder or decoder:

- a. Left-click on the desired encoder or decoder and select **Actions** from the context menu.



- b. Drag and drop the appropriate firmware update file into the box and click on the **“Update Device”** button.



The screenshot shows a web interface with a dropdown menu titled "Actions". The menu contains several buttons: "CEC On", "CEC Off", a "Hex:" label followed by an empty text input field, "Reboot", "Factory Defaults", and "Delete". Below these buttons is a section titled "Update Device Firmware" which contains a large dashed rectangular box with the text "Drop file here, or click here to select file." and an "Update Device" button at the bottom.

3. You will be prompted to confirm this the desired action. Confirm the action by clicking the Update button. The ZyPer unit will automatically reboot itself once the firmware update is complete.




The screenshot shows a confirmation dialog box with the title "Are you sure?". The main text asks, "Would you like to update the device Thailand with semtech_blueriver_4.0.1.0rc8-zeevee.apz?". At the bottom right, there are two buttons: "Cancel" and "Update".


Creating Video Walls

One of the purposes of the Management Platform is to create and manage video walls. A video wall is a collection of displays or projectors arranged in a square or rectangular fashion. The source is then “mapped” to each display, thereby creating one large display from multiple, smaller displays.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Walls** tab at the left of the page.



3. In the **Walls** pane, click on the **+** button to create a new video wall.



4. This will bring up the wall **Editor**.

Walls

Editor

Please set the values for Rows and Columns below to greater than zero.

Name

Rows

Columns **Bezel**

5. Enter the number of display columns in the **Number of Columns** field.
6. Enter the number of display rows in the **Number of Rows** field.

In this example, we have arranged our displays in two rows and two columns. This is a blank 2x2 *video wall*:

Editor

Name

Rows

Columns **Bezel**


- Drag Displays from the **Display** pane into the Editor to populate the wall. Provide a name for the new video wall in the **Name** field. Values in this field cannot contain spaces. Since more than one *video wall* can be created, always be sure to provide a descriptive name. This field cannot be blank.

The screenshot shows a software interface for configuring video walls. It is divided into two main sections: 'Walls' and 'Displays'.

The **Walls** section contains an **Editor** pane. Inside the Editor, there are three 4K display icons arranged in a 2x2 grid. The top-left, top-right, and bottom-left positions are occupied by 4K displays, each labeled with its position (TopLeft, TopRight, BotLeft) and a '2' indicating two displays. The bottom-right position is empty. Below the display grid, there is a **Name** field containing '4KWall' and an **Update** button. Below the name field, there are **Rows** and **Columns** settings, both set to '2'. There are also **Bezel** settings for Top, Bottom, Left, and Right, all set to '0'.

The **Displays** section is on the right. It has a search filter 'filter for name...' and four selection checkboxes. Below the filter, there are three 4K display icons labeled BotLeft, TopLeft, and TopRight, each with a '2' and a trash icon.

- Leave the **Bezel Top**, **Bezel Bottom**, **Bezel Left**, and **Bezel Right** set to 0. Bezel compensation will be covered in the next section.
- Click the **Create** button.
- The new Wall will now be available within the Walls window.
- Video Walls are deleted by clicking on the small Trash Can icon. The user will be prompted to confirm deletion.



Bezel Compensation

Every video output device has an area where video is not displayed. This area is called the *bezel*. *Bezel compensation* takes this area into account when a single video source is divided and displayed on multiple output devices.

1. Check the output on the video wall and identify any misaligned edges. For best results, it is recommended to use a static video pattern for this test.

In the illustration on the left, we have a 2x2 video wall without *bezel compensation*. Note the ZeeVee logo is not aligned correctly across all four displays. On the right, *bezel compensation* is used to fix the issue.



Without Bezel Compensation




With Bezel Compensation


It is recommended that when the video wall is set up for the first time, that these values be set to zero. *Bezel compensation* can be changed at any time.

Bezel compensation is always measured in pixels.

2. Left click the edit video wall button in the lower left corner of the desired wall.



- The video wall editor will come back up onto the screen.




- Enter the desired values, in pixels, for each bezel field: **Bezel Top**, **Bezel Bottom**, **Bezel Left**, **Bezel Right**.
- Once the desired values have been entered, click the **Update** button. This will save the new settings.
- Check the picture on the displays. Repeat steps 2 - 5 as necessary.
- Note:** Only the ZyPer4K allows bezel adjustment. Video walls with the ZyPerHD or ZyPerUHD do not allow bezel adjustment.

Creating a Multiview Screen


One of the purposes of the Management Platform is to create and manage multiview screens. A multiview screen is a collection of sources arranged on a single display. There can be up to 9 sources displayed on a single display in a variety of preset patterns.

Note: Only the ZyPer4K versions with the HDMI 2.0 feature support multiview screens. This feature is not supported by the ZyPerHD, ZyPerUHD or ZyPer4K units with only HDMI 1.4 support.


1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Multiview** tab at the left of the page.




3. In the **Multiview** pane, click on the **+** button to create a new video wall.




4. This will bring up the Multiview editor where you can create and customize a multiview display.




5. Click on the **Patterns** button in the lower right corner to bring up a list of pre-defined patterns.




6. After selecting a pattern you will see the grid fill in with the places to drag sources.



7. Drag sources into the various locations. Note: The same source can be dragged into multiple windows as long as the windows are the same size. Dragging a source onto different size windows is NOT supported.



- If desired, assign Audio from one of the Sources. This is done by clicking on one of the small Audio symbols in the top center of each Window. Note that only audio from one source is supported.




- Give the Multiview a name and press the **Save** button.
- To use the Multiview, drag the newly created multiview onto a Display in the **Display** pane.


Creating Zones

In many installations, displays are placed in more than one room. These rooms are often referred to as *zones*. Creating a *Zone*, using the Management Platform, allows you to organize these displays in a group. *Video Walls* can also be added to *Zones*.


1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Zones** option at the left of the page.




3. In the Zones window, click on the **+** symbol to add a Zone.



- This will open the Zones Editor. Drag Display and Video Walls into the Zone from the **Displays** or **Walls** windows.




- Continue adding the desired displays (or *video walls*) to the drop-pane.




- Provide a name for the *Zone*. If a custom name is used, it must not contain spaces. In this example, we will call our Zone, "ConferenceRm", since our displays are installed in a conference room. It is recommended that a unique and descriptive name be used to identify each *Zone*.

- Click the **Create** button to save the *Zone*. Close the editor window to exit without saving changes.
- The new *Zone* will appear under the **Zones** window.



- Zones are deleted by clicking on the small Trash Can icon. The user will be prompted to confirm deletion.




Device Grid Page

This page is used to show all encoder/decoders in a text based grid. Information shown includes device name, type, MAC address, Model, IP address, EDID and Connected Encoder (Decoders only)

Device Grid

This section provides information about the Management Platform, such as the host name, IP address, MAC address, version, serial number, uptime duration, and free memory.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Device Grid** option at the left of the page.



3. Device information will be shown in a grid format. You may want to close other windows to be able to maximize the size of the grid.

zeevee										ZyPer Management Platform		Admin
Device Grid (19)												Filter By
Name	Type	MAC	Model	IP Address	Mask	EDID Type	EDID Info		Connected Encoder	Receiving Video		
Laptop	encoder	34:1b:22:80:26:2a	ZyperHD	172.16.6.94	255.255.0.0	Builtin	zyper4k30			No		
ConferenceRoom	encoder	34:1b:22:80:28:fe	ZyperHD	172.16.6.87	255.255.0.0	Builtin	zyper4k30			No		
BrandVideoLoop	encoder	34:1b:22:80:29:37	ZyperHD	172.16.6.88	255.255.0.0	Builtin	zyper4k30			No		
WildlifeHD	encoder	34:1b:22:80:29:38	ZyperHD	172.16.6.86	255.255.0.0	Builtin	zyper4k30			No		
DigitalSignage	encoder	34:1b:22:80:29:69	ZyperHD	172.16.6.95	255.255.0.0	Builtin	zyper4k30			No		
Cuba	encoder	d8:80:39:9a:96:7	Zyper4K	172.16.6.40	255.255.255.0	Builtin	zyper4k30			Yes		
Cam1	encoder	d8:80:39:9a:afa3	Zyper4K	172.16.6.39	255.255.255.0	Builtin	zyper4k30			Yes		
Camera4	encoder	d8:80:39:9a:e6:d	Zyper4K	172.16.6.33	255.255.255.0	Builtin	zyper4k30			Yes		
Thailand	encoder	d8:80:39:eb:1:cb	Zyper4K	172.16.6.106	255.255.255.0	Builtin	zyper4k30			No		
Preview	decoder	34:1b:22:80:26:74	ZyperHD	172.16.6.96	255.255.255.0	SAMSUNG		Laptop		No		
Samsung-HD	decoder	34:1b:22:80:29:a8	ZyperHD	172.16.6.90	255.255.255.0	CP9687		Laptop		No		
TopRightHD	decoder	34:1b:22:80:29:ae	ZyperHD	172.16.6.91	255.255.255.0	CP9687		N/A		No		
BotLeftHD	decoder	34:1b:22:80:29:af	ZyperHD	172.16.6.92	255.255.255.0	CP9687		N/A		No		
BotRightHD	decoder	34:1b:22:80:29:c4	ZyperHD	172.16.6.93	255.255.255.0	unknown		N/A		No		
TopLeftHD	decoder	34:1b:22:80:29:c7	ZyperHD	172.16.6.89	255.255.255.0	CP9687		N/A		No		
Bot-Right	decoder	d8:80:39:9a:fa:1	Zyper4K	172.16.6.71	255.255.255.0	SyncMaster		Cam1		Yes		
Top-Right	decoder	d8:80:39:9a:7f:ec	Zyper4K	172.16.6.42	255.255.255.0	SyncMaster		Cuba		Yes		
Top-Left	decoder	d8:80:39:9a:b5:37	Zyper4K	172.16.6.41	255.255.255.0	SyncMaster		Camera4		Yes		
Bot-Left	decoder	d8:80:39:9b:3a:84	Zyper4K	172.16.6.43	255.255.255.0	LG Ultra HD		N/A		No		

- Clicking on any device name in the grid will allow you to manually enter a new name.

		Name	Type
		Laptop	
<input type="checkbox"/>		Laptop	encoder 3
<input type="checkbox"/>		ConferenceRoom	encoder 3
<input type="checkbox"/>		BrandVideoLoop	encoder 3
<input type="checkbox"/>		WildlifeHD	encoder 3

- Clicking on pencil symbol will open Device Details window.

View and change details of one device.

4K
ZVdec1

ZVdec1 - Display ✕

- ▶ Summary
- ▶ Connections
- ▶ ID
- ▶ Status
- ▶ Config
- ▶ Actions

- Clicking on the drop down option for EDID Info will allow you to select a specific EDID for an encoder.

Device Grid (19)											Filter By
Name	Type	MAC	Model	IP Address	Mask	EDID Type	EDID Info	Connected	Receiving		
Laptop	encoder	34:1b:22:80:26:2a	ZyperHD	172.16.6.94	255.255.0.0	Builtin	zyper4k30		No		
ConferenceRoom	encoder	34:1b:22:80:28:fe	ZyperHD	172.16.6.87	255.255.0.0	Builtin	zyper4k30		No		
BrandVideoLoop	encoder	34:1b:22:80:29:37	ZyperHD	172.16.6.88	255.255.0.0	Builtin	zyper4k30		No		
WildlifeHD	encoder	34:1b:22:80:29:36	ZyperHD	172.16.6.86	255.255.0.0	Builtin	zyper4k60		No		
DigitalSignage	encoder	34:1b:22:80:29:69	Zyper4K	172.16.6.95	255.255.0.0	Builtin	zyper4k60-hbraudio		No		
Cuba	encoder	d8:80:39:9a:96:7	Zyper4K	172.16.6.40	255.255.255.0	Builtin	zyper4k60-hd-hdr		Yes		
Cam1	encoder	d8:80:39:9a:afa:3	Zyper4K	172.16.6.39	255.255.255.0	Builtin	zyper4k60-hdr-bt2020		Yes		
Camera4	encoder	d8:80:39:9a:e6:d	Zyper4K	172.16.6.33	255.255.255.0	Builtin	zyper4k60-hdr-bt2020-hbraudio		Yes		
Thailand	encoder	d8:80:39:eb:1:cb	Zyper4K	172.16.6.106	255.255.255.0	Builtin	zyper4k60-hdr-hbraudio		Yes		
Preview	decoder	34:1b:22:80:26:74	ZyperHD	172.16.6.96	255.255.255.0		zyperHd60		No	aptop	
Samsung-HD	decoder	34:1b:22:80:29:a8	ZyperHD	172.16.6.90	255.255.255.0		zyperPc		No	aptop	
TopRightHD	decoder	34:1b:22:80:29:ae	ZyperHD	172.16.6.91	255.255.255.0		zyperUhd30-hbraudio		No	/A	
BotLeftHD	decoder	34:1b:22:80:29:af	ZyperHD	172.16.6.92	255.255.255.0		zyperUhd60-420		No	/A	
BotRightHD	decoder	34:1b:22:80:29:c4	ZyperHD	172.16.6.93	255.255.255.0		zyperUhd60-hbraudio		No	/A	
TopLeftHD	decoder	34:1b:22:80:29:c7	ZyperHD	172.16.6.89	255.255.255.0		zyperUhd60-hd-hdr		No	/A	
Bot-Right	decoder	d8:80:39:5a:7:41	Zyper4K	172.16.6.71	255.255.255.0		zyperUhd60-hdr		Yes	am1	
Top-Right	decoder	d8:80:39:9a:7:ac	Zyper4K	172.16.6.42	255.255.255.0		zyperUhd60-hdr-bt2020		Yes	uba	
Top-Left	decoder	d8:80:39:9a:5:37	Zyper4K	172.16.6.41	255.255.255.0		zyperUhd60-hdr-hbraudio		Yes	amera4	
Bot-Left	decoder	d8:80:39:9b:3a:84	Zyper4K	172.16.6.43	255.255.255.0		LG Ultra HD		No	N/A	


Server Functions Page

The majority of this page is used to display general information about the Management Platform. In addition, this page provides controls for setting the EDID mode and rebooting or restarting the server. Server firmware can also be updated from this window. For detailed instructions on how to update the ZMP, please refer to appendix 5


Server Information

This section provides information about the Management Platform, such as the host name, IP address, MAC address, version, serial number, uptime duration, and free memory.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Server** option at the left of the page.



3. Information about the Management Platform will be displayed in the **Server** pane.



Setting the EDID Mode

By default, Auto EDID mode is *enabled*. This means that the Management Platform will compare the encoder EDID with the decoder EDID. If they are different, then the EDID from the decoder (sink) will be used by the encoder (source). Setting the EDID Mode affects all join modes: fast-switched, genlocked, and video-wall. Refer to the [join](#) command in the [API Command Listing](#) (page 63) section for more information.

1. Login to the ZMP. Refer to [Accessing ZMP](#) (page 13) for more information.
2. Click the **Server** tab at the left of the page.
3. EDID information will appear in the **Server** window under the Status information. You may need to scroll down in the window to see the EDID information.

Note: There is a check box at the bottom of the Server window for “**Show advanced controls**” This box must be checked to enabled changing of the EDID mode setting.

Config

Encoder Default Audio Format

Force PCM

Allow Compressed

EDID Mode


Enabled

Disabled

Server Reboot, Restart, and Shutdown

The Management Server can be rebooted, restarted, or shut down from the Server window. Each option affects the Management Server in different ways, as listed below.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Server** tab at the left of the page.
3. Reboot, Restart and Shutdown options will appear in the **Server** window under the Status information. You may need to scroll down in the window to see these options.



4. Click the desired button under **Server Functions**.
 - ▶ **Restart**
Restarts the server. Linux is not restarted.
 - ▶ **Reboot**
Linux is rebooted.
 - ▶ **Shut Down**
Shuts down the Management Server.
 - ▶ **Trouble Report**
Generates a trouble report than can be provide to ZeeVee support.

Server License and Update

The License for the Management Server can be updated to increase the maximum number of supported endpoints and their Server software version can also be updated.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Server** tab at the left of the page.
3. Scroll down to the License option..

The screenshot displays a web interface for managing server licenses. At the top, there is a 'Server' tab. Below it, the 'License' section is visible. It contains the following information:

- Product ID:** 038D0240-045C-0532-4406-CB0700080009
- License:** none (displayed in a text input field)
- Limit:** 48
- Devices Exceeded:** 0


At the bottom of the license section, there is a button labeled 'Update License'.

4. Record the Product ID number and provide this to ZeeVee. This ID is used by ZeeVee to generate the new license key when purchased by a customer.
5. Once received, you can enter a new license key as provided by ZeeVee to increase the limit on the number of endpoints. (Please contact ZeeVee support for additional information)
6. Please see the Appendix of this document for information on updating the Server Software. **Note:** In a redundant environment, Software must be updated on slave first, then switchover, then update on new slave. See online help section 11.2

Help Page

The **Help** page provides a help reference for each page within the ZMP.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Help** tab at the left of the page.
3. The Management Platform **Help** window will be displayed.




4. Click the desired section. As the mouse pointer moves over each section, the text will become underlined.

Users and Roles Pages


The **Users** page provides the ability to create additional users beyond the Administrator and in conjunction with the **Roles** page assign different access/abilities to each user.

1. Login to the ZMP. Refer to [Accessing ZMP \(page 13\)](#) for more information.
2. Click the **Users** tab and **Roles** tab at the left of the page.
3. The Management Platform **Users** and **Roles** windows will be displayed.



The first User shown in the Users window is Admin. The Admin account cannot be deleted and the name cannot be changed. You can however change the password from the default of “admin” to a password of your choosing.

Click on the edit icon within the Admin user. The following screen will appear and allow you to change the password.



The screenshot displays the Zeevee user management interface. At the top, there is a navigation menu with three horizontal lines, the Zeevee logo, and a green checkmark with the number '2'. Below this is a 'Users' window with a close button. Inside the 'Users' window is an 'Editor - Admin' window, also with a close button. The 'Editor - Admin' window contains the following fields:

- Full Name:** A text input field containing 'Admin'.
- User ID:** A text input field containing 'admin'.
- Password:** A text input field with a pink background and a red border. Below the field is the text '(At least one character of any type)'. The field is currently empty.
- Password Verification:** A text input field with a pink background and a red border. The field is currently empty.
- Force password change on next sign in
- Save:** A button in the bottom right corner.

Enter the new password on both the "Password" and "Password Validation" lines and then hit the "Save" button in the lower right corner.

It is recommended to record this new password in a secure location.

Adding a New User

To create a new user click on the “+” symbol in the **Users** window. The screen shown below will appear. Enter the Full Name, User ID and Password for the new user. You can keep this password or force the user to generate a new password the first time they login by clicking the “Force password change on next sign in” box.


Save the user by clicking the Save button in the lower right corner.

The screenshot shows a window titled "Users" with a close button (X) in the top right corner. Inside this window is a sub-window titled "Editor - Sample User" with its own close button (X). The sub-window contains the following elements:

- Full Name:** A text input field containing "Sample User".
- User ID:** A text input field containing "samuser".
- Password:** A password input field with the text "*****" and a note below it: "(At least one character of any type)".
- Password Verification:** A password input field with the text "*****".
- Force password change on next sign in:** A checkbox that is currently unchecked.
- Buttons:** "Cancel" and "Save" buttons are located at the bottom of the sub-window.


Adding or Editing a Role

To create a new role click on the “+” symbol in the **Roles** window. The screen shown below will appear. In the General tab enter the Role Name. In the example below the name is “Junior Admin”.



The screenshot shows a window titled "Roles" with a close button (X) in the top right corner. Below the title bar is a search field labeled "filter for name...". Inside the window, there is a sub-window titled "Editor - Junior Admin" with its own close button (X). This sub-window also has a search field labeled "filter for name...". Below the search field are three tabs: "General", "Users", and "Permissions". The "General" tab is selected. Under the "General" tab, there is a section titled "Role Name" with a text input field containing the text "Junior Admin". At the bottom of the sub-window, there are two buttons: "Cancel" on the left and "Save" on the right.

The next thing you will need to do is assign Permissions to this new role. To do this click on the Permissions tab.



There are 10 categories that can be assigned different levels of access within the Permissions tab. Sources, Displays, Zones, Walls, Multiview, Logs, Help, Users, Roles and Server. Most categories have 2 or 3 levels of access:

View: User is allowed to access the designated tab within ZMP


Config: User is allowed to alter or create new configurations within the designated tab. For example the user can create a new Wall, Multiview or Zone.

Admin: User has full functional control over configurations, including ability to delete sources and displays.


Click on the appropriate levels of access to set permission. The process is color coded to make it easier. Green = Full access, Yellow = Partial access, Red = No access.

Be sure to Save any changes before moving to the step of assigning specific users these permission levels.

You need to have both the **Users** and **Roles** windows visible to assign a User with a set of Roles / Permissions. Open the Users tab in the Roles window and drag a specific User from the User window over. (Drag the “person” icon located to the far left next to user ID)



Be sure to Save any updates.



In example above, “Art” was dragged over to “Junior Admin” role. Be sure to Save this setting before closing the **Roles** window.

3 Advanced Operation

Accessing the API

Using Telnet

Telnet is a popular protocol that can be used on both Windows® and Mac OS® operating systems to connect to the programming shell. On a Windows operating system, a Telnet client, such as “PuTTY”, must be installed. From a Unix or Mac OS command line, use the `telnet` command followed by the IP address of the Management Platform:

```
telnet 192.168.1.6
```

Instead of specifying the IP address of the Management Platform, the following identifier can also be used: `zyper.local`

Example: `telnet zyper.local`

Telnet will use port 23 by default and once connected, the API prompt will be displayed:

```
Zyper$
```

Getting Help

Help is available in two forms. Typing `help` or `?` at the prompt will list all available commands:

```
Zyper$ help
add device ip-address <ip>
add zone-display <zoneName[.zoneName]> <decoderMac|decoderName|wallName>
...
...
...
update device <deviceNamePart>|all|encoders|decoders <filename>
update server <filename>
Zyper$
```

In addition, a partial list of commands can be listed by specifying the first word of each command. The first part of the command must be specified *before* the `help` command. For example, the following will only list command with the `join` prefix.

```
Zyper$ join help
join <encoder:macOrNameOrNone> <decoder:macOrName> genlocked
join <encoder:macOrNameOrNone> <decoder:macOrName> fast-switched
join <encoder:macOrName> <decoder:macOrName> analog-audio
Zyper$
```

Setting the Time Zone

The Management Platform uses the Network Time Protocol (NTP) to set the date and time. However, the time zone will need to be specified.

1. Telnet to the Management Platform.

```
telnet 192.168.1.6
```

2. After the connection has been established, use the `set server timezone` command to set the time zone.

The time zone must be specified in POSIX format and is case-sensitive. Refer to the following link for more information:

http://wikipedia.org/wiki/List_of_tz_database_time_zones.

```
Zyper$ set server timezone America/New_York
Success
Zyper$
```


Use the `show server info` command to verify the correct time zone has been set.

```
Zyper$ show server info
server(192.168.1.78);
  server.gen; hostname=zyper.local, version=2.0.35220, previousVersion=2.0.35125, macAddress=1c:1b:0d:82:ff:1a,
serialNumber=ZZM1H500032B
  server.gen; uptime=0d:0h:13m:13s, freeMem=7.007GB, bootCount=6
  server.gen; runningInVm=false
  server.time; time=Thu Apr 25 22:15:34 2019, timezone=America/
New_York
  server.license; productID=031B021C-040D-0582-FF06-1A0700080009,
license=JSGH-RLUH-0000-116F-9328-F426-4BB5-89E2-024D-8CBE-FF1C
  server.license; limit=unlimited, knownDevices=16, devicesUp=0,
devicesExceeded=0
  server.deviceUpdates; active=0
Success
Zyper$
```

EDID Management

Auto EDID Mode

By default, Auto EDID mode is *enabled*. This means that the Management Platform will compare the encoder EDID with the decoder EDID. If they are different, then the EDID from the decoder (sink) will be used by the encoder (source). Setting the EDID Mode affects all join modes: fast-switched, genlocked, and video-wall. Refer to the [join](#) command in the [API Command Listing \(page 63\)](#) section for more information.



Using Custom EDID Data

There may be some instances where a custom EDID is desired. One example is when using a single encoder with multiple displays, such as a *video wall*. In such a case, follow the steps below to save and load a custom EDID to the Management Platform.

1. Telnet to the Management Platform.

```
telnet 192.168.1.6
```

2. Disable Auto EDID mode by entering the following command:

```
zyper$ set server auto-edid-mode disabled
```

3. Use the `save device-edid` command to save the EDID of the sink device (attached to the decoder) to the Management Platform, using the following convention:

```
save device-edid [id] [filename]
```

Make sure to replace `[id]` with the identifier of the sink device containing the EDID you wish to capture. You can specify either a MAC address or a name identifier. Follow the identifier with the name of the EDID file. For example:

```
zyper$ save device-edid SonyXBR4 myEDID
```

4. After executing this command, two files will be created under the following directory:

```
/srv/ftp/files/myEDID  
/srv/ftp/files/myEDID.txt
```

`myEDID` is a binary EDID data file in standard format. `myEDID.txt` contains the decoded EDID in standard ASCII text.

These files must remain in this directory when disabling Auto EDID mode.

5. To force a ZyPer encoder to use the saved EDID you need to have the MP load the binary EDID file onto the desired encoder.

```
zyper$ load encoder-edid [id] saved [filename]
```

Make sure to replace `[id]` with the identifier of the source device you want to load the EDID onto. You can specify either a MAC address or a name identifier. Follow the identifier with the name of the EDID file. For example:

```
zyper$ load encoder-edid BlueRay1 saved myEDID
```

6. To return to Auto EDID mode, for any reason, enter the following command at the prompt:

```
zyper$ load encoder-edid BlueRay1 auto
```

or

```
zyper$ set server auto-edid-mode enabled
```

Using AJAX/JSON

The AJAX/JSON programming interface allows developers to control the Management Platform within browser-based applications. All calls to the server are asynchronous post/receive operations using Javascript and do not require any specific HTML or CSS code. We will present two examples in this section: Login authentication and command request/response.

Login Authentication

There are two methods to authenticate with the server. The first and recommended method is to pass the username and password to `rcLogin.php`. The second method is to pass the username and password in every AJAX request.

Once the server accepts the username and password, it will generate a secure cookie called "userToken". This cookie will expire one hour after the last AJAX command is received by the server. After the cookie expires, all other AJAX requests will result in a failed authentication until `rcLogin.php` is called again. The following code excerpt is from the `zyperLogin()` function within `zyper.html`:

```
...
...
xmlhttp=new XMLHttpRequest();
xmlhttp.onreadystatechange = function(){
    if (xmlhttp.readyState == 4 && xmlhttp.status == 200){
        procLoginResp(xmlhttp.responseText);
    }
}
postdata = "";
postdata += encodeURIComponent("serverSocketName") + '=' +
    encodeURIComponent(socketName) + '&' +
    encodeURIComponent("username") + '=' +
    encodeURIComponent(username) + '&' +
    encodeURIComponent("password") + '=' +
    encodeURIComponent(password) + '&';
xmlhttp.open("POST", url, true);
xmlhttp.setRequestHeader("Content-Type", "application/x-www-form-urlencoded");
xmlhttp.send(postdata);
}
```

The response is a string value. The variable `resp` can be "Success", "Failed", or "Server not running".

```
function procLoginResp(jsonData) {
    var resp = JSON.parse(jsonData);
    ...
    ...
}
```

Command Request / Response

After login, any further commands are sent to the rcCmd.php

The following code excerpt sends an AJAX request to list all ZyPer encoders and decoders:

```
function zt(){
    xmlhttp = new XMLHttpRequest();
    xmlhttp.open("POST", url, true);
    xmlhttp.setRequestHeader("Content-Type", "application/x-www-form-
urlencoded");
    xmlhttp.onreadystatechange = function(){
        if (xmlhttp.readyState == 4 && xmlhttp.status == 200){
            procResp(xmlhttp.responseText);
        }
    }
xmlhttp.send(encodeURIComponent("commands:show device-status
all"));
}
```

In this example, the `encodeURIComponent` function has two parts: The request type, which is `commands` and the command `show device-status all`. Refer to the [show device status](#) command for more information. Currently, `commands` is the only request type that is supported and only a single command can be supplied for each request.

Here, we handle the AJAX response:

```
function procRespTest(jsonData){
    var jsData = JSON.parse(jsonData);
    # jsData.status may have the values:
    # "Success"
    # "Request failed authentication"
    # "Server not running"
    # "no commands provided"
    #
    if (jsData.status == "Success"){
        var element = document.getElementById("responseError");
        element.innerHTML = jsData.responses[0].error;
        element = document.getElementById("responseWarning");
        element.innerHTML = jsData.responses[0].warning;
        element = document.getElementById("numObjectsInResponse");
        element.innerHTML = jsData.responses[0].text.length;
    }
    else{
        // Failed authentication
    }
}
```

The JSON data is decoded using the `JSON.parse()` method. In this example, information about the response data is displayed on the web page (HTML code not shown).

The JavaScript object that is returned is:

```
var jsObj = {
  status: true | false;
  responses: [ {error: "errorText",
               warning: "warningText",
               text: [ { param1: "vall", parmN: "paramN" } ]
             }
            ]
};
```

The return value is an object that contains two members: `status` and `responses`. If the `status` member is not equal to "Success", then the `responses` member is not valid. If the request fails authentication, then the `status` value will be "Request failed authentication". Note that there may be other web-server level failures that can be returned in the `status` string.

The second member in the returned object, `responses`, which is an array of objects. Each of these objects contains three members: `error`, `warning`, and `text`. The `error` and `warning` members are strings. The `text` member is an array of objects with the desired parameters and values. If the `error` string is non-null, then the `warning` and `text` members will be null. If `text` is non-null, then the `warning` string may still be valid.

Currently, the `responses` member is always an array size of 1.

Fast-Switched vs. Genlocked Mode

The ZyPer4K provides two uniquely different modes for joining video/audio between a source (encoder) and display (decoder). The chart below details the differences between these two modes.

Feature	<i>Fast-Switched</i>	<i>Genlocked</i>
Latency	1-frame of latency. (16-33ms depending on frame rate of source video)	0 frames of latency. Less than 100µs
Transition Appearance	Instantaneous if switching between sources at same resolution and frame rate	Visible blanking of display when switching between sources
Scaling	Automatic scaling up or down to preferred resolution of the display (As determined by display EDID)	Source is not scaled. What comes in at source is presented to display exactly as input. (Note: Special Genlock-scaled mode is available)
HDR	HDR input is automatically reduced to 8-bits at output	HDR input is maintained exactly as input at the output
Dolby / Encoded Audio	Dolby or other encoded audio formats are passed from encoder to decoder (New in 2.0 release)	Dolby or other encoded audio formats are passed from encoder to decoder
Video Wall	Video walls are technically not supported in Fast-Switched mode. (Join command for walls defaults to Genlock-scaled)	Video walls are technically always in Genlock-scaled mode
Multiview	Multiview is supported in Fast-Switch mode	Multiview is not supported in Genlocked mode
USB, IR, RS232	None of these items are associated with Fast-Switched or Genlocked mode	

API Command Listing

Command	Description
<code>add device</code>	Manually adds a device to Management Platform
<code>add zone-display</code>	Adds a display or Video wall to an existing zone.
<code>channel</code>	Cycles up or down through encoders. Used to change channels.
<code>create zone</code>	Creates a new empty zone.
<code>create multiview</code>	Creates a new multiview display (ZyPer4K only)
<code>create video-wall</code>	Creates an empty 2x2 video wall.
<code>data-connect</code>	Creates a TCP port connection between devices for IR or RS232
<code>delete all-configuration</code>	Deletes all encoder/decoder and server information from the Management Platform
<code>delete device</code>	Deletes the specified encoder or decoder from the Management Platform database.
<code>delete multiview</code>	Deletes the specified multiview from the Management Platform database. (ZyPer4K only)
<code>delete multiview-window</code>	Deletes a specific window from an existing multiview (ZyPer4K only)
<code>delete video-wall</code>	Deletes the specified video wall from the Management Platform database.
<code>delete zone</code>	Deletes an existing zone
<code>delete zone-display</code>	Removes a display from an existing zone
<code>events</code>	Causes the event mode to be entered
<code>factory-defaults device</code>	Sets the specified encoder/decoder to factory-default settings.
<code>flash-leds</code>	Physically identifies the specified encoder/decoder on the network using LED flashes. (ZyPer4K only)
<code>join</code>	Switches audio and/or video from source to display or video wall
<code>join video-source</code>	Selects audio feed to follow a video join
<code>load encoder-edid</code>	Uploads an EDID file to the specified encoder
<code>logging</code>	Used to set logging level and add notes to the log
<code>preview-stream</code>	Used to turn on/off the preview stream viable in the Management Platform GUI (ZyPer4K and ZyPerUHD only)
<code>redundancy switchover</code>	Swap Management Platform Master and Slave
<code>redundancy delete down-servers</code>	Removes no longer present servers from list of redundant servers
<code>restart device</code>	Restarts the specified encoder/decoder
<code>restart server</code>	Restarts the Management Platform

Command	Description
<code>restore server database</code>	Restores a saved database
<code>revert server</code>	Switch to a previously installed version of the API
<code>save device-edid</code>	Saves the EDID from a decoder to a local file
<code>save server database</code>	Saves current server database to file
<code>send</code>	Sends an IR, CEC or RS232 string to the specified device
<code>script</code>	Executes the specified AJAX/JSON or text script.
<code>send</code>	Sends an IR or RS232 string to the specified device
<code>set encoder analog-audio-out source</code>	Sets the source of Analog audio output for specified encoder (ZyPer4K and ZyPerUHD only)
<code>set encoder audio-format</code>	Sets allowable input audio formats
<code>set encoder hdcp-mode</code>	Sets the HDCP compatibility at the encoder side
<code>set decoder connection-mode</code>	Changes current connection to decoder to fast-switched, genlocked or genlocked-scaled. (ZyPer4K only)
<code>set decoder display-mode</code>	Sets default decoder output to crop, stretch or box
<code>set decoder display-resolution</code>	Set decoder output size to auto or manual resolution. (Width, Height, FPS)
<code>set decoder analog-audio-out source</code>	Sets the source of Analog audio output for specified decoder
<code>set decoder edid-prefer-mode</code>	Sets the preferred resolution from the display EDID
<code>set decoder hdmi-audio-out source</code>	Sets the source of HDMI audio output for specified decoder
<code>set decoder power-save</code>	Enables or disables power-save feature (ZyPerUHD only)
<code>set device ethernet-management port</code>	Enables or disables the 1G Ethernet utility port for the specified device (ZyPer4K only)
<code>set device general name</code>	Sets the name for the specified device.
<code>set device ip dhcp link-local</code>	Sets the specified device to DHCP or Link-Local mode (ZyPer4K only)
<code>set device ip static</code>	Sets the device to static mode (ZyPer4K and ZyPerUHD only)
<code>set device rs232</code>	Sets the RS232 settings for the specified device

Command	Description
<code>set device send-ip-mcast-range</code>	Sets allowable range of multicast addresses for selected devices (ZyPer4K only)
<code>set device source-display iconImageName</code>	Sets the icon image for the specified device.
<code>set device source-display location</code>	Sets the location name for the specified device.
<code>set device source-display manufacturer</code>	Sets the manufacturer name for the specified device.
<code>set device source-display model</code>	Sets the model name for the specified device
<code>set device source-display serialNumber</code>	Sets the serial number name for the specified device
<code>set device usb-filter</code>	Allows restrictions to USB use on selected device (ZyPer4K only)
<code>set device video-port</code>	Selects active input port for ZyPer4K units with multiple inputs (ZyPer4K only)
<code>set multiview</code>	Assigns source to a position and size within a multiview display (ZyPer4K only)
<code>set multiview audio-source window-number</code>	Selects the input source to provide Audio for multiview display (ZyPer4K only)
<code>set multiview canvas-size</code>	Specifies Multiview canvas for multiview creation. (ZyPer4K only)
<code>set responses rs232-term-chars</code>	Specifies the RS232 termination string
<code>set server auto-edid-mode</code>	Sets the EDID mode
<code>set server data-transfer-mode</code>	Sets server transfer mode to raw or telnet
<code>set server ip</code>	Sets the IP address of the Management Platform
<code>set server license</code>	Sets server license. (Max endpoints)
<code>set server redundancy</code>	Set a virtual IP address/mask for Master and Slave Management Platforms
<code>set server ssh password</code>	Used to set ssh password
<code>set server telnet mode</code>	Used to enable or disable telnet access
<code>set server telnet password</code>	Used to set telnet password
<code>set server timezone</code>	Sets the time zone
<code>set video-wall</code>	Creates a new video wall or modifies an existing wall
<code>set video-wall decoder</code>	Assigns the specified decoder to a position within the video wall

Command	Description
<code>show data-relays</code>	Shows what rs232 or IR data relay ports are opened on the server.
<code>show device capabilities</code>	Shows detailed capabilities of specified device or devices
<code>show device config</code>	Shows detailed configuration information for specified device or devices
<code>show device connections</code>	Shows encoder connections to decoders
<code>show device status</code>	Provides detailed status informatoin for specified device or devices
<code>show device user-added</code>	Will show a list of all ZyPer endpoints that have been manually added with the add device command
<code>show multiviews config</code>	Lists all created multiviews with source, position and size info (<i>ZyPer4K only</i>)
<code>show multiviews status</code>	Lists all created multiviews with source, datarate and multicast address info (<i>ZyPer4K only</i>)
<code>show preview-streams</code>	Lists names of encoders currently generating a preview stream. (<i>ZyPer4K and ZyPerUHD only</i>)
<code>show responses</code>	Displays the lastChangeld for the specified device
<code>show server config</code>	Displays the IP address and EDID mode of the Management Platform
<code>show server info</code>	Displays Management Platform information
<code>show server redundancy</code>	Displays information about Master and Slave Management Platforms
<code>show video-walls</code>	Displays a list of all created video walls
<code>show zones</code>	Displays a list of zone and displays contained within
<code>shutdown server</code>	Shuts down or reboots the Management Platform
<code>sleep</code>	Sets a time dely, in milliseconds
<code>stop encoder</code>	Stop a specified stream (<i>ZyPer4K only</i>)
<code>start encoder</code>	Start a specified stream (<i>ZyPer4K only</i>)
<code>switch</code>	Switches IR or RS-232 between devices
<code>trouble-report</code>	Generates a trouble report
<code>update device</code>	Updates the individual encoder or decoder units
<code>update server</code>	Updates the Management Platform software. See Updating the Software (page 210) for more information.

add device

Used to manually add a device to the ZyPer Management Platform that are located on a different VLAN/Subnet than the ZMP itself.

A qualified network engineer should be involved in making these configuration updates and the network switch provider may need to be consulted to ensure support of needed features.

Syntax

```
add device ip-address ip
```

Parameters

i

Type: **IP Address**

The IP address of the device

Example

```
add device ip-address 192.168.10.81  
Success
```

Detailed Example

The ZyPer4K Endpoints are located on VLAN 10 and the 192.168.10.X subnet. The ZyPer Management Platform is on VLAN 20 and the 192.168.20.X subnet.

The ZMP will automatically discover any ZyPer4K endpoints located on VLAN 20. The ZMP will NOT automatically discover any ZyPer4K endpoints located on VLAN 10. However, given the proper circumstances, the ZyPer4K endpoints on VLAN 10 can be manually added to the ZMP for control.

For this to work, the network MUST be configured to route traffic between VLAN 10 and VLAN 20. How to configure the network to allow routing between VLANs is beyond the scope this document and should be done by a qualified network engineer. A simple test to confirm routing is that a device in VLAN 10 can ping a device in VLAN 20.

The ZyPer4K endpoints need to have a known IP Address. The IP Address should either be assigned by a DHCP server or assigned statically.

ZyPer4K endpoints need to be added one at a time.

You can get a listing of all "user added" devices with the "show device user-added" command.

add zone-display

Adds a display or video-wall to an existing zone.

Care should be taken that individual displays found within walls are not added to a Zone. This would result in the same display being in a zone more than once.

Syntax

```
add zone-display id
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device. String names are case-sensitive.

Example

```
add zone-display myWall
Success
```

Related Commands

```
create zone
delete zone
delete zone-display
show zones
```

channel

Will cycle through all encoders (of the same type as the decoder) that have a number (channel) suffix, “_nnn”, where nnn is an integer (channel).

If there are encoders with names: enc_1, enc_100, enc_50, then a decoder will cycle through them in the order: enc_1, enc_50, enc_100, then back to enc_1.

If there are no encoders (of the same type as the decoder) with the channel suffix, an error is returned.

Only fast-switch connection types is supported. If there was already a connection of some other type, it is changed to Fast-Switched.

If the decoder has no connection, the encoder with the lowest channel suffix will be connected using fast-switch.

If the decoder has a connection to an encoder that does not have the channel suffix, then it will connect to the encoder that has the lowest channel suffix.

Note: In Fast-Switch mode the join video-source <decoder> command must be used to set audio to follow video join. Otherwise audio will not follow the video during channel up/down command.

Syntax

```
channel direction <decoder-id>
```

Parameters

direction

Type: **STRING**

argument	Description
up	cycle to next higher numbered encoder
down	cycle to next lower numbered encoder

decoder-id

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

Example

```
channel up MyDecoder
Channel changed to Channel_2
Success
```

Related Commands

[join video-source](#)

create multiview

Creates an empty multiview display. (**ZyPer4K only**) Once created, the new multiview will be listed under the **Multiview** menu within the built-in ZMP.

Use the `set multiview` command to set a source encoder to a specified location and size within the multiview.

Refer to [Creating a Multiview Screen \(page 42\)](#) for information on managing multiview displays in the built-in ZMP.

Syntax

```
create multiview name
```

Parameters

name

Type: **STRING**

The name of the multiview. The name of the multiview cannot exceed 255 characters in length. Names are case-sensitive.

Example

```
create multiview myMultiview
Success
```

Related Commands

```
delete multiview
delete multiview-window
set multiview
set multiview audio-source window number
show multiviews config
show multiviews status
```


create video-wall

Creates an empty 2x2 video wall. Once created, the new video wall will be listed under the **Display Config** menu within the built-in ZMP.

Use the `set video-wall-encoder` command to assign a source encoder to the wall. To modify the size of the video wall and/or control bezel parameters, use the `set video-wall` command.

Refer to [Creating Video Walls \(page 37\)](#) for information on managing video walls in the built-in ZMP.

Syntax

```
create video-wall name
```

Parameters

name

Type: **STRING**

The name of the video wall. The name of the video wall cannot exceed 255 characters in length. Names are case-sensitive.

Example

```
create video-wall myWall
Success
```

Related Commands

```
delete video-wall
set video-wall
```

create zone

Creates an empty zone. Once created, the new zone will be listed under the **Zones** menu within the built-in ZMP.

Use the `add zone-display` command to assign decoders or video walls to the zone.

Syntax

```
create zone name
```

Parameters

name

Type: **STRING**

The name of the zone. The name of the video wall cannot exceed 255 characters in length. Names are case-sensitive.

Example

```
create zone Zone1  
Success
```

Related Commands

```
add zone-display  
delete zone  
delete zone-display  
show zones
```

data-connect

Connects two devices for IR or RS232 communication over a specified TCP port.

The feature of data-relays was added to allow a third party to connect to the ZMP server with a specific port and pass raw or telnet API commands (depending on the mode) to the server and port which is designated for a particular encoder or decoder.

Syntax

```
data-connect id1 id2 mode tcp-port port
```

Parameters

id1

Type: **STRING**

The name of the first device. String names are case-sensitive.

id2

Type: **STRING**

The name of the second device or server. String names are case-sensitive.

mode

Type: **STRING**

ir or rs232

port

Type: **INTEGER**

TCP-Port #. Integer range from 1,024 to 49,152

Example

```
data-connect Encoder1 server ir tcp-port 8573
Relay TCP port = 8573; telnet handshake mode
Success
```

Related Commands

```
show data-relays
```

delete all-configuration

Deletes all device and server information from the Management Platform. The network configuration is preserved.

Syntax

```
delete all-configuration action
```

Parameters

action

Type: **STRING**

Supply one of the following arguments before executing this command.

argument	Description
reboot	Unit is automatically rebooted
restart	The ZyPer server service is restarted
shutdown	Unit is shutdown

Example

```
delete all-configuration restart
```

Related Commands

```
factory-defaults device
```

delete device

Deletes the specified device from the Management Platform database.

Note that if the deleted device remains on the network, then it will be rediscovered by the Management Platform and reposted to the database. To permanently remove a device from the database, physically disconnected it and execute the `delete device` command.

Syntax

```
delete device id
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device. String names are case-sensitive.

Example

```
delete device myDevice  
Success
```

```
delete device 0:1e:c0:f6:42:a1  
Success
```

Related Commands

[factory-defaults device](#)

delete multiview

Deletes the specified multiview from the database on the Management Platform. (ZyPer4K only)

Syntax

```
delete multiview name
```

Parameters

name

Type: **STRING**

The name of the multiview. Names are case-sensitive.

Example

```
delete multiview myMultiview  
Success
```

Related Commands

```
create multiview  
delete multiview-window  
set multiview  
set multiview audio-source window number  
show multiviews config  
show multiviews status
```

delete multiview-window

Deletes the specified window from an existing multiview. (ZyPer4K only)

Syntax

```
delete multiview-window name window arg
```

Parameters

name

Type: **STRING**

The name of the multiview. Names are case-sensitive.

arg

Type: **INTEGER**

Window number to remove. Integer range from 1 to 9

Example

```
delete multiview-window myMultiview window 5  
Success
```

Related Commands

```
create multiview  
delete multiview  
set multiview  
set decoder multiview audio-source window number  
show multiviews config  
show multiviews status
```

delete video-wall

Deletes the specified video wall from the database on the Management Platform.

Syntax

```
delete video-wall name
```

Parameters

name

Type: **STRING**

The name of the video wall. Names are case-sensitive.

Example

```
delete video-wall myWall  
Success
```

Related Commands

```
create video-wall  
set video-wall
```


delete zone

Deletes the specified zone from the database on the Management Platform.

Syntax

```
delete zone name
```

Parameters

name

Type: **STRING**

The name of the zone. Names are case-sensitive.

Example

```
delete zone zone1  
Success
```

Related Commands

```
add zone-display  
create zone  
delete zone-display  
show zones
```

delete zone-display

Deletes the specified display from an existing zone.

Syntax

```
delete zone-display name id
```

Parameters

name

Type: **STRING**

The name of the zone. Names are case-sensitive.

id

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder/display. String names are case-sensitive.

Example

```
delete zone-display myzone mydisplay1  
Success
```

Related Commands

```
add zone-display  
create zone  
delete zone  
show zones
```

events

Causes the events mode to be entered.

Syntax

```
events
```

Server sends initial events and new events as they occur to the telnet session. Any character entered to the server causes the mode to exit back to the API prompt.

See Section 4 of this document for additional details on the events feature.

factory-defaults device

Set the specified device to the factory-default settings.

Syntax

```
factory-defaults device id
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device. String names are case-sensitive.

Example

```
factory-defaults device Airshow  
Success
```

```
factory-defaults device 0:1e:c0:f6:a8:c3  
Success
```

Related Commands

```
delete all-configuration
```

flash- leds

Physically identifies the specified device on the network. When this command is executed, the fiber LED indicators on the device will flash for 5 seconds. (ZyPer4K only)

Syntax

```
flash- leds id
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device. String names are case-sensitive.

Example

```
flash- leds myEncoder  
Success
```

```
flash- leds 0:1e:c0:f6:59:13  
Success
```

join

Joins the specified decoder (display) with the specified encoder (source). The *mode* parameter must be specified and defines the type of join to execute.

- ▶ **analog-audio**
Embeds audio stream from the encoder on the output of the decoder. The audio can be from the HDMI input or from the (analog) Audio jack on the encoder. In order to control what type of audio is being sent from an encoder, refer to the `set device` command.
- ▶ **fast-switched**
Allows the joining of an encoder and decoder with no video dropout. In order to make use of this feature, the resolution and frame rate of the “new” encoder must be the same as the previous encoder.
- ▶ **genlocked**
This mode provides a very low-latency, all-purpose method of joining an encoder and decoder. (ZyPer4K only)
- ▶ **genlocked-scaled**
This mode provides a very low-latency, all-purpose method of joining an encoder and decoder that includes scaling up or down at the decoder/display.
- ▶ **hdmi-audio**
Embeds hdmi-downmix audio from an encoder to specified decoder.
- ▶ **multiview**
Join the configured multiview to a display (decoder) (ZyPer4K only)
- ▶ **video**
Joins video only from encoder to decoder. No audio.
- ▶ **video-wall**
Join the encoder to the named video-wall
- ▶ **window**
Join any portion of a source to any portion of a display
- ▶ **usb**
Creates USB connection between encoder and decoder. Note that multiple connections are valid.
- ▶ **none**
Special command to disconnect existing connections (joins) Example: `join none decoder fast-switched`

Syntax

```
join enc dec mode
join none dec fast-switched
```

Parameters

enc

Type: **STRING** or **MAC Address**

The name or MAC address of the encoder. String names are case-sensitive.

dec

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder. Can also be name of existing video-wall String names are case-sensitive.

zone

Type: **STRING**

The name of an existing zone. String names are case-sensitive.

mode

Type: **STRING**

Supply one of the following arguments before executing this command.

argument	Description
analog-audio	Embed audio from the specified encoder
fast-switched	Join in "fast-switched" mode
genlocked	Low-latency join mode (ZyPer4K only)
genlocked-scaled	Low-latency with scale up/down (ZyPer4K only)
hdmi-audio	Join hdmi--audio to either hdmi-out or analog-out. Note this command will cause hdmiAudioFollowVideo=False for specified decoder. See join video-source command on next page.
multiview	Join a multiview to a display (ZyPer4K only)
video-wall	Join a source to a video-wall
video	Join video only (audio not joined)
window	Join any portion of a source to any portion of a display (ZyPer4k only)
usb	Establish USB connection
"none"	Disconnect existing joins

Notes:

Multiviews cannot be joined to a zone.

USB cannot be joined to a zone.

Examples

```
join myEncoder1 myDecoder2 fast-switched  
Success
```

```
join myEncoder1 myDecoder2 hdmi-audio  
Success
```

```
join myMultiview2 Display4 multiview  
Success
```

```
join myEncoder1 myWall video-wall  
Success
```

```
join none myDecoder1 fast-switched
```

Window Example

```
join myEncoder1 myDecoder2 window viewport-source 0 0 1920 1080  
viewport-dest 500 500 500 500
```

(Viewport-source parameters are starting X/Y coordinates of the source and desired X/Y size)

(Viewport-dest parameters are starting X/Y coordinates in the display and desired X/Y size)

join video-source

Tells a decoder to automatically join corresponding audio from a source encoder whenever a join command is used to join video.

Syntax

```
join video-source dec mode
```

Parameters

dec

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

mode

argument	Description
audio	automatically join audio from connected encoder (ZyPerUHD only)
hdmi-audio	automatically join hdmi-audio from connected encoder (ZyPer4K only)

Example

```
join video-source MyDecoder hdmi-audio
Success
```

Related Commands

```
join hdmi-audio
```

load encoder-edid

Uploads an EDID file to the specified encoder.

Important Note: Auto-EDID mode should be disabled when loading a specific EDID to an encoder. Otherwise the loaded EDID will immediately get replaced by the Auto-EDID option.

Syntax

```
load encoder-edid enc mode file
```

Parameters

enc

Type: **STRING** or **MAC Address**

The name or MAC address of the encoder. String names are case-sensitive.

mode

argument	Description
auto	use whatever EDID information is provided by connected decoder
built-in	use one of the EDID files provided by ZeeVee. Many options available covering various 4k settings. See list below.
saved	use a file that user has previously saved to the system with the save device-edid command

file

Type: **STRING**

The name of the file to load.

Build in EDID options

```
zyper-default
zyper4k30
zyper4k60
zyper4k60-420
zyper4k60-hbraudio
zyper4k60-hd-hdr
zyper4k60-hdr
zyper4k60-hdr-bt2020
zyper4k60-hdr-bt2020-hbraudio
zyper4k60-hdr-hbraudio
zyperHd60
zyperPc
zyperUhd30
zyperUhd30-hbraudio
zyperUhd60
zyperUhd60-420
zyperUhd60-hbraudio
zyperUhd60-hd-hdr
zyperUhd60-hdr
zyperUhd60-hdr-bt2020
zyperUhd60-hdr-bt2020-hbraudio
zyperUhd60-hdr-hbraudio
```

Examples

```
load encoder-edid myEncoder saved myEDID.bin
Success
```

```
load encoder-edid myEncoder built-in zyper4k60
Success
```

Related Commands

```
save device-edid
set server auto-edid-mode
```

logging

Used to set the level of detail captured by Trouble Reports and manually add text notes into log for Trouble report. To be used at direction of ZeeVee support team to aid in troubleshooting of issues.

Syntax

```
logging level arg
```

Parameters

arg

Type: **INTEGER**

Logging Level. Integer range from 1 to 4

Example

```
logging level 2  
Success
```

Syntax

```
logging note string
```

Parameters

string

Type: text

String with length from 1 to 132 characters

Example

```
logging note "my inserted text"  
Success
```

preview-stream

Used to turn on/off a small thumbnail size preview stream that is viewable in the ZyPer Management Platform GUI. (ZyPer4K and ZyPerUHD only)

Syntax

```
preview-stream enc arg comp width size
```

Parameters

enc

Type: **STRING** or **MAC Address**

The name or MAC address of the encoder. String names are case-sensitive.

arg

argument	Description
stop	used to manually stop the preview stream. Note that it can be turned back on from the GUI
start	used to manually start the preview stream.

comp

argument	Description
hls	set the format of the preview stream to HLS
jpeg	set the format of the preview stream images to JPEG

size

Type: **Integer**

Width of the preview stream in pixels. (180 to 400)

Example

```
preview-stream MyEnc start hls width 300
BWG: After Start Preview Streams running = 3
Success
```

```
preview-stream MyEnc stop
Success
```

HLS Notes

A maximum of 20 preview streams may be enabled at a single time.

ZyPer4K devices must be on firmware release 4.0.1.0 or newer for this feature to work.

The HLS stream can be viewed by any HLS capable viewer such as a browser. The path needed is shown below:

```
http://mp_ip_address/media/encoder_mac_address.m3u8
```

mp_ip_address is the IP address of the ZyPer Management Platform
encoder_mac_address is the MAC address of the Z4K encoder

Example

```
http://192.168.0.78/media/d8:80:39:eb:1c:ee.m3u8
```

JPEG Notes

JPEG images cannot be viewed in the ZyPer Management Platform GUI. This feature is intended for 3rd party control systems to grab individual JPEG images. (1 per second)

The JPEG images can be viewed by any JPEG capable viewer such as a browser. They can also be directly downloaded to a system. The path needed is shown below:

```
http://mp_ip_address/media/encoder_mac_address.jpeg
```

mp_ip_address is the IP address of the ZyPer Management Platform
encoder_mac_address is the MAC address of the Z4K encoder

Examples

```
http://192.168.0.78/media/d8:80:39:eb:1c:ee.jpeg
```

```
curl http://192.168.0.78/media/80:1f:12:4d:bb:11.jpeg > preview.jpg
```

redundancy switchover

If there is an active slave, this command causes the existing master to become the slave and the existing slave to become the master. The server does not restart or re-initialize any other state, including any existing video and audio connections.

The IP address that is always assigned to the master. If the active slave becomes the master, this IP address will then terminate at that system. Note that any existing TCP connection will terminate and have to be reopened (to the new master).

Syntax

```
redundancy switchover
```

Parameters

none

Example

```
redundancy switchover  
Success
```

Related Commands

```
set server redundancy  
redundancy delete down-servers
```

redundancy delete down-servers

Cleans up and removes any redundant servers from server list that are no longer available in the system.

Syntax

```
redundancy delete down-servers
```

Parameters

none

Example

```
redundancy delete down-servers  
Success
```

Related Commands

```
set server redundancy  
redundancy switchover
```


restart device

Restarts the specified device.

Syntax

```
restart device id
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device. String names are case-sensitive.

Example

```
restart device myEncoder2  
Success
```

```
restart device 0:1e:c0:f6:cb:76  
Success
```

Related Commands

```
restart server
```

restart server

Restarts the server. Linux is not restarted.

Syntax

```
restart server
```

Parameters

none

Example

```
restart server  
Success
```

Related Commands

```
restart device
```

restore server database

Restores a stored server database from file. (Stored on the ZyPerMP hardware)

Important Note: Saved database to be restored MUST have been created using the exact same version of API that is currently running.

Syntax

```
restore server database name
```

Parameters

name

Type: **STRING**

The name of the stored database. Names are case-sensitive.

Example

```
restore server database jan16_2019
Loaded database jan16_2019; restarting server
Success
```

Related Commands

```
save server database
```

revert server

Returns to a previously installed version of the API and device database.

This feature can be used to go back to a previous software version and database version in case of a failed software upgrade. Primarily used to recover previous state if something goes wrong.

Syntax

```
revert server
```

Note: The show sever info command will identify the Previous Version that will be restored to the system.

Example

```
revert server
Reverting from update_nuc_1.8.34605.zyper to update_nuc_2.0.34928.
yper
Success
```

Related Commands

```
show server info
```

save device-edid

Saves the EDID of the downstream sink to the `srv/ftp/files` folder on the Management Server. Executing this command will generate two file types: `.bin` and `.txt`. The `.bin` file is the EDID in standard format. The `.txt` file is the decoded EDID data. See [Using Custom EDID Data \(page 65\)](#) for more information on using this command.

Syntax

```
save device-edid id file
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the decoder that is connected to the sink device. String names are case-sensitive.

file

Type: **STRING**

The name of the EDID file. Two files will be created using the *file* name: `.txt` and a file with no extension.

Example

```
save device-edid 0:1e:c0:f6:a5:2f myEDID
Success
```

Related Commands

```
load encoder-edid
set server auto-edid-mode
```

save server database

Saves the current MP database to a file. (Stored on the ZyPerMP hardware)

Syntax

```
save server database name
```

Parameters

name

Type: **STRING**

The name of the database. Names are case-sensitive.

Example

```
save server database jan16_2019
Saved database to jan16_2019
Success
```

Related Commands

```
restore server database
```

script

Executes the specified script. The script must exist in the `/srv/ftp/files` folder. Use the optional `loop` argument to place the script in a loop. The script will continue running until a key is pressed on the keyboard.

Syntax

```
script file [loop]
```

Parameters

file

Type: **STRING**

The name of the script file.

Example

```
script myScript  
Success
```

Related Commands

[sleep](#)

send

Sends an IR or RS232 string to the specified device. Use the *type* parameter to specify an IR or RS232 code.

Syntax

```
send id type text
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device.

type

Type: **STRING**

Specifies IR, CEC or RS232 command

argument	Description										
<i>ir</i>	The string must be the hex representation of the binary data. (Pronto code) The maximum length for a string is 256 characters. (ZyPer4K only)										
<i>cec</i>	on off (Used to turn a device on or off) (ZyPerUHD and ZyPer4K only)										
<i>cec hex-string</i>	hex-numerals-no-delimiters (ZyPer4K only)										
<i>rs232</i>	The string is ASCII and must not exceed 256 characters in length. Spaces and the following control characters are supported as a portion of the string: <table border="0" style="margin-left: 20px;"> <tr> <td style="padding-right: 20px;">\n</td> <td>New line</td> </tr> <tr> <td style="padding-right: 20px;">\r</td> <td>Carriage return</td> </tr> <tr> <td style="padding-right: 20px;">\t</td> <td>Tab</td> </tr> <tr> <td style="padding-right: 20px;">\\</td> <td>Slash</td> </tr> <tr> <td style="padding-right: 20px;">\xnn</td> <td>Hex value, where nn is a two-digit hex value, including leading zeros</td> </tr> </table>	\n	New line	\r	Carriage return	\t	Tab	\\	Slash	\xnn	Hex value, where nn is a two-digit hex value, including leading zeros
\n	New line										
\r	Carriage return										
\t	Tab										
\\	Slash										
\xnn	Hex value, where nn is a two-digit hex value, including leading zeros										

text

Type: **STRING**

The string to send. See the table, above, for restrictions.

set encoder analog-audio-out

Sets the analog audio output source type for the specified encoder. (ZyPer4K and ZyPerUHD only)

Syntax

```
set encoder id mode type
```

Parameters

id
Type: **STRING** or **MAC Address**
The name or MAC address of the encoder. String names are case-sensitive.

mode
Type: **STRING**
The audio output to use.

argument	Description
analog-audio-out	Audio output from the Audio port on the Encoder.

type
Type: **STRING**
The audio mode (analog or HDMI).

argument	Description
source none	No analog audio output from the encoder
source hdmi-downmix	Uses downmixed audio from input HDMI stream.

Example

```
set encoder Myencoder1 analog-audio-out source hdmi-downmix
Success
```

set encoder audio-format

Sets the allowable audio input formats at the encoder. (ZyPer4K and ZyPerUHD only)

Detailed Background

ZeeVee added a feature that will allow compressed formats to be passed down in an encoder EDID file. This EDID will be then forwarded to the source device to determine the type of audio sent to the encoder.

This enhancement was to provide fast-switched connections the “compressed audio” options in the EDID file. Prior to this version with the fast-switched connection, ZeeVee modified the EDID passed from the decoder to the encoder and removed all compression formats. This left just LPCM as the only option under the “Audio data block” in the edid file.

>>> Audio data block <<<

Linear PCM, max channels 8

Supported sample rates (kHz): 192 176.4 96 88.2 48 44.1 32

Supported sample sizes (bits): 24 20 16

The information provided to the Video Source device (such as BluRay Player or Media player) increases the possibility of compression being a chosen audio format. However it is still up to the device to choose uncompressed or compressed formats. It is important to know that some devices such as the Apple 4K TV requires the audio output type to be set (even if the audio format is available in the EDID). Compression will need to be set manually on these types of devices.

In addition any downmixed stream internal to ZyPer devices will not process compressed audio, so you will not hear compressed audio on these connections.

Syntax

```
set encoder id mode
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the encoder. String names are case-sensitive.

mode

Type: **STRING**

The supported input audio mode

argument	Description
force-pcm	Force PMC audio format at encoder. Does not allow compressed formats such as Dolby.
allow-compressed	Passes the decoders edid with unmodified audio information and thus allows compression options to be seen.
server-default	Follows the server setting

Example

```
set encoder Encoder1 audio-format allow-compressed
Success
```

Related Commands

```
set server encoder-default-audio-format
```

Additional Information

In an attempt to properly Identify the Audio Streams used under the product the following changes were also made along with some modification to the API commands.

Product	Old Audio Stream Name	New Stream Name
ZyPer4K	hdmi (used in genlocked mode)	hdmi-passthrough-audio
ZyPer4K	hdmi-audio-downmix	hdmi-audio
ZyPer4K	analog-audio	No Change
ZyPerUHD	audio	hdmi-audio
ZyPerUHD	analog-audio	No Change
ZyPerHD	Part of fast-switched connection	No Change
ZyPerHD	Part of fast-switched connection	No Change

set encoder hdcp-mode

Sets the hdcp mode for the specified encoder.

Syntax

```
set encoder id mode type
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the encoder. String names are case-sensitive.

mode

Type: **STRING**

The hdcp mode to use

argument	Description
hdcp-mode	HDCP mode of the Encoder.

type

Type: **STRING**

The audio mode (analog or HDMI).

argument	Description
enabled	encoder will accept HDCP 1.4/2.2 compatible streams
disabled	encoder will reject HDCP 1.4/2.2 compatible streams.

Example

```
set encoder Myencoder1 hdcp-mode disabled
Success
```

Notes

Useful when user does not want Source such as Apple Macbook to provide HDCP protected content to the Encoder.

set decoder

Sets the audio output type and video timing details for the specified decoder.

Syntax

```
set decoder id mode type
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

mode

Type: **STRING**

argument	Description
analog-audio-out	Audio output from the Audio port on the decoder.
connection-mode	Sets/changes current connection mode to decoder. (Options are fast-switched, genlocked and genlocked-scaled) (ZyPer4K only)
display-advanced-timing	Set advanced features, Front porch, sync width, sync polarity and total size
display-mode	Set display to box, crop or stretch input stream within display resolution
display-resolution	Set display resolution manually (pixels) or automatically based on EDID.
hdcp-mode	Allows user to force HDCP protection at level 1.4 or 2.2 on previously unprotected content. (ZyPerUHD only)
hdmi-audio-out	Audio output from the HDMI port on the decoder.

type

Type: **STRING**

HDCP options. (Note: Valid with ZyPerUHD only) Used to minimize connection time.

argument	Description
auto	Maintain existing HDCP level. None if none
force-version-1.4	Apply HDCP 1.4 protection to output stream
force-version-2.2	Apply HDCP 2.2 protection to output stream

The audio mode (analog out or HDMI out).

argument	Description
source analog-audio	Uses the audio output created with the join command.
source hdmi-audio	Uses the HDMI stream (HDMI audio-out only) Use if video in Fast-Switch mode.
source hdmi-passthrough-audio	Used if video is in Genlock mode.
source hdmi-audio-downmix	Uses the HDMI-downmix stream.

Display timing, aspect ratio, mode, size.

argument	Description
sync-front-porch	Synchronization mode.
sync-width	Synchronization width
hsync-polarity	Horizontal sync polarity (auto, negative, positive)
vsync-polarity	Vertical sync polarity (auto, negative, positive)
total-size	Horizontal and vertical size (Pixels or auto)
box	Box image within display. (Smaller source to larger display)
crop	Crop image within display (Larger source to smaller display)
stretch	Scale image to fill display. (Scale up or down) (Default Setting)
pixelsHoriz	Width in pixels or auto
pixelsVert	Height in pixels or auto
fps	Frames per second
source	Match decoder resolution to source input size
auto	automatically based on EDID

Command Description: Override output display size and fps

```
set decoder <Decoder_Name or MAC> display-resolution active-size <int> pixelsHoriz <int> pixelsVert <int> fps <int>|source
```

This command allows an override of EDID parameters supplied by the display. Regardless of what the supplied EDID indicates, the decoder will generate a stream with specified overall size and frame rate parameters.

Note that in “genlock-scaled” mode, the frame rate parameter is ignored – it must be the same as the encoder frame rate. This does mean care must be taken when setting this parameter if the source stream is 60fps (e.g. 720p60fps) and scaled to 4K. That only works if the display supports 4K60.

If configured resolution specification in these parameters that exceed the displayed maximum resolution, the display will black out with no indication to the user.

Example command:

```
Zyper$ set decoder Dec1 display-resolution active-size 3840 2160 fps 60
```

Command Description: Output display size determined by received EDID

Command Syntax

```
set decoder <Decoder_Name or MAC> display-resolution auto
```

The command causes the decoder to set output display size to the "preferred" value in the EDID received from the display.

Command Description: Override detailed video parameters

Command Syntax

```
set decoder <decoderMac|decoderName> display-advanced-timing active-size <pixelsHoriz:int>
<pixelsVert:int> fps <float> total-size <pixelsHoriz:int> <pixelsVert:int> sync-front-porch
<pixelsHoriz:int> <pixelsVert:int> sync-width <pixelsHoriz:int> <pixelsVert:int> sync-polarity
h-positive|h-negative v-positive|v-negative
```

This command allows an override of EDID parameters supplied by the display. Regardless of what the supplied EDID indicates, the decoder will generate a stream with specified detailed timing parameters.

If configured resolution specification in these parameters that exceed the displayed maximum resolution, the display will black out with no indication to the user.

Example command:

```
Zyper$ set decoder Dec1 display-advanced-timing active-size 1920 1080 fps 60 total-size 2200 1200
sync-front-porch 88 4 sync-width 44 5 sync-polarity h-positive v-positive
```


set decoder edid-prefer-mode

Sets the preferred resolution from the display EDID

Syntax

```
set decoder id mode type
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

mode

Type: **STRING**

argument	Description
edid-prefer-mode	Select preferred EDID mode

type

Type: **STRING**

HDCP options. (Note: Valid with ZyPerUHD only) Used to minimize connection time.

argument	Description
max	Default mode. Selects the largest resolution defined in the EDID.
strict	Selects the Preferred resolution as stated in the display EDID

"max" - Default mode. Selects the largest resolution defined in the EDID. This has been the operating mode prior to this command. In almost all cases, this is the native resolution of the display. However, some displays can accept a resolution above the native (and scale down). In this case, it is better to use the "strict" mode.

"strict" - The Preferred Resolution is selected as defined in the EDID 1.3 specification. EDID 1.3 specifies that the first Detailed Timing Descriptor in the Standard Timing Information block is always the preferred resolution, although it is only the native resolution if the native-resolution flag is set. If the native-resolution flag is not set, then the maximum resolution will be chosen (falls back to "max" mode).

Note: All comparisons of “resolution” actually mean comparisons of the associated Pixel Clock. The Pixel Clock represents the entire resolution definition: horizontal and vertical size, fps, bit-depth and color decimation (RGB/4:4:4, 4:2:2, 4:2:0).

The command will immediately reanalyze the active EDID and if needed change the preferred resolution and reconnect to the encoder.

The reason for the “max” mode, and for it being the default, is that many displays do not follow the EDID 1.3 specification, claiming a native, Preferred Resolution below the display’s actual native resolution. It is fairly common for a UHD display to have an HD resolution as the specified preferred resolution.

Note: ZyPer4K and ZyPerUHD, depending on mode, may support only a limited set of output resolutions, particularly when the scaler is enabled. ZMP will choose the active resolution based decoder capability, scaler mode and preferred resolution. However, the display’s Preferred Resolution is displayed regardless of what the decoder ultimately actually uses. The active resolution is displayed in the decoder status as well.

Overriding Preferred Resolution Selection

It should rarely be required. But if the EDID supplied by the display is not correct, or for some reason ZMP chooses a Preferred Resolution that is not desired, the following command will force the decoder to a specific output resolution:

```
set decoder <decoder> display-resolution active-size <int> <int> fps <float>
```

When set, the decoder output resolution will remain as specified without exception.

Note: When in this mode, it is very possible that no video will be displayed, and with no warning from ZMP. It is up to the user to ensure that the output settings are valid for the display.

Scaler Control

ZyPer4K "HDMI 2.0" and ZyPerUHD decoders have output scaling. Besides the obvious benefit of supporting HD-only displays with a UHD source, the other major benefit is faster switching times. With ZyPer4K, there is virtually no delay. With ZyPerUHD it is less than a one second.

However, there are some cases where disabling the scaler produces a better image. Of course, if the scaler is disabled and the source provides a resolution greater than the display's ability, it will be black. To solve this problem, we have a new mode that disables the scaler, but only if the display can handle the source resolution.

The decoder display-resolution command now has an option called "source".

```
set decoder <decoder> display-resolution source
```

When in "source" mode the scaler is disabled if the display can handle the received resolution. Otherwise it is automatically enabled (e.g. if the source is 480 and the Preferred Resolution is 1080 then the scaler is disabled, but if source is UHD and the Preferred Resolution is 1080, then the scaler is enabled).

The downside to this mode: switching time between non-scaled resolutions is about 3 seconds. Switching time between scaled and non-scaled resolutions is closer to 4s.

Active Output Resolution Selection

Selecting the correct output resolution for a decoder is, unfortunately, a fairly complicated endeavor. Clearly depends on the display (Preferred Resolution), but also on the decoder capability and the source resolution.

Remember: All comparisons of "resolution" actually mean comparisons of the associated Pixel Clock. The Pixel Clock represents the entire resolution definition: horizontal and vertical size, fps, bit-depth and color decimation (RGB/4:4:4, 4:2:2, 4:2:0).

Also, setting "edid-prefer-mode" only affects which Preferred Resolution is chosen. It does not affect when that Preferred Resolution is used (or if it is used). Although the chosen Preferred Resolution is always reported in the decoder status output (as is the chosen active output resolution).

ZyPer4K HDMI 1.4 Devices

No scaler, effectively always in "display-resolution source" mode. Source is always sent to output. If output can't handle source, there will be no video.

Decoder Preferred Resolution is only status; it is never used to affect the decoder output resolution. Decoder "display-resolution" overrides are ignored.

ZyPer4K HDMI 2.0 Devices

Presently, the decoder active resolution is limited to a number of resolutions: 4096x2160, 3840x2160, 1080x1920 or 1280x720. The closest lower resolution is used.

There are a number of exceptions to the operation.

- Scaler always converts to 8bit 444/RGB. That means UHDp60 4:2:0 is converted to UHDp60 4:4:4. UHDp60 YUV 4:2:0 bit rate is lower than HDM 1.4. But UHDp60 4:4:4 is not. In this case, the output FPS is divided by 2.
- If in genlock-scaled, video-wall or window mode, decoder FPS must equal encoder FPS
 - Means 1080p60 scaling to UHD must be UHDp60, which won't work if display is only UHDp30 capable.
 - If UHDp60 > decoder Preferred Resolution, then the output is left at 1080p60.
- If source is 1080i
 - Output must be input FPS * 2
 - If decoder resolution > 1080, it is set to 1080.

display-resolution = auto

When in this mode, the output resolution will always be the **Preferred Resolution**. There really is no reason not to use this mode with the Z4K Charlie and will produce the lowest switching times.

display-resolution = source

When in this mode, the output resolution will always be the **encoder resolution**, unless the source resolution greater than the encoder resolution (same case as display-resolution auto).

This mode may provide better video at or below the preferred resolution of the display. However, the switching time is somewhat slower (~3.3s).

display-resolution = source-ignore-edid

Same operation as display-resolution = auto, but effectively using a manually entered Preferred Resolution. Generally only used if the EDID is incorrect.

ZyPerUHD

The ZyPerUHD scaler scales up fine (source resolution lower than display preferred). However, it can only scale down from UHD to 1080.

Even with this limitation, the vast majority of installations will be fine. The exception comes with PC-based resolutions. For example a case that will not work well:

- 1080-only display and source resolution of 1920x1200

For the cases where VESA/PC resolutions such as 1920x1200, 2560x1440 and 2560x1600 are needed, all displays must be at least that resolution or greater. For example, a 1920x1200 display can handle all resolutions up to 1920x1200 and it can also handle UHD, since the decoder will output UHD scaled down to 1080 (which is fine for a 1920x1200 display).

And, clearly, all of those resolutions will be fine if the displays are UHD capable (scaling up works, plus, the new mode "display-size source" can be used).

If a configuration that causes downscaling that is not handled well, likely generating poor video, a warning will be generated.

display-resolution = auto

When in this mode, the output resolution will always be the **Preferred Resolution**, unless the source resolution greater than the preferred resolution.

This mode provides the fastest switching time (less than 1 second). However, there may be some cases where video quality is less than when using display-resolution = source.

If source is greater than decoder Preferred Resolution, then decoder output will be **1920x1080** (unless the display does not support it) with the preferred FPS. As noted, the only case this normally works for is when the source is 3840x2160.

display-resolution = source

When in this mode, the output resolution will always be the **encoder resolution**, unless the source resolution greater than the encoder resolution (same case as display-size auto).

This mode may provide better video at or below the preferred resolution of the display. However, the switching time is somewhat slower (~3.3s).

display-resolution = source-ignore-edit

Same operation as display-resolution = auto, but effectively using a manually entered Preferred Resolution. Generally only used if the EDID is incorrect.

set decoder power-save

Enables or disables power save feature of the decoder. (ZyPerUHD only)

When decoder is not receiving a stream the decoder will enter a low power mode and the display will go black.

Syntax

```
set decoder id power-save arg
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

arg

Type: **STRING**

Supply one of the following arguments.

argument	Description
enabled	Power save feature enabled.
disabled	Power save feature disabled.

Example

```
set decoder myDecoder power-save enabled  
Success
```

set device ethernet-management-port

Enables or disables the 1Gb Utility Ethernet port on the specified encoder or decoder.
(ZyPer4K only)

Syntax

```
set device id ethernet-management-port arg
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device. String names are case-sensitive.

arg

Type: **STRING**

Supply one of the following arguments.

argument	Description
enabled	Ethernet port is enabled.
disabled	Ethernet port is disabled.

Example

```
set device myDecoder5 ethernet-management-port disabled
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device ip
set device rs232
set device source-display iconImageName
set device source-display location
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```

set device general name

Sets the name for the specified encoder or decoder.

Syntax

```
set device id general name str
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the device. String names are case-sensitive.

str

Type: **STRING**

The name for the device.

Example

```
set device myDecoder5 general name Samsung-55  
Success
```

Related Commands

```
set device analog-audio mode  
set device gig-ethernet-port mode  
set device ip  
set device ip static  
set device rs232  
set device source-display iconName  
set device source-display location  
set device source-display manufacturer  
set device source-display model  
set device source-display serialNumber
```


set device ip

Sets DHCP mode for the specified device.

Syntax

```
set device id ip arg
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

arg

Type: **STRING**

Supply one of the following arguments.

argument	Description
dhcp	IP address assigned by DHCP server
link-local	IP address self assigned Link-Local

Example

```
set device ip dhcp
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip static
set device rs232
set device source-display iconImageName
set device source-display location
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```

set device ip static

Sets static mode for the specified device. The IP address, subnet mask, and gateway must be supplied.

Syntax

```
set device id ip static addr mask gatew
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

addr

Type: **IP Address**

The desired IP address for the device.

mask

Type: **IP Address**

The desired subnet mask for the device.

gatew

Type: **IP Address**

The desired gateway for the device.

Example

```
set device ip static 10.5.68.121 255.255.255.0 10.5.64.1  
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip
set device rs232
set device source-display iconImageName
set device source-display location
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```

set device rs232

Sets the RS232 settings for the specified device.

Syntax

```
set device id rs232 baud data stop parity
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the device. String names are case-sensitive.

baud

Type: **INTEGER**

The baud rate for the device. Supply one of the following values from the table below.

argument		
9600	38400	115200
19200	57600	

data

Type: **INTEGER**

The data bit setting for the device. Supply one of the following values from the table below.

argument
7-bits
8-bits

*stop*Type: **INTEGER**

The stop bit setting for the device. Supply one of the following values from the table below.

argument
1-stop
2-stop

*parity*Type: **STRING**

The parity setting for the device. Supply one of the following values from the table below.

argument
even
odd
none

Example

```
set device decoderNumber2 rs232 57600 8-bits 1-stop none
Success
```

Related Commands

```
send
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip
set device ip static
set device source-display iconName
set device source-display location
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```

set device send-ip-mcast-range

Sets allowable range of multicast addresses for selected devices. (ZyPer4K only)

Syntax

```
set device id send-ip-mcast-range first:ip last:ip
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the encoder. String names are case-sensitive. Can all use “all” or “encoders” as an ID option.

first:ip / last:ip

Type: **Multicast Address**

Supply the starting and ending multicast addresses in the allowable range.

Note: Allowable range is from 224.1.1.1 to 239.255.255.255

Example

```
set device encoders send-ip-mcast-range 224.1.1.25 224.1.2.125
```

Related Commands

```
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip static
set device rs232
set device source-display iconName
set device source-display location
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```

set device source-display iconImageName

Assigns an icon to the desired device. The icon will be displayed within the ZMP to identify the device.

Syntax

```
set device id source-display iconImageName fname
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the encoder or decoder. String names are case-sensitive.

fname

Type: **FILENAME**

The full filename of the icon to be used. The filename is case-sensitive.

argument	Description
abc	ABC network icon
cbs	CBS network icon
nbc	NBC network icon
fox	Fox network icon
xbox	Xbox game console icon
golf	Gold channel icon
espn	ESPN network icon
tennis	Tennis channel icon
cnn	CNN network icon
ps3	PlayStation game console icon
DVD	DVD player icon
BluRay	BluRay icon
VCR	VCR icon
CableBox	Cable box icon
Laptop	Laptop icon
BroadcastCamera	Broadcast camera icon
SecurityCamera	Security camera icon

Example

```
set device Encoder1 source-display iconImageName cbs
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip
set device ip static
set device rs232
set device source-display location
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```


set device source-display location

Assigns a location description for the specified device.

Syntax

```
set device id source-display location loc
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the device. String names are case-sensitive.

loc

Type: **STRING**

The location description of the device (e.g. "Conference_Rm", "Den", etc.). Do not use quotes when specifying this string value.

Example

```
set device myDecoder3 source-display location VideoWall-1
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip
set device ip static
set device rs232
set device source-display iconImageName
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```

set device source-display manufacturer

Assigns a manufacturer description for the specified device.

Syntax

```
set device id source-display manufacturer mfg
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the device. String names are case-sensitive.

mfg

Type: **STRING**

The manufacturer description of the device (e.g. "Sony", "Panasonic", etc.). Do not use quotes when specifying this string value.

Example

```
set device myDecoder3 source-display manufacturer Sony  
Success
```

Related Commands

```
set device analog-audio mode  
set device general name  
set device gig-ethernet-port mode  
set device ip  
set device ip static  
set device rs232  
set device source-display iconImageName  
set device source-display location  
set device source-display model  
set device source-display serialNumber
```

set device source-display model

Assigns a model description for the specified device.

Syntax

```
set device id source-display model model
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the device. String names are case-sensitive.

model

Type: **STRING**

The manufacturer's model number of the device.
Do not use quotes when specifying this string value.

Example

```
set device myDecoder3 source-display model DVPSR210P
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip
set device ip static
set device rs232
set device source-display iconImageName
set device source-display location
set device source-display manufacturer
set device source-display serialNumber
```

set device source-display serialNumber

Assigns the manufacturer serial number for the specified device.

Syntax

```
set device id source-display serialNumber serial
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the device. String names are case-sensitive.

serial

Type: **STRING**

The manufacturer serial number of the device.

Example

```
set device myDecoder3 source-display serialNumber 123456789
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device gig-ethernet-port mode
set device ip
set device ip static
set device rs232
set device source-display iconImageName
set device source-display location
set device source-display manufacturer
set device source-display model
```

set device usb-filter

Allows restrictions to USB use on selected device. (ZyPer4K only)

Syntax

```
set device id usb-filter arg
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the encoder or decoder. String names are case sensitive

arg

Type: **STRING**

Supply one of the following arguments.

argument	Description
none	No restrictions on USB port
except-hid	Allows any USB device except HID devices
storage	Allows any USB device except Storage devices

Example

```
set device myDecoder2 usb-filter none
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device ip
set device rs232
set device source-display iconName
set device source-display location
set device source-display manufacturer
set device source-display model
set device source-display serialNumber
```

set device video-port

Selects active input port for ZyPer4K units with multiple inputs. (ZyPer4K only)

Syntax

```
set device id video-port arg
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the encoder. String names are case sensitive.

arg

Type: **STRING**

Supply one of the following arguments.

argument	Description
hdmi	Use the HDMI input (Located to the right)
hdmi-optional-in	Use the HDMI input (Located to the left). "Primary Input" Dual input HDMI only.
auto	Use whatever port has an active input if only one source is connected. Note only valid for DisplayPort and Dual-HDMI options. Does not work with SDI or Analog inputs.
display-port	Use the Display-Port input
hdsmi	Use the SDI input port
component	Use component input. (Requires ZeeVee Hydra cable)
composite	Use composite input (Requires ZeeVee Hydra cable)
s-video	Use s-video input (Audio not supported)
vga	Use vga input. (Requires ZeeVee VGA cable)

Example

```
set device myEncoder1 video-port display-port
Success
```

Related Commands

```
set device analog-audio mode
set device general name
set device ip
set device rs232
```

set multiview

Assigns source to a position and size within a multiview display. (ZyPer4K only)

Syntax

```
set multiview id window-number wn encoder-name enc position  
percent-position-x posx percent-position-y posy percent-size-x sx  
percent-size-y sy layer ly
```

```
set multiview id window-number wn encoder-name enc position pixel-  
position-x posx pixel-position-y posy pixel-size-x sx pixel-size-y  
sy layer ly
```

Parameters

id

Type: **STRING**

Name of previously created multiview. String names are case-sensitive.

wn

Type: **Integer**

Window number within the multiview (1-9)

enc

Type: **STRING or MAC Address**

The name or MAC address of the source encoder. String names are case sensitive.

posx

Type: **Integer**

X coordinate of multiview window. Upper left corner of window. Represented either as percentage of screen (0-99) or exact pixel location.

posy

Type: **Integer**

Y coordinate of multiview window. Upper left corner of window. Represented either as percentage of screen (0-99) or exact pixel location.

*sx*Type: **Integer**

Size/Length of multiview window. Represented either as a percentage of X dimension or exact pixel size.

*sy*Type: **Integer**

Size/Height of multiview window. Represented either as a percentage of Y dimension or exact pixel size.

*ly*Type: **Integer**

Window Layer. Value from 1-9 with layer 1 being the bottom layer and 9 being the top.

Example

Using Percentages

```
set multiview myMview1 window-number 1 encoder-name myEnc1 percent-  
position-x 50 percent-position-y 50 percent-size-x 25 percent-size-y 25  
layer 3
```

Using Pixel Values

```
set multiview myMview1 window-number 1 encoder-name myEnc1 pixel-  
position-x 1920 pixel-position-y 1080 pixel-size-x 800 pixel-size-y 600  
layer 3
```

Related Commands

```
create multiview  
delete video-wallmultiview  
delete multiview-window  
set device rs232multiview audio-source window-number  
show multiviews config  
show multiviews status
```

set multiview (layer, position, size)

Allows user to change a multiview window layer, position or size without specifying other parameter. (ZyPer4K only)

Syntax

```
set multiview id window-number wn position-x posx position-y posy  
size-x sx size-y sy layer ly
```

Parameters

id

Type: **STRING**

Name of previously created multiview. String names are case-sensitive.

wn

Type: **Integer**

Window number within the multiview (1-9)

posx

Type: **Integer**

X coordinate of multiview window. Upper left corner of window. (0-99)

posy

Type: **Integer**

Y coordinate of multiview window. Upper left corner of window. (0-99)

sx

Type: **Integer**

Size/Length of multiview window. As a percentage of X dimension.

sy

Type: **Integer**

Size/Height of multiview window. As a percentage of Y dimension.

ly

Type: **Integer**

Window Layer. Value from 1-9 with layer 1 being the bottom layer and 9 being the top.

ly

Type: **Integer**

Window Layer. Value from 1-9 with layer 1 being the bottom layer and 9 being the top.

Examples

```
set multiview myMview1 window-number 2 layer 4
Success
```

```
set multiview myMview1 window-number 2 size size-x 50 size-y 50
Success
```

```
set multiview mv1 window-number 2 position position-x 0 position-y 50
Success
```

Related Commands

```
create multiview
delete multiview
delete multiview-window
set multiview audio-source window-number
show multiviews config
show multiviews status
```

set multiview audio-source window number

Selects the input source to provide Audio for multiview display. (ZyPer4K only)

Syntax

```
set multiview id audio-source window number arg
```

Parameters

id

Type: **STRING**

Name of previously created multiview. String names are case-sensitive.

arg

Type: **STRING / Integer**

Supply one of the following arguments.

argument	Description
Integer	Integer from 1-9 identifying source to use for audio
none	Set no audio for the multiview window

Example

```
set multiview myMview1 audio-source window number 4  
Success
```

Related Commands

```
create multiview  
delete multiview  
delete multiview-window  
show multiviews config  
show multiviews status
```

set multiview canvas-size

Selects the canvas size for creating multiview windows. (ZyPer4K only)

Helpful feature to control bandwidth of scaled streams for a multiview. Default canvas size is 3840x2160. This can create case where datarate from encoder is greater than 9.5Gb limit.(Full size stream plus scaled stream.) Reducing the canvas size will reduce required size and datarate of scaled stream used for multiview.

Syntax

```
set multiview id canvas-size pixelsHoriz pixelVert
```

Parameters

id

Type: **STRING**

Name of previously created multiview. String names are case-sensitive.

pixelsHorz

Type: **Integer**

Horizontal width of the multiview canvas. (640 to 4096)

pixelsVert

Type: **Integer**

Vertical height of multiview window. (480 to 2160)

Example

```
set multiview MyView1 canvas-size 1920 1080
Success
```

Related Commands

```
create multiview
delete video-wallmultiview
delete multiview-window
set device rs232multiview
show multiviews config
show multiviews status
```

set multiview title

Used to create a text overlay in a multiview window. (ZyPer4K only)

Create a string of text to be overlaid somewhere in a multiview window. Color of text and color of background can be specified. Size of text can be specified. Transparency of text and background can be specified. Note that 100% transparent setting is not fully transparent.

Syntax

```
set multiview id window-number wn title text title  
set multiview id window-number wn title text-size ts  
set multiview id window-number wn title transparency text tt  
background bt  
set multiview id window-number wn title color text tc background bc
```

Parameters

id

Type: **STRING**

Name of previously created multiview. String names are case-sensitive.

wn

Type: **Integer**

Window number within the multiview (1-9)

ts

Type: **Integer**

Size of text (1-10)

tt

Type: **Integer**

Text Transparency. Percentage (0-100)

bt

Type: **Integer**

Background Transparency. Percentage (0-100)

*tc*Type: **STRING**

Text color. Can be any of the following options: black, blue, brown, cyan, darkBlue, gray, green, lightBlue, lightGray, lime, magenta, maroon, olive, orange, purple, red, silver, white, yellow.

*bc*Type: **STRING**

Background color. Can be any of the following options: black, blue, brown, cyan, darkBlue, gray, green, lightBlue, lightGray, lime, magenta, maroon, olive, orange, purple, red, silver, white, yellow.

*title*Type: **STRING**

Any text string to be associated and displayed in the selected multiview window. Strings contains spaces must be enclosed in quotations.

Examples

```
set multiview MyView1 window-number 1 title text "Window #1"  
Success
```

```
set multiview MyView1 window-number 1 title text-size 10  
Success
```

```
set multiview MyView1 window-number 1 title transparency text 0  
background 100  
Success
```

```
set multiview MyView1 window-number 1 title color black background-  
color green
```

Related Commands

```
create multiview  
delete video-wallmultiview  
delete multiview-window  
set device rs232multiview  
show multiviews config  
show multiviews status
```

set responses rs232-term-chars

Specifies the termination character for an RS232 string. The default string is “\n\r”. Any character in the termination string causes the response-string to terminate and be placed into the response-string ring buffer.

This string is optional. If it is not specified, then the string is empty and each low-level response is handled as a separate response.

Syntax

```
set responses id chr
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

chr

Type: **STRING**

The specified string.

Example

```
set responses decoder-2 rs-232-term-chars "\r"  
Success
```

Related Commands

```
set device rs232
```

set server auto-edid-mode

Sets the EDID mode for the Management Platform. By default, Auto-EDID mode is enabled.

Syntax

```
set server auto-edid-mode mode
```

Parameters

mode

Type: **STRING**

Supply one of the following arguments.

argument	Description
disabled	Disables auto-EDID mode.
enabled	Enables Auto EDID mode.

Example

```
set server auto-edid-mode disabled
Success
```

Related Commands

```
set server timezone
```


set server data-transfer-mode

Sets the transfer mode for the Management Platform.

Syntax

```
set server data-transfer-mode mode
```

Parameters

mode

Type: **STRING**

Supply one of the following arguments.

argument	Description
raw	Sets raw communication mode.
telnet	Sets telnet communication mode.

Example

```
set server data-transfer-mode telnet
Success
```

Related Commands

```
set server timezone
```

set server encoder-default-audio-format

Sets the default encoder audio format for HDMI audio input.

Detailed Background

ZeeVee added a feature that will allow compressed formats to be passed down in an encoder EDID file. This EDID will be then forwarded to the source device to determine the type of audio sent to the encoder.

This enhancement was to provide fast-switched connections the “compressed audio” options in the EDID file. Prior to this version with the fast-switched connection, ZeeVee modified the EDID passed from the decoder to the encoder and removed all compression formats. This left just LPCM as the only option under the “Audio data block” in the edid file.

>>> Audio data block <<<

Linear PCM, max channels 8

Supported sample rates (kHz): 192 176.4 96 88.2 48 44.1 32

Supported sample sizes (bits): 24 20 16

The information provided to the Video Source device (such as BluRay Player or Media player) increases the possibility of compression being a chosen audio format. However it is still up to the device to choose uncompressed or compressed formats. It is important to know that some devices such as the Apple 4K TV requires the audio output type to be set (even if the audio format is available in the EDID). Compression will need to be set manually on these types of devices.

In addition any downmixed stream internal to ZyPer devices will not process compressed audio, so you will not hear compressed audio on these connections.

Syntax

```
set server encoder-default-audio-format mode
```

Parameters

mode

Type: **STRING**

Supply one of the following arguments.

argument	Description
allow-compressed	Passes the decoders edid with unmodified audio information and thus allows compression options to be seen.
force-pcm	Forces the EDID modification described above

Example

```
set server encoder-default-audio-format allow-compressed
Success
```

Related Commands

```
set encoder audio-format
```

Additional Information

In an attempt to properly Identify the Audio Streams used under the product the following changes were also made along with some modification to the API commands.

Product	Old Audio Stream Name	Netw Stream Name
ZyPer4K	hdmi (used in genlocked mode)	hdmi-passthrough-audio
ZyPer4K	hdmi-audio-downmix	hdmi-audio
ZyPer4K	analog-audio	No Change
ZyPerUHD	audio	hdmi-audio
ZyPerUHD	analog-audio	No Change
ZyPerHD	Part of fast-switched connection	No Change
ZyPerHD	Part of fast-switched connection	No Change

set server ip

Sets the IP Address of the Management Platform. For MP hardware with multiple Network Interfaces this command is used to set the IP Address of each interface independently.

Syntax

```
set server ip id mode IP Address Mask Gateway reboot
```

Parameters

id

Type: **STRING**

Supply one of the following arguments.

argument	Description
server	Select the "Video" network. (ZyPer Network)
management	Select the "Management" network. (Non-ZyPer Network)

mode

Type: **STRING**

Supply one of the following arguments.

argument	Description
static	Manually select/assign IP Address
dhcp	Allow DHCP server to automatically assign IP Address

Example

```
set server ip server dhcp reboot
Success
```

```
set server ip server static 192.168.1.26 255.255.255.0 none reboot
Success
```

Related Commands

```
set server timezone
```

set server license

Sets the license for the Management Platform. This controls the maximum number of endpoints supported by the Management Platform

Syntax

```
set server license key
```

Parameters

key

Type: **STRING**

License key obtained from ZeeVee that sets maximum number of endpoints

Example

```
set server license QDZV-AYYA-0048-303D-5C0E-BD5D-56AA-154D-976C-  
BCE3-BAC4  
Success
```

Related Commands

```
set server auto-edid-mode
```

set server redundancy

Sets a virtual IP address and Mask for the Master and Slave Management Platforms in the system. (See Appendix for additional Redundancy Configuration Instructions)

Syntax

```
set server redundancy serv_id virtual-ip address IP_Address
network-interface video|management
```

Parameters

serv_id

Type: **STRING**

The servers to apply Virtual-ID to.

argument	Description
<i>all-servers</i>	All Management Platforms on the Network. (Master and Slave)
<i>this-server</i>	The specific server (Master or Slave) currently logged into.
<i>server IP Address</i>	Manually enter IP address of a specific Management Platform. (Master or Slave)

IP_Address and Mask

Type: **STRING**

Virtual IP address with Subnet Mask

argument	Description
<i>IP Address</i>	Virtual IP address to use for designated servers: Example: 192.168.0.25
<i>network-interface</i>	Selects either the Video or Management interface for MP units with Dual Network Interfaces

Note: The virtual address has to be accessible within the subnet already defined for the interface. So, if the “video network”, aka the original interface has 172.6.2.22/24, then the virtual address has to be 172.16.2.xxx.

Examples

```
set server redundancy all-servers virtual-ip address 192.168.0.25
network-interface v
Success
```

```
set server redundancy this-server preferred-master true preferred-
slave false
Success
```

```
set server redundancy 192.168.1.202 preferred-master false
preferred-slave true
Success
```

set server ssh password

Sets the password for ssh access.

The ssh account is: zyper

The default password is: zyper

If a password is not provided, then the current password will be deleted. In this case, no password prompt will be displayed.

Syntax

```
set server ssh password pass
```

Parameters

pass

Type: **STRING**

The desired password.

Examples

```
set server ssh password biGB055
```

Success

```
ssh zyper@<ip_address>
```

Notes

To reset system to no ssh password:

FTP the empty file named "defaultPasswords" to the /files directory of the MP (no file extension)

Power cycle the MP within **1 minute**, when it comes back the passwords will be defaulted.

This provides the very secure requirement of having physical access to the MP in order to reset the password.

Related Commands

```
set server auto-edid-mode
```

```
set server telnet password
```

```
set server telnet mode
```

```
set server timezone
```


set server telnet password

Sets the password for Telnet. If a password is not provided, then the current password will be deleted. In this case, no password prompt will be displayed.

By default Telnet has no password.

Syntax

```
set server telnet pass
```

Parameters

pass

Type: **STRING**

The desired password.

Example

```
set server telnet password biGB055  
Success
```

Notes

To reset system to no telnet password:

FTP the empty file named “defaultPasswords” to the /files directory of the MP (no file extension)

Power cycle the MP within **1 minute**, when it comes back the passwords will be defaulted.

This provides the very secure requirement of having physical access to the MP in order to reset the password.

Related Commands

```
set server auto-edid-mode  
set server ssh password  
set server telnet mode  
set server timezone
```

set server telnet mode

Used to enable or disable telnet access to the server.

Syntax

```
set server telnet mode mode
```

Parameters

mode

Type: **STRING**

Supply one of the following arguments.

argument	Description
enabled	Telnet access is enabled
disabled	Telnet access is disabled

Example

```
set server telnet mode disabled  
Success
```

Example trying to access via Telnet once disabled

```
telnet 192.168.0.78  
Trying 192.168.0.78...  
telnet: connect to address 192.168.0.78: Connection refused  
telnet: Unable to connect to remote host
```

Related Commands

```
set server auto-edid-mode  
set server ssh password  
set server telnet password  
set server timezone
```

set server timezone

Sets the time zone for the Management Platform. The time zone must be specified in POSIX format.

Syntax

```
set server timezone zone
```

Parameters

zone

Type: **STRING**

The time zone in POSIX format.

Example

```
set server timezone America/New_York  
Success
```

Related Commands

```
set server auto-edid-mode
```

set video-wall

Changes the size of the specified video wall and bezel parameters. Bezel values are measured in pixels.

Setting bezel values will affect a resolution change to the display. If the resolution is not supported by the display, then the display will have no picture. If this is the case, try assigning a different bezel pixel value.

Syntax

```
set video-wall id size rows rows columns cols top-bezel bezt
bottom-bezel bezb leftBezel bezl right-bezel bezr
```

Parameters

id

Type: **STRING**

The name of the video wall. String names are case-sensitive.

rows

Type: **INTEGER**

The number of rows. (Maximum 9 for ZyPer4K/ZyPerUHD, Maximum 4 for ZyPerHD)

cols

Type: **INTEGER**

The number of columns. (Max 9 for ZyPer4K/ZyPerUHD, Max 4 for ZyPerHD)

bezt

Type: **INTEGER**

The top bezel pixel value.

bezb

Type: **INTEGER**

The bottom bezel pixel value.

bezl

Type: **INTEGER**

The left bezel pixel value.

bezr

Type: **INTEGER**

The right bezel pixel value.

Note: Bezel adjustment only supported on ZyPer4K

Example

```
set video-wall Mywall1 size rows 5 columns 5 top-bezel 0 bottom-  
bezel 0 leftBezel 0 right-bezel 0  
Success
```

Related Commands

```
create video-wall  
set video-wall  
show video-walls  
join video-wall  
set video-wall new-name
```

set video-wall decoder

Assigns the specified decoder, to the desired row and column, on the specified video wall.

Syntax

```
set video-wall wallid decoder id row col
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the decoder. String names are case-sensitive. If *none* is passed as the argument, then any existing display is disconnected from that position in the video wall.

wallid

Type: **STRING**

The name of the video wall. String names are case-sensitive.

row

Type: **INTEGER**

The row of the specified video wall.

col

Type: **INTEGER**

The column of the specified video wall.

Example

```
set video-wall myVideoWall decoder myDecoder 2 3
Success
```

Related Commands

```
create video-wall
set video-wall
show video-walls
join video-wall
```

set video-wall new-name

Changes the name of an existing video wall

Syntax

```
set video-wall id new-name name
```

Parameters

id

Type: **STRING** or **MAC Address**

The name or MAC address of the encoder. String names are case-sensitive. If `none` is passed as the argument, then the display is disconnected from that position in the video wall.

name

Type: **STRING**

The updated name of the video wall.

Example

```
set video-wall myWall12 new-name yourWall12  
Success
```

Related Commands

```
create video-wall  
set video-wall  
show video-walls  
join video-wall
```

show data-relays

Shows what rs232 or IR data relay ports are opened on the server.

The feature of data-relays was added to allow a third party to connect to the ZMP server with a specific port and pass raw or telnet API commands (depending on the mode) to the server and port which is designated for a particular encoder or decoder.

Syntax

```
show data-relays
```

Parameters

none

Example

```
show data-relays
data-sessions(d8:80:39:5a:69:a9);
  device: name=Encoder1
  ir-tcp: port=8573
  ir-connections: none
data-sessions(d8:80:39:59:af:be);
  device: name=Decoder1
  rs232-tcp: port=5324
  rs232-connections: none
Success
```

Related Commands

[data-connect](#)

show device capabilities

Displays device capabilities for the specified device(s).

Syntax

```
show device capabilities id select [since]
```

Parameters

id

Type: **STRING or MAC Address**

The identifier of the device. Either the full or portion of a string name or MAC address can be supplied.

select

Type: **STRING**

Supply one of the following arguments.

argument	Description
all	Displays configuration information for all available devices.
encoders	Only encoders are displayed.
decoders	Only decoders are displayed.

since

This parameter is optional and can be specified to display units based on the number of changes, using the `lastChangeId` value on each device. However, if used, a `lastChangeId` value must follow. Supply the `since` argument before the providing the `lastChangeId` value.

argument	Description
since	Required when using this parameter.

Example

```
show device capabilities myEnc1 since 20
device(d8:80:39:9a:e6:d);
  device.CapabilitiesVersion; values=1
  device.streams-supported; values=video:video-scaled:analog-
audio:hdmix-downmix-audio
  device.stream-mode-settable; values=video:video-scaled:analog-
audio:hdmix-downmix-audio
  device.stream-mcast-settable; values=video:analog-audio:hdmix-
downmix-audio
  device.join-video; values=multiview:genlocked:fast-switched
  device.video-port; values=hdmix
  device.hdmix-status; values=link:hdmix:resolution:fps
  device.join-audio; values=analog:hdmix-downmix-audio
  device.hdmix-audio-source; values=analog:hdmix:hdmix-downmix
  device.analog-audio-source; values=none:analog:hdmix-downmix
  device.encoder-analog-audio-source; values=none:hdmix-downmix
  device.ir; values=device:server
  device.rs232; values=device:server
  device.video-wall; values=maxSize(5):bezelsSupported
  device.send-multicasts; values=settable
  device.ip-mode; values=dhcp:static
  device.ip-params; values=address:mask:gateway
  device.decoder-edid; values=save
  device.encoder-edid; values=save:load
  device.flash-leds; values=supported
  device.ethernet-management-port-mode; values=supported
  device.video-input-port; values=hdmix:display-port:auto
lastChangeIdMax(5072370);
Success
```

Related Commands

```
show device status
show device config
```

show device config

Displays device information for the specified device(s).

Syntax

```
show device config id select [since]
```

Parameters

id

Type: **STRING or MAC Address**

The identifier of the device. Either the full or portion of a string name or MAC address can be supplied.

argument	Description
all	Displays configuration information for all available devices.
encoders	Only encoders are displayed.
decoders	Only decoders are displayed.

since

This parameter is optional and can be specified to display units based on the number of changes, using the `lastChangeId` value on each device. However, if used, a `lastChangeId` value must follow. Supply the `since` argument before the providing the `lastChangeId` value.

argument	Description
since	Required when using this parameter.

Example

```
Zyper$ show device config Thailand since 20
device(d8:80:39:eb:1:cb);
  device.gen; model=Zyper4K, type=encoder, name=Thailand, state=Up,
lastChangeId=110366
  device.gen; firmware=4.0.1.0
  device.hdmi; hdcpMode=disabled
  device.ports; videoPort=hdmi
  device.ip; mode=dhcp, address=172.16.6.106, mask=255.255.255.0,
gateway=172.16.6.1
  device.rs232; sendingToMacOrIp=none(0.0.0.0), terminationChars=\
x0A\x0D, baudrate=57600, dataBit=8, stop_Bit=1, parity=none
  device.ir; sendingToMacOrIp=none(0.0.0.0)
  device.source; iconName=xbox, manufacturer=, model=,
location=, serialNumber=
  device.audioOutSourceType; analogOutSourceType=none
  device.hdmiAudioIn; format=server-default
  device.sendIpMcastRange; first=224.1.1.1, last=239.255.255.255
  device.videoStream; ipMcastAddr=224.1.1.1, mode=enabled
  device.videoScaledStream; ipMcastAddr=224.1.1.15, mode=disabled
  device.analogAudioIpMcast; ipAddr=224.1.1.4, mode=disabled
  device.hdmiAudioIpMcast; ipAddr=224.1.1.13, mode=enabled
  device.preview-stream; mode=enabled, type=hls, width=auto
lastChangeIdMax(110367);
Success
```

Related Commands

```
show device status
show device capabilities
show device connections
```

show device connections

Shows encoder connections to decoders

Syntax

```
show device connections
```

Parameters

none

Example

```
show device connections
encoder.GalapagosHD; BotLeftHD
encoder.RaptorsHD; SamsungHD
encoder.MuralsHD; BotRightHD
encoder.Soccer4K; TopRight, BotLeft
Success
```

Related Commands

```
show device status
show device capabilities
show device config
```

show device status

Displays status information for the specified device(s). This command functions the same as the `show device config` command.

Syntax

```
show device status id [since]
```

Parameters

id

Type: **STRING or MAC Address**

The identifier of the device. Either the full or portion of a string name or MAC address can be supplied.

Supply one of the following arguments.

argument	Description
all	Displays configuration information for all available devices.
encoders	Only encoders are displayed.
decoders	Only decoders are displayed.

since

This parameter is optional and can be specified to display units based on the number of changes. Supply this argument followed by the desired value to query.

argument	Description
since	Required when using this parameter.

Example

```
Zyper$ show device status Thailand since 20
device(d8:80:39:eb:1:cb);
  device.gen; model=Zyper4K, type=encoder, name=Thailand, state=Up,
uptime=0d:0h:38m:7s, lastChangeId=74
  device.temperature; main=0C
  device.firmwareUpdate; status=idle, loadingFile=none,
percentComplete=0
  device.hDMIInput; cableConnected=connected, hDCP=inactive,
hdcpVersion=NONE, hdmi2.0=yes, horizontalSize=3840,
verticalSize=2160, fps=29.999, interlaced=no
  device.hDMIInput; hTot=4400, hBlank=560, hFront=176, hSync=88,
hSyncPol=positive
  device.hDMIInput; vTot=2250, vBlank=90, vFront=7, vSync=10,
vSyncPol=positive
  device.hDMIInput; pixelClock=296.995, colorEncoding=RGB,
colorDepth=8, colorSpace=BT-709, colorQuantRange=default,
timingStandard=CEA-861-F VIC-95
  device.autoEdid; mode=disabled
  device.edid; sourceType=unknown
  device.edid; edidStatus=valid, edidMonitorName=Default
  device.edid; firstDescriptorPreferredResolution=yes
  device.edid; maxFps=85.00, maxPixelClockMhz=600.00,
maxDeepColorPixelClockMhz=600.00, rgbColorDepth=12,
yuv420ColorDepth=12
  device.edid; only420=none, also420=3840-50+3840-60,
yuvQuantRange=default, rgbQuantRange=default
  device.edid.audio.PCM; channels=6, sampleRates=48hz-44.1hz-32hz,
sampleBits=16-20
  device.edid.preferredResolution; pixelClockMhz=297.00,
sizeX=4096, sizeY=2160, fps=30.00
  device.edid.maxResolution; pixelClockMhz=297.00, sizeX=4096,
sizeY=2160, fps=30.00
  device.videoStream; inputFps=30.00, inputDataRate=6531Mbps,
compressionFactor= 1.00, streamFps=30.00, streamDataRate=0Mbps
  device.videoScaledStream; inputFps=30.00, inputDataRate=6531Mbps,
streamFps=30.00, streamDataRate=0Mbps
lastChangeIdMax(86);
Success
```

Related Commands

`show device config`

show device user-added

Shows add devices that have been manually added to the Management Platform using the add device command.

Syntax

```
show device user-added
```

Parameters

none

Example

```
show device user-added
device(d8:80:39:eb:1c:ee);
device.gen; model=Zyper4K, type=encoder, name=London, state=Up,
uptime=0d:18h:32m:36s, lastChangeId=55
device.ip; address=192.168.10.79
device(d8:80:39:59:f1:ff);
device.gen; model=Zyper4K, type=decoder, name=Right, state=Up,
uptime=0d:18h:32m:36s, lastChangeId=52
device.ip; address=192.168.10.81
device(d8:80:39:59:af:be);
device.gen; model=Zyper4K, type=decoder, name=Left, state=Up,
uptime=0d:18h:30m:5s, lastChangeId=56
device.ip; address=192.168.10.82
Success
```

Related Commands

```
add device
show device status
show device capabilities
show device config
```


show multiviews config

Shows configuration information on all multiview displays. (ZyPer4K only)

Syntax

```
show multiviews config
```

Parameters

none

Example

```
show multiviews config
multiview(Ltest1);
  multiview.audio; sourceWindow=none;
  multiview.window1; encoder-name=Airshow4K, percentPosX=40,
percentPosY=5, percentSizeX=55, percentSizeY=55, layer=1;
  multiview.window2; encoder-name=Soccer4K, percentPosX=5,
percentPosY=5, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window3; encoder-name=Wildlife4K, percentPosX=5,
percentPosY=65, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window4; encoder-name=Soccer4K, percentPosX=65,
percentPosY=65, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window5; encoder-name=USA4K, percentPosX=5,
percentPosY=35, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window6; encoder-name=USA4K, percentPosX=35,
percentPosY=65, percentSizeX=30, percentSizeY=30, layer=1;
multiview(MView4k);
  multiview.audio; sourceWindow=1;
  multiview.window1; encoder-name=Airshow4K, percentPosX=0,
percentPosY=0, percentSizeX=50, percentSizeY=50, layer=1;
  multiview.window2; encoder-name=USA4K, percentPosX=0,
percentPosY=50, percentSizeX=50, percentSizeY=50, layer=1;
  multiview.window3; encoder-name=Soccer4K, percentPosX=50,
percentPosY=0, percentSizeX=50, percentSizeY=50, layer=1;
  multiview.window4; encoder-name=Wildlife4K, percentPosX=50,
percentPosY=50, percentSizeX=50, percentSizeY=50, layer=1;
multiview(LBar);
  multiview.audio; sourceWindow=none;
  multiview.window1; encoder-name=Soccer4K, percentPosX=5,
percentPosY=5, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window2; encoder-name=Wildlife4K, percentPosX=5,
percentPosY=65, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window3; encoder-name=USA4K, percentPosX=35,
```

```
percentPosY=65, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window4; encoder-name=Soccer4K, percentPosX=65,
percentPosY=65, percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window5; encoder-name=USA4K, percentPosX=5, percentPosY=35,
percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window6; encoder-name=Airshow4K, percentPosX=35,
percentPosY=5, percentSizeX=60, percentSizeY=60, layer=1;
Success
```

Related Commands

```
create multiview
delete video-wallmultiview
delete multiview-window
set device rs232multiview
show multiviews status
```

show multiviews status

Shows status information for all multiview displays. (ZyPer4K only)

Syntax

```
show multiviews status
```

Parameters

none

Example

```
Zyper$ show multiviews config
multiview(L-Shape);
  multiview.gen; audioSourceWindow=none, canvas-width=3840, canvas-
height=2160
  multiview.window1; encoder-name=Camera4, encoder-
mac=d8:80:39:9a:e6:d, percentPosX=5, percentPosY=5,
percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window2; encoder-name=Cam1, encoder-
mac=d8:80:39:9a:af:a3, percentPosX=35, percentPosY=5,
percentSizeX=60, percentSizeY=60, layer=1;
  multiview.window3; encoder-name=Camera4, encoder-
mac=d8:80:39:9a:e6:d, percentPosX=5, percentPosY=35,
percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window4; encoder-name=Thailand, encoder-
mac=d8:80:39:eb:1:cb, percentPosX=5, percentPosY=65,
percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window5; encoder-name=Cam1, encoder-
mac=d8:80:39:9a:af:a3, percentPosX=35, percentPosY=65,
percentSizeX=30, percentSizeY=30, layer=1;
  multiview.window6; encoder-name=Cam1, encoder-
mac=d8:80:39:9a:af:a3, percentPosX=65, percentPosY=65,
percentSizeX=30, percentSizeY=30, layer=1;
multiview(mv2x2);
  multiview.gen; audioSourceWindow=none, canvas-width=3840, canvas-
height=2160
  multiview.window1; encoder-name=Cam1, encoder-
mac=d8:80:39:9a:af:a3, percentPosX=0, percentPosY=0,
percentSizeX=50, percentSizeY=50, layer=1;
```

```
multiview.window2; encoder-name=Camera4, encoder-  
mac=d8:80:39:9a:e6:d, percentPosX=50, percentPosY=0,  
percentSizeX=50, percentSizeY=50, layer=1;  
multiview.window3; encoder-name=Cuba, encoder-  
mac=d8:80:39:9a:96:7, percentPosX=0, percentPosY=50,  
percentSizeX=50, percentSizeY=50, layer=1;  
multiview.window4; encoder-name=Thailand, encoder-  
mac=d8:80:39:eb:1:cb, percentPosX=50, percentPosY=50,  
percentSizeX=50, percentSizeY=50, layer=1;  
multiview.window5; encoder-name=Cuba, encoder-  
mac=d8:80:39:9a:96:7, percentPosX=25, percentPosY=25,  
percentSizeX=50, percentSizeY=50, layer=2;  
Success
```

Related Commands

```
create multiview  
delete video-wallmultiview  
delete multiview-window  
set device rs232multiview  
show multiviews config
```

show multiviews titles

Shows title information for all multiview displays. (ZyPer4K only)

Syntax

```
show multiviews titles arg
```

Parameters

arg

Type: **STRING**

Supply one of the following arguments.

argument	Description
config	Displays title configuration information for multiview.
text	Displays text configuration information for multiview.

Examples

```
Zyper$ show multiviews titles text
multiview(mv1);
  multiview.gen; audioSourceWindow=none, canvas-width=3840, canvas-
height=2160
  multiview.window1; title=Window1
  multiview.window2; title=Window2
  multiview.window3; title=none
  multiview.window4; title=none
Success
```

```
Zyper$ show multiviews titles config
multiview(mv1);
  multiview.gen; audioSourceWindow=none, canvas-width=3840, canvas-
height=2160
  multiview.window1; position=bottom-center, textSize=8,
textColor=lightGray, backgroundColor=black, textTransparency=0,
backgroundTransparency=80
  multiview.window2; position=top-left, textSize=8,
textColor=lightGray, backgroundColor=black, textTransparency=0,
backgroundTransparency=80
  multiview.window3; position=top-left, textSize=8,
textColor=lightGray, backgroundColor=black, textTransparency=0,
backgroundTransparency=80
  multiview.window4; position=bottom-center, textSize=8,
textColor=lightGray, backgroundColor=black, textTransparency=0,
backgroundTransparency=80
Success
```

show responses

Displays response strings from the specified device.

Syntax

```
show responses id type param3
```

Parameters

id

Type: **STRING or MAC Address**

The name or MAC address of the device. String names are case-sensitive.

type

Type: **STRING**

Supply one of the following arguments.

argument	Description
<code>ir</code>	Displays IR response strings.
<code>rs232</code>	Displays RS232 response strings.

param3

Supply one of the following arguments.

argument	Description
<code>last</code>	Displays the last received response, based on the argument supplied for the <i>type</i> parameter.
<code>last-change-id</code>	Displays the <code>lastChangeId</code> of the most recently received response.
<code>since</code>	Displays only new response data. Follow this argument with desired value to query.

Example

```
show responses 0:1e:c0:f6:b0:8a rs232 since 10
lastChangeId(0);
Success
```

```
show responses 0:1e:c0:f6:b0:8a ir last-change-id
lastChangeId(0);
Success
```

```
show responses 0:1e:c0:f6:b0:8a ir last
lastChangeId(0);
Success
```

```
show responses UHDdec1 rs232 last
device(34:1b:22:80:64:68);
  device.rs232Response.19; string="Yes ZeeVee Support is the
Greatest\x0D"
lastChangeId(20);
Success
```

```
Zyper$ show responses UHDdec1 rs232 since 19
device(34:1b:22:80:64:68);
  device.rs232Response.19; string="Yes ZeeVee Support is the
Greatest\x0D"
  device.rs232Response.20; string="Really, still the greatest!\x0D"
lastChangeId(21);
Success
```

show server config

Displays configuration information for the Management Platform.

Syntax

```
show server config
```

Parameters

none

Example

```
Zyper$ show server config
server(192.168.0.78);
  server.gen; autoEdidMode=enabled, redundancy=enabled
  server.ip-server-address; mode=static, address=192.168.0.78,
mask=255.255.255.0, gateway=none
  server.ip-management-address; mode=none, address=NA
  server.telnetAccess; mode=enabled
  server.encoder-defaults; hdmi-audio-format=force-pcm
  server.data-transfer; telnet=telnet-handshake-mode
  server.logging; level=1
Success
```

Related Commands

```
show server info
```


show server info

Displays information for the Management Platform, including IP settings, uptime, and license level.

Syntax

```
show server info
```

Parameters

none

Example

```
Zyper$ show server info
server(192.168.0.78);
  server.gen; hostname=zyper.local, version=2.1.35811,
previousVersion=1.8.34521, macAddress=1c:1b:0d:82:ff:1a,
serialNumber=ZZM1H500032B
  server.gen; uptime=0d:2h:7m:50s, freeMem=6.541GB, bootCount=23
  server.gen; runningInVm=false
server.time; time=Fri Dec 6 10:23:09 2019, timezone=America/
New_York
  server.license; productID=031B021C-040D-0582-FF06-1A0700080009,
license=JSGH-RLUH-0000-116F-9328-F426-4BB5-89E2-024D-8CBE-FF1C
  server.license; limit=unlimited, knownDevices=21, devicesUp=10,
devicesExceeded=0
  server.deviceUpdates; active=0
  server.activeDeviceVersions; num_0.10.2=1, num_3.5.2=1,
num_4.0.0=4, num_4.0.1=4
Success
```

Related Commands

```
show server config
revert server
```

show server redundancy

Displays information about master and slave Management Platforms

Syntax

```
show server redundancy
```

Parameters

none

Example

```
show server redundancy
server(192.168.1.201);
  server.status; state=slave, version=1.7.1.33348, wasMaster=true,
wasSlave=true
  server.config; preferredMaster=true, preferredSlave=false
  server.virtualIp; address=192.168.1.206, mask=255.255.255.0
  server.slaveStatus; dbRunning=Yes, dbRunningState=Slave has read
all relay log; waiting for the slave I/O thread to update it, G
TID=0-1546798323-2301091, dbError=none
server(192.168.1.202);
  server.status; state=master, version=1.7.1.33348, wasMaster=true,
wasSlave=true
  server.config; preferredMaster=true, preferredSlave=false
  server.virtualIp; address=192.168.1.206, mask=255.255.255.0
Success
```

Related Commands

```
set server redundancy
redundancy switchover
```

show video-walls

Displays all video walls that have been created and all associated information.

Syntax

```
show video-walls
```

Parameters

none

Example

```
show video-walls
videoWall(myWall);
  videoWall.gen; videoSourceMac=0:1e:c0:f6:a8:c3, numDisplayRows=4,
numDisplayCols=4
  videoWall.bezel; top=0, bottom=0, left=0, right=0
  videoWall.decodersRow1; col1=none, col2=none, col3=none,
col4=none;
  videoWall.decodersRow2; col1=none, col2=none, col3=none,
col4=none;
  videoWall.decodersRow3; col1=none, col2=none, col3=none,
col4=none;
  videoWall.decodersRow4; col1=none, col2=none, col3=none,
col4=none;
Success
```

Related Commands

```
create video-wall
set video-wall
set video-wall-decoder
set video-wall-encoder
```

show zones

Displays all zones that have been created and all associated information.

Syntax

```
show zones
```

Parameters

none

Example

```
show zones
  testzone; Dec1, Dec2, Dec3, Dec4
  Zone1; Dec1, Dec3
  Zone2; Dec2, Dec4
Success
```

Related Commands

```
add zone-display
create zone
delete zone
delete zone-display
```

shutdown server

Performs a shutdown of the Management Platform.

Syntax

```
shutdown server
```

Parameters

none

Example

```
shutdown server  
Success  
Connection closed by foreign host.
```

Related Commands

```
restart server
```

sleep

Specifies a sleep duration in milliseconds. This command is sometime required when executing a series of commands within a web page, using AJAX. Often times, a pause must occur in order for a device or the Management Platform to change states before another command is executed.

Syntax

```
sleep ms
```

Parameters

ms

Type: **INTEGER**

The duration in milliseconds.

Example

```
sleep 500  
Success
```

Related Commands

[script](#)

start encoder

Used to start a specific encoder multicast stream. This command only has affect if at least one decoder has been “joined” to the encoder and the “encoder stop” command has been used to override the enabling of the encoder stream. In effect, this command removes a previously entered “encoder stop” command – it returns stream control to normal operation based on existing “join” configuration. The command will immediately restore stream operation based on existing join configuration. No further join commands are required. (ZyPer4K only)

Syntax

```
start encoder id stream arg
```

Parameters

id

Type: **STRING or MAC Address**

The identifier of the device. Either the full or portion of a string name or MAC address can be supplied.

arg

Supply one of the following arguments.

argument	Description
analog-audio	analog audio multicast stream.
hdmi-audio	downmix audio multicast stream
video	full scale video stream
video-scaled	downscaled video stream (for multiview)

Example

```
start encoder Myencoder1 stream video
Success
```

Related Commands

[stop encoder](#)

stop encoder

Used to stop a specific encoder multicast stream. This command only has affect if at least one decoder has been “joined” to the encoder. In effect, this command overrides any existing “join” command – either present or future. (ZyPer4K only)

When stopping a “scaled-video” stream, any multiview window receiving that stream will go black. The rest of the multiview will be unaffected.

Syntax

```
stop encoder id stream arg
```

Parameters

id

Type: **STRING or MAC Address**

The identifier of the device. Either the full or portion of a string name or MAC address can be supplied.

arg

Supply one of the following arguments.

argument	Description
analog-audio	analog audio multicast stream.
hdmi-audio	downmix audio multicast stream
video	full scale video stream
video-scaled	downscaled video stream (for multiview)

Example

```
stop encoder Myencoder1 stream video-scaled
Success
```

Related Commands

```
start encoder
```


switch

This command is used in conjunction with the IR and RS232 switching commands. Both the `rs232` and the `ir` argument specify unidirectional connection between two devices. When switching data to the server, use the `show responses` command to retrieve the data.

Syntax

```
switch txid rxid type
```

Parameters

txid

Type: **STRING or MAC Address**

The name or MAC address of the encoder. String names are case-sensitive.

rxid

Type: **STRING or MAC Address**

The name or MAC address of the decoder. String names are case-sensitive.

type

Type: **STRING**

Supply one of the following arguments.

argument	Description
<code>ir</code>	Specifies a IR connection. (ZyPer4K and ZyPerUHD only)
<code>rs232</code>	Connection to another device or the server. Set <code>rxid = none</code> to pass data to an arbitrary IP host.

Example

```
switch DVD-Wildlife SonyXBR4 rs232
Success
```

Related Commands

`send`

trouble-report

Generates capture logs and system state information and is used by the ZeeVee support team for troubleshooting purposes. This file is in `.tgz` format and is written to the `/srv/ftp/files` folder on the Management Platform.

Syntax

```
trouble-report
```

Parameters

none

Example

```
trouble-report  
Success
```

update device

Updates the firmware on the encoder and/or decoder units. The firmware update file file uses the `.apz` or `.zip` extension.

Syntax

```
update device arg file
```

Parameters

arg

Supply one of the following arguments.

argument	Description
id	Encoder or Decoder name. Names are case-sensitive
all	All encoders and decoders in the system
encoders	All encoders in the system
decoders	All decoders in the system

file

Type: **STRING**

The full filename of the software file.

Example

```
update device all Z4K_Firmware_HDMI2.0_v3_5_2_0.apz
Warning:(18) Firmware updating started, use 'show device status' to
monitor progress
Success
```

update server

Updates the Management Platform software. The server software file uses the `.zyper` extension. Refer to [Updating the Software \(page 210\)](#) for more information on using this command.

Syntax

```
update server file
```

Parameters

file

Type: **STRING**

The full filename of the software file.

Example

```
update server new-software-file.zyper  
Success
```

```
Server rebooting; connection will end
```

Important Note:

The ZyPer MP update file will be available in three, platform-specific versions. Please use the correct version for the hardware platform being updated.

ZyPerMP NUC computer: `update_nuc_2.0.xxxxx.zyper`
ZyPerMP Proserver: `update_proserver_2.0.xxxxx.zyper`
ZyPerMP VMware: `update_vm_2.0.xxxxx.zyper`

4 Event Mechanism

events

ZMP Event Mechanism

There are three ways to receive events:

- Second telnet session to receive events asynchronously. Session not used for API commands, only to receive events.
- Browser WebSocket to ZMP server. Allows server to asynchronously send events to the browser.
- Reliable, low-overhead API command to poll for events.

Event Message Format

```
Event::::<source>::::<lastChangeId>::: <Message>
```

Where:

```
source           device-name or "server"
```

Example:

```
Event::DeviceStateChange::DE1(d8:80:39:9a:af:e1)::Jun-18-02:42:56:PM::13:::
state=Up
```

Telnet Event Session

- Client telnets to the ZMP server as normal
- API prompt received
- Command entered: "events"
 - Causes the event mode to be entered
 - Server sends initial events (described below) and new events as they occur to this telnet session
 - Any character entered to the server causes the mode to exit back to the API prompt

Browser WebSocket

Client usage of a WebSocket to receive events is quite simple. Example JavaScript from the sample zyper.html file shows how to connect to the websocket server on ZMP. Upon connection, initial events (described below) will be sent, and then any new events as they occur.

```
eventSock = new WebSocket("ws://rey:8001", "zeeVeeLogging")
eventSock.onopen = eventSockOpened;
eventSock.onMessage = eventRcvd;
eventSock.onclose = eventSockClosed;

function eventSockOpened() {
    eventSock.send("Send Events"); // ignored by server
}
function eventRcvd(event) {
    var evWin = document.getElementById('eventWindow');
    evWin.innerHTML += event.data + "<br>";
    evWin.scrollTop = evWin.scrollHeight;
}
function eventSockClosed() {
    console.log("EVENT SOCK CLOSED");
}
}
```

API Polling

The “show events since <id>” command may be used over telnet or from a browser using AJAX/JSON and preferably long-polling. It is a simple, low overhead and very reliable mechanism to ensure all events have been received.

```
Zyper$ show events since 0
server(172.16.2.169);
  server.event.0; event="Mon Jun 18 18:44:06 2018: ip=172.16.2.64, state=down->master"
  server.event.1; event="Mon Jun 18 18:44:10 2018: state=up"
  server.event.2; event="Mon Jun 18 18:44:10 2018: state=up"
  ...
  server.event.28; event="Tue Jun 19 05:00:03 2018: sizeX=1280->720, sizeY=720->480, fps=60.00->60.00"
  server.event.29; event="Tue Jun 19 05:01:24 2018: cable=disconnected"
  server.event.30; event="Tue Jun 19 05:01:26 2018: cable=connected"
  server.event.31; event="Tue Jun 19 05:01:26 2018: sizeX=720->1280, sizeY=480->720, fps=60.00->60.00"
lastChangeld(32);
Success
Zyper$
Zyper$ show events since 28
server(172.16.2.169);
  server.event.28; event="Tue Jun 19 05:00:03 2018: sizeX=1280->720, sizeY=720->480, fps=60.00->60.00"
  server.event.29; event="Tue Jun 19 05:01:24 2018: cable=disconnected"
  server.event.30; event="Tue Jun 19 05:01:26 2018: cable=connected"
  server.event.31; event="Tue Jun 19 05:01:26 2018: sizeX=720->1280, sizeY=480->720, fps=60.00->60.00"
lastChangeld(32);
Success
Zyper$
Zyper$ show events since 32
lastChangeld(32);
Success
Zyper$
```

Initial Events

Upon entering telnet “events” mode, or upon a WebSocket connection, the server will send a DeviceStatus event for each known device. Each of these events will have lastChangeld set to 0.

Event List

ServerIpChanged:

Message: ipAddress=<from>-><to>

Example:

```
Event::ServerIpChanged::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::  
ipAddress=169.254.1.10->172.16.2.22
```

ServerStateChange:

Message: state=<from>-><to>

serverState:

- down
- initialization
- master
- slave-sync
- slave
- slave-switching-over
- slave-db-updating
- not-participating
- slave-waiting-for-master
- slave-version-mismatch

Example:

```
Event::stateChange::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::  
state=slave->master
```

NewServer:

Message: id=<id>, ip=<ipAddr>, state=<serverState>

Example:

```
Event::NewServer::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15:: id=  
693EF360-B908-11DC-9EA5-10BF483EF417, ip=172.16.2.22, state=initialization
```

OtherServerStateChange:

Message: ip=<ipAddr>, state=<from>-><to>

Example:

```
Event::OtherServerStateChange::EE5(d8:80:39:9b:c:e5)::Jun-18-  
02:42:56:PM::15:: ipAddress=169.254.1.10->172.16.2.22, state=slave->master
```


DeviceStatus: initial device state**Message:** state=down**Message:** state=up, uptime=<seconds>, cable=disconnected**Message:** state=up, uptime=<seconds>, cable=connected, sizeX=<pixels>, sizeY=<pixels>, fps=<fps>**Message (DECODER):** state=up, uptime=<seconds>, cable=connected, sizeX=<pixels>, sizeY=<pixels>, fps=<fps>, receivingVideoFromEncoder=no|yes|yes-with-warning [, reason=<reason> | warning=<warning>]**“no” reason list:**

decoder not joined
 decoder down
 decoder hdmi down
 encoder down
 encoder stream disabled
 encoder hdmi down
 display does not support resolution
 encoder and decoder hdcp do not match
 encoder has unsupported color format
 encoder data rate exceeded
 decoder data rate exceeded
 multiview error -- do 'show multiviews status'
 decoder resolution < UHD; can't join multiview
 encoder resolution < UHD; can't join video-wall
 encoder has multiview conflict with genlock
 problem with network connection

“yes-with-warning” warning list:

multiview partially active -- do 'show multiviews status'

Examples:

```
Event::DeviceState::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
state=down
```

```
Event::DeviceState::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
state=up, uptime=1234, cable=connected, sizeX=3840, sizeY=2160, fps=60,
receivingVideoFromEncoder=no, reason=encoder hdmi down
```

DeviceStateChange: device up/down**Message:** state=up|down**Example:**

```
Event::DeviceStateChange::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
state=up
```

CableConnection**Message:** cable=connected|disconnected**Example:**

```
Event::CableConnection::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
cable=connected
```

VideoStatusChange: sending video or not and why

Message: receivingVideoFromEncoder=no|yes|yes-with-warning
[, reason=<reason> | warning=<warning>]

Example:

Event::VideoStatusChange::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
receivingVideoFromEncoder=no, reason=encoder hdmi down

ResolutionChange: just resolution change

Message: sizeX=from->to, sizeY=from->to, fps=from->to

Example:

Event::ResolutionChange::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
sizeX=1920->3840, sizeY=1080->2160, fps=59.95->59.94

VideoChanged: encoder only, non-resolution change

Message: interlaced=<from>-><to>, color=<from>-><to>,
colorDepth=<from>-><to>, hdcp=<from>-><to>, hdcpVersion=<from>-
><to>, hdmi20=<from>-><to>

Where:

Interlaced: yes, no
Color values: RGB, YUV444, YUV422, YUV420
colorDepth: 8, 10, 12
hdcp: yes, no
hdcpVersion: none, 1.4, 2.2
hdmi20: yes, no

Example:

Event::VideoChanged::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
interlaced=yes->no, color=RGB->YUV444, colorDepth=8->10, hdcp=yes->no,
hdcpVersion=1.4->2.2, hdmi20=no->yes

RS232Data

Message: data=<rs232Data>

Example:

Event::RS232Data::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
data="hello there"

Note: RS232 events are only sent after a termination character has been received. If there are no termination characters defined, an event is generated after 10ms of no additional input.

IRData

Message: data=<irData>

Example:

```
Event::IrData::DCD(d8:80:39:9a:d0:cd)::Jun-19-05:02:07:PM::133::
data="\0000006d0000002700ae00a70016000f001500100015000f00150
0100015000f001500340016000f0015000f0015000f00150010001400100
01400100015000f001400100080016003500160034001600340016000f0
01500100015000f001500100015000f001500100014001000140010001
5000f00150034001600330016003400160034001600330016003300160-
034001600330016017c"
```

AutoEdidSelect

Message: sourceDecoder=<dec>, edidValid=yes|no, pixClockMhz=<from>-><to>, color=<from>-><to>, colorDepth=<from>-><to>, onlyPcmAudio=<from>-><to>

Example:

```
Event::AutoEdidSelect::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
sourceDecoder=D14, edidValid=yes, pixClockMhz=150->600, color=RGB-
>YUV420, colorDepth=8->10, onlyPcmAudio=no->no
```

MulticastConflict

Message: conflict=<multicastAddr>, action=getting new address

Example:

```
Event::MulticastConflict::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
conflict=224.1.1.1, action=getting new address
```

AllocMcastFailed

Message: allocation=failed

Example:

```
Event::AllocMcastFailed::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15::
allocation=failed
```

EdidFirstChecksumInvalid

Message: `firstChecksum=invalid`

Example:

Event::EdidFirstChecksumInvalid::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15:: firstChecmsum=invalid

EdidSecondChecksumInvalid

Message: `secondChecksum=invalid`

Example:

Event::EdidSecondChecksumInvalid::EE5(d8:80:39:9b:c:e5)::Jun-18-02:42:56:PM::15:: secondChecmsum=invalid

5 SNMP and LLDP

ZyPer Management Platform SNMP and LLDP support

The ZyPer Management Platform provides SNMPv2c and SNMPv3 access to status and configuration for the server and all devices. Specifically, it provides access to:

- Server information and configuration
- General device status and configuration (common to encoders and decoders)
- Decoder-specific status and configuration
- Encoder-specific status and configuration

The SNMP MIB, ZEEVEE-MIB.txt, may be obtained from www.zeevee.com. The MIB (Management Information Base) provides variable definitions for the above data. Note that ZEEVEE-MIB.txt imports several other standard MIBs, which are also available from the ZeeVee website for convenience.

The ZMP SNMP implementation also supports the following standard MIBs for generic host management:

- SNMPv2-MIB
- IF-MIB
- IP-MIB
- TCP-MIB
- UDP-MIB

And finally, a very common companion to SNMP is LLDP – Link Layer Discover Protocol. ZMP runs an LLDP daemon that collects link neighbor information. That information may be retrieved using SNMP to create a network topology map. ZMP supports the standard MIB, LLDP-MIB.txt, to enable this.

SNMP Agent SNMPv3 Account Configuration

ZMP SNMPv3 implements a simplified User-based Security Model (USM). Client accounts use MD5 authentication without encryption and are only read-only.

Further, ZMP effectively does not implement the View-based Access Control Model (VACM), in that each account has access to the entire mib.

From the ZMP CLI, the following commands manage SNMPv3 accounts:

```
add snmp user v3 access-level read-only encrypted no
user-name <newSnmpUser> password <string>
delete snmp user v3 username <string>
show snmp users
```

For example, to add user testAccount, with a password, myPassword, the following would be entered:

```
Zyper$ add snmp user v3 access-level read-only auth
MD5 encrypted no user-name testAccount password
myPassword
```

```
Zyper$ show snmp users
snmp(172.16.2.169);
  snmp.user: version=v3, auth=MD5, encryption=none,
  username=testAccount
```

SNMP Agent SNMPv2c Account Configuration

SNMPv2c accounts are based only on a username, although SNMP calls it a “community”. There is no secure authentication of the user and no encryption.

As with V3, ZMP effectively does not implement VACM – that is, each user/community has access to the entire mib.

From the ZMP CLI, the following commands manage SNMPv2c accounts:

```
add snmp user v2c access-level read-only community
<string>
delete snmp user v2c community <snmpUser>
show snmp users
```

For example:

```
Zyper$ add snmp user v2c access-level read-only
community public

Zyper$ show snmp users
snmp(172.16.2.169);
  snmp.user: version=v3, auth=MD5, encryption=none,
  username=testAccount
  snmp.user: version=v2c, community=public
```

SNMP Client

Choose an SNMP client. There are many. The following examples use the client applications provided in the Linux Net-SNMP package.

Examples using Linux Net-SNMP and the above V3 account to retrieve the “zvzServerInfo” group of variables defined in the ZEEVEE-MIB.txt file:

```
bin $ snmpwalk -u testAccount -l authNoPriv -A
myPassword 172.16.2.169 zvzServerInfo
ZEEVEE-MIB::zvzServerInfoHostname.0 = STRING: rey
ZEEVEE-MIB::zvzServerInfoVersion.0 = STRING: 2.1.35413:3
5414
ZEEVEE-MIB::zvzServerInfoPreviousVersion.0 = STRING: N/A
ZEEVEE-MIB::zvzServerInfoSerialNumber.0 = STRING:
ZMPFB0002b3913cf8A
ZEEVEE-MIB::zvzServerInfoUptime.0 = Timeticks: (0) 0:00:
00.00
ZEEVEE-MIB::zvzServerInfoLicenseLimit.0 = INTEGER: 0
ZEEVEE-MIB::zvzServerInfoKnownDevices.0 = INTEGER: 12
ZEEVEE-MIB::zvzServerInfoDevicesUp.0 = INTEGER: 7
ZEEVEE-MIB::zvzServerInfoDevicesExceeded.0 = INTEGER: 0
```

And a similar example using the V2c account created above:

```
bin $ snmpwalk -v2c -c public 172.16.2.169
zvzServerConfig
ZEEVEE-MIB::zvzServerConfigAutoEdidMode.0 = INTEGER:
enabled(1)
ZEEVEE-MIB::zvzServerConfigHdmiAudio.0 = INTEGER:
allowCompressed(1)
ZEEVEE-MIB::zvzServerConfigLicense.0 = STRING: none
```

SNMP Notifications

There are four different types of SNMP Notifications. The original was for SNMPv1. That format is no longer in use. Then came v2C, which is very easy to use, but not used often due to lack of authentication or encryption. SNMPv3 has two different notification mechanisms. They both use the same format as defined in SNMPv2c, but add authentication and encryption. The first v3 notification is still called a trap. It is similar to v2c in that it is unreliable – the trap sender sends it over UDP and forgets. The configuration required for this form of notification is surprisingly terrible, and for that reason, not supported by ZMP. The final notification form is called an “Inform”. This is the same as the trap, but reliably sent. The receiver must acknowledge the inform, and the sender must try a number of times until an acknowledgment is received. Interestingly, using the Inform is not very hard.

NOTE: Roles are reversed for notifications! ZMP is the client and your trap server... is the server. That means that to receive either v2c traps, or v3c informs, you must configure your trap daemon with the correct authentication and access control. As a warning, the net-snmp trap daemon, as with its snmp daemon, is just bit tricky to use.

From the ZMP CLI, the following commands manage notification generation:

```
add snmp trap-server v2c-trap ip-address <address:ip>
community <string>
add snmp trap-server v3-inform ip-address
<address:ip> auth MD5 encrypted no username <string>
password <string>
delete snmp trap-server v2c-trap <address:ip>
community <string>
delete snmp trap-server v3-inform <address:ip>
username <string>
how snmp trap-servers
```

For example, adding a trap server (management station) to receive v3 informs:

```
Zyper$ add snmp trap-server v3-inform ip-address
172.16.2.103 auth MD5 encrypted no username
testinforms password zazzle1234
```

Now... you must configure your trap server with the above v3 account details.

If you are doing that on Linux, then:

If `snmptrapd` is running, **stop** it.

Add the following line to `/var/net-snmp/snmptrapd.conf`:

```
createUser testinforms MD5 zazzle1234
```

Add the following line to `/usr/local/share/snmp/snmptrapd.conf`

```
authUser log testinforms
```

NOTE! This file may be elsewhere, like `/usr/share/snmp/snmptrapd.conf`

Then, restart `snmptrapd`

I like to start it locally, without it forking, and output to the terminal

```
sudo snmptrapd -n -f -Lo
```

If you want traps to go to syslog, then just start it without any options.

More Technical Information on the Linux Net-SNMP Package

If NetSNMP is installed on Ubuntu Linux, then you either have to install the mibs in `/usr/share/snmp/mibs`, or use the `-M` command line switch to *fully* specify the path (cannot use the `~` character). For example, if the mibs are placed under your home directory, “snmp-mibs”, the following will work:

```
snmpwalk -M +${HOME}/snmp-mibs -m all -u testAccount -l  
authNoPriv -A myPassword 127.0.0.1 zvsServerInfo
```

Note the above example uses the account and password created in the earlier example. Further, if the mibs are copied to the `/usr/share/snmp/mibs` directory, then the `-M` in the above command may be omitted.

Note also that the Ubuntu net-snmp directory structure does not follow the man pages for net-snmp apps. Very annoying. However, any ZMP system (including in-house servers and build systems), the “standard” directories are followed. In this case, the mib directory is `/usr/local/share/snmp/mibs`.

6 Appendix

Updating the Software

Using Mac OS X

1. Make sure the Management Platform is powered and is working correctly.
2. Download the latest software from the ZeeVee website. Make note of the location of where the software was downloaded.
3. Launch the Terminal app, found under the Applications > Utilities folder. By default, the current directory will be the Home directory.

```
Last login: Tue Mar 22 14:24:08 on console
Andrews-MacBook-Pro:~ Andrew$
```

4. Change the directory to the location of the downloaded software file. For example, if the software was downloaded to the Desktop, then change to the Desktop folder, as shown:

```
Last login: Tue Mar 22 14:24:08 on console
Andrews-MacBook-Pro:~ Andrew$ cd desktop
Andrews-MacBook-Pro:desktop Andrew$
```

5. Use the FTP protocol to login to the Management Platform. At the terminal prompt, type the following and press the [ENTER] key.

```
Andrews-MacBook-Pro:desktop Andrew$ ftp 192.168.1.6
```

6. Enter the user name and password. Use `anonymous` for the user name and use `guest` for the password. The password will not be echoed to the screen.

```
Andrews-MacBook-Pro:desktop Andrew$ ftp 192.168.1.6
Connected to 192.168.1.6
220 (vsFTPD 3.0.2)
Name (192.168.1.6:Andrew): anonymous
331 Please specify the password.
Password:
230 Login successful.
Remote system type is UNIX.
Using binary mode to transfer files.
ftp>
```

7. Type `cd files` at the ftp prompt to change to the `/files` directory.

```
ftp> cd files
250 Directory successfully changed.
ftp>
```

8. Enter and run the `put` command, followed by the full name of the software file, as shown. Make sure to replace `[version]` with the version of the filename you are using. For example:

```
ftp> put update_nuc_1.7.1.33348.zyper
```

9. Press the `[ENTER]` key. Information similar to the following will be displayed.

```
local: update_nuc_1.07.1.33348.zyper remote: update_
nuc_1.7.1.33348.zyper
229 Entering Extended Passive Mode (|||35257|).
150 Ok to send data.
100% |*****| 6830 KiB 94.30
MiB/s 00:00 ETA
226 Transfer complete.
6994519 bytes sent in 00:00 (92.30 MiB/s)
```

10. Type the `exit` command to exit FTP.

```
ftp> exit
Andrews-MacBook-Pro:desktop Andrew$
```

11. Telnet to the Management Platform, as shown.

```
$ telnet 192.168.1.6
Trying 192.168.1.6...
Connected to 192.168.1.6
Escape character is '^]'.
zyper$
```

12. Use the `update` command to update the Management Platform. Once entered, the Management Platform will reboot and the software will be updated. Note that the connection will be lost, temporarily, during the update process.

```
zyper$ update server update_nuc_1.7.1.33348.zyper
Success
```

```
Server rebooting; connection will end
```

Using Windows

1. Make sure the Management Platform is powered and is working correctly.
2. Download the latest software from the ZeeVee website. Make note of the location of where the software was downloaded.
3. Open Chrome and enter the IP address of the Management Platform using the FTP protocol. For example:

```
ftp://169.254.185.207
```


4. The /files folder will be displayed.
5. Drag-and-drop the latest software file to the /files folder.
6. Use the Telnet protocol to access the Management Platform API.
7. Use the `update` command to update the Management Platform. Once entered, the Management Platform will reboot and the software will be updated. Note that the connection will be lost, temporarily, during the update process.

```
zyper$ update server update_nuc_1.7.1.33321.zyper  
Success
```


```
Server rebooting; connection will end
```

Using ZyPer Management Platform

1. Make sure the Management Platform is powered and is working correctly.
2. Download the latest software from the ZeeVee website. Make note of the location of where the software was downloaded.
3. Login to the ZyPer Management Platform. Refer to [Accessing ZMP \(page 13\)](#) for more information.
4. Click the **Server** option at the left of the page.



5. Scroll down within the Server pain until you see the option to Update Server Software. Drag the latest software into the box and press **Update Server** to begin process. (**Note:** You can also revert the server to the previously installed version of software by clicking the **Revert Server** button) **"Show advanced controls"** must be enabled to use this option.



Show advanced controls

Important Note:

The ZyPer MP update file will be available in three, platform-specific versions. Please use the correct version for the hardware platform being updated.

ZyPerMP NUC computer: update_nuc_2.1.xxxx.zyper
ZyPerMP Proserver: update_proserver_2.1.xxxx.zyper
ZyPerMP VMware: update_vm_2.1.xxxx.zyper

Redundancy Configuration Instructions

To configure redundancy, follow the steps below. The secondary server must be running for the redundancy fields to be visible in ZMP or the API.

Configuring redundancy through the API

Configuring the IP Address

- 1) Login to the main ZMP, or Master through telnet.
- 2) Issue the **"set server redundancy all-servers"** command to configure redundancy

```
IE: set server redundancy all-servers virtual-ip address 172.16.5.239 network-interface video
```

- 3) Use the **"show server redundancy"** command to review the redundancy configuration and confirm the changes
- 4) Login to the Secondary server, or Slave, through telnet.
- 5) Use the **"show server redundancy"** command to review the redundancy configuration and confirm the changes

Configure the preferred roles

- 1) Login to the Master ZMP through telnet.
- 2) Issue the **"set server redundancy this-server"** command to set the preferred master and slave states on the server.

```
IE: set server redundancy this-server preferred-master true preferred-slave false
```

- 3) Use the **"show server redundancy"** command to review the redundancy configuration and confirm the changes
- 4) Login to the Slave ZMP through telnet.
- 5) Use the **"show server redundancy"** command to review the redundancy configuration and confirm the changes

Configuring redundancy through ZMP

- 1) Login through your Master ZMP GUI with Chrome.
- 2) Open the Server Panel
- 3) Scroll down to the Redundancy fields
- 4) Set the fields listed below.

Virtual IP: The IP address that the Master and Slave servers will use. This IP address must be unique and available on the network as it will be used for telnet access for the API as well as ZMP.

Virtual Mask: The subnet mask for the virtual interface, must be correct for the IP address listed above and not it should not conflict with the main eth0 interface.

Preferred Roles Radio Button: The preferred roles for the server. This field is used to decide the Master or Slave upon both servers initializing at the same time. Although rare, this can occur.

State: The current role of the current Server connected to.

Server

Redundancy

IP: 172.16.5.240

Virtual IP:

Virtual Mask:

State: Master

Preferred

Master

Slave

After configuration is complete on the Master, the information should populate to the Slave server. The preferred roles for the Slave server will still need to be configured. This can be done by logging into ZMP using the Slave server IP address and modifying the Preferred roles.

The “**State**” field will reflect the servers current state.

5) After the configuration changes are made, login into ZMP with the Virtual IP address configured above.

The server panel should show the correct redundancy information.

Note: The “**switchover**” button above will allow the servers to swap roles as needed.

Virtual interface on the ZMP.

Below is an example of the output of the “ifconfig” from the ZMP showing the virtual IP configured on the current master server.

```
eth0  Link encap:Ethernet  HWaddr 40:8d:5c:32:46:0e
      inet addr:172.16.5.240 Bcast:172.16.5.255 Mask:255.255.255.0
      UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
      RX bytes:36015816 (36.0 MB)  TX bytes:31515642 (31.5 MB)

eth0:ZMP Link encap:Ethernet  HWaddr 40:8d:5c:32:46:0e
      inet addr:172.16.5.239 Bcast:0.0.0.0 Mask:255.255.255.0
      UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1

eth0:avahi Link encap:Ethernet  HWaddr 40:8d:5c:32:46:0e
      inet addr:169.254.4.58 Bcast:169.254.255.255 Mask:255.255.0.0
      UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1

lo    Link encap:Local Loopback
      inet addr:127.0.0.1 Mask:255.0.0.0
      UP LOOPBACK RUNNING  MTU:65536  Metric:1
      RX bytes:4873342 (4.8 MB)  TX bytes:4873342 (4.8 MB)
```

Hardware Specifications (Intel NUC version)

CPU	<ul style="list-style-type: none"> Intel® Pentium® Processor J5005
Operating System	<ul style="list-style-type: none"> Linux Ubuntu 14.04
Internal Storage	<ul style="list-style-type: none"> 64 GB SSD
Graphics	<ul style="list-style-type: none"> Intel® HD Graphics 600
LAN	<ul style="list-style-type: none"> Gigabit LAN
Internal Memory	<ul style="list-style-type: none"> 8 GB DDR4
Power Supply	<ul style="list-style-type: none"> Input: 100 ~ 240 V AC Output: 19V DC, 3.42 A
I/O	<ul style="list-style-type: none"> 2 x HDMI 2.0a 4 x USB 3.0, Type- A, female 1 x RJ45 1 x 19V DC 1 x Kensington lock slot 2 x 3.5mm headset jacks (Not used)
Operating Temperature	<ul style="list-style-type: none"> 0 °C to +40 °C
Storage Temperature	<ul style="list-style-type: none"> -20 °C to +60 °C
VESA	<ul style="list-style-type: none"> VESA Bracket included Supports 75 x 75 and 100 x 100 mm
Dimensions (W x H x D)	<ul style="list-style-type: none"> 4.55 in x 2.01 in x 4.57 in (115 mm x 51 mm x 111 mm)



RoHS



Hardware Specifications (Enterprise Grade Rack Mount)

CPU	<ul style="list-style-type: none"> Intel® Xeon E3-1200 v5
Operating System	<ul style="list-style-type: none"> Linux Ubuntu 14.04
Internal Storage	<ul style="list-style-type: none"> 64 GB SSD
Graphics	<ul style="list-style-type: none"> ASPEED AST2400 BMC
LAN	<ul style="list-style-type: none"> Dual Gigabit LAN
Internal Memory	<ul style="list-style-type: none"> 8 GB DDR4
Power Supply	<ul style="list-style-type: none"> 200W Low-Noise AC-DC power supply with PFC
I/O	<ul style="list-style-type: none"> 1 x VGA (15-pin D-sub) 2 x USB 2.0, Type-A, female 2 x RJ45 (LAN) (Video Network and Management Network) 1 x RS232 (9-pin D-sub)
Operating Temperature	<ul style="list-style-type: none"> +10 °C to +35 °C
Storage Temperature	<ul style="list-style-type: none"> -40 °C to +70 °C
Dimensions (W x H x D)	<ul style="list-style-type: none"> 17.2 in x 1.7 in x 11.3 in (437 mm x 43 mm x 287 mm)
Weight	<ul style="list-style-type: none"> 8.45 lbs, (3.83 kg)



RoHS



Power Button



Status LEDs



Ethernet Port 0 = Video Port. DHCP default IP Address

Ethernet Port 1 = Management Port.

Static IP Address 192.168.20.2 Subnet Mask = 255.255.255.0

Hardware Specifications (VMware Virtual Machine)

CPU	<ul style="list-style-type: none">• Dual CPU's
Server Platform	<ul style="list-style-type: none">• VMware ESXi
Internal Storage	<ul style="list-style-type: none">• 34 GB or greater
LAN	<ul style="list-style-type: none">• Gigabit LAN
Internal Memory	<ul style="list-style-type: none">• 8 GB or greater





North America: +1 (347) 851-7364 • sales@zeevee.com

International: +1 (347) 851-7364 • sales@zeevee.com

EMEA: +44 1494 956677 • EMEAsales@zeevee.com