



Maximum RFID

UHF CREDENTIALS for VEHICLE MOUNTING with LR-2000, LR-3000 & LR-3200 READERS

WS-UHF-0-0 Windshield Tag

-) Self-adhesive — tag adheres permanently **inside windshield glass**
-) Tag is destroyed if it is ripped off windshield after adhesive cures
-) Hands-free identification — out of driver's line of sight
-) Secure tag — for one-time use — slits give evidence of tampering



RV-UHF-0-0 Rearview Mirror Tag

-) Tag adheres permanently on shell of rear-view mirror
-) Self-adhesive — tag is destroyed if it is pulled off after curing
-) Hands-free identification — **low visibility** — black side faces reader
-) Secure tag permanently attached inside or outside the vehicle



MT-UHF-0-0 Metal-Mount Tag

-) Bar-type tag — variety of locations and fastenings — reads **on metal**
-) Self-adhesive — also held by screws, rivets, cable ties ...
-) Use inside or outside on front, side or top of vehicles
-) For big trucks, buses, forklifts, containers, golf carts, wheelchairs ...



SV-UHF-0-0 Sideview Mirror Tag

-) Tag adheres permanently on edge of mirror shell
-) Self-adhesive — tag is disabled if pulled off after adhesive cures
-) Hands-free — small, thin, simple, **out of sight** under mirror
-) Secure tag — flexible use in other outside locations



PT-UHF-0-0 Portable Tag

-) Tag installs like a toll highway tag on windshield behind mirror
-) Hook-and-loop adhesive strip holds tag firmly in reading position
-) Hands-free use inside vehicles — **move tag** easily to other vehicles
-) For readers installed above the traffic lane or at either side



VT-UHF-0-0 Sunvisor Tag

-) Hand-held — tag can be held by fingertips on clip — or ...
-) Hands-free — tag clips to sunvisor — easily moved to other vehicles
-) Clip holds tag facing reader through windshield when visor is down
-) Lower visor to read tag — tag is **out of sight** when not reading



HT-UHF-0-0 Hangtag

-) Tag hooks on rearview mirror's post — easily moved or carried
-) Hook lets tag hang free — to read, driver can turn tag by fingers
-) Hands-free identification — also portable like a card — hold to read
-) **Visible through windshield** for printed or laminated identification



ST-UHF-0-0 Supertag

-) Large tag with **superior read range** in tough assignments
-) Attaches by double-side adhesive tape, screws, rivets, cable ties ...
-) Permanent or temporary mounting — for rugged use and bad weather
-) Perfect in industrial and commercial applications — inside or outside





Maximum RFID

NOTE: For UHF credentials held by hand, see product sheet "UHF Credentials for Holding by Hand". For vehicle-mounted tags, see below. Reading Distances – Up to These Distances in Practical Applications

<u>Tag</u> ... <u>Conditions</u>	<u>LR-2000, LR-3000, LR-3200</u>	<u>uAccess Readers</u>
WS-UHF-0-0 on windshield	25 feet (7.6 meters)	(Not applicable)
RV-UHF-0-0 on mirror shell	20 feet (6.1 meters)	(Not applicable)
MT-UHF-0-0 on metal surface	15 feet (4.6 meters)	(Not applicable)
SV-UHF-0-0 on sideview mirror	25 feet (7.6 meters)	(Not applicable)
PT-UHF-0-0 on windshield	15 feet (4.6 meters)	(Not applicable)
VT-UHF-0-0 clipped on visor	15 feet (4.6 meters)	(Not applicable)
HT-UHF-0-0 hanging on mirror	10 feet (3.0 meters)	6 inches (15 cm)
ST-UHF-0-0 fastened on metal	35 feet (10.7 meters)	(Not applicable)

Reader Selection With vehicle-mounted tags, use LR-2000, LR-2200, LR-3000, and their "HiLo" variations.

Technology in Tags and Cards

- J UHF communications: Bi-directional between UHF readers and credentials.
- J Excitation frequency: 865-868 MHz for the LR-2200 reader; 902-928 MHz for other UHF readers.
- J Read repetition rate: Set in the readers. For "LR" readers, rep rate is 3 reads per second (field-programmable to slower rates).

Encoding for Tags

- J Code format type – Wiegand. • Open code formats – 26-bit-STD and 37-bit-AWI. • For a custom format, call AWID.

Information Required in Purchase Order (Include leading zeros in facility code and ID numbers.)

- J Quantity. • AWID's part no. • Code format (example: 26-bit-STD). • Facility or site code. • Start ID number sequence.

Size of Tags and Cards (Approximate)

<u>Tag</u>	<u>Width</u>	<u>Height</u>	<u>Thickness</u>	<u>Notes</u>
WS-UHF-0-0	4 inches	1 inch	<1/32 inch	Peel-off sheet covers adhesive.
RV-UHF-0-0	4-3/16 inches	1-1/8 inches	<1/32 inch	Peel-off sheet covers adhesive.
MT-UHF-0-0	8 inches	15/16 inch	1/4 inch	Self-adhesive. 2 holes for fasteners.
SV-UHF-0-0	4-3/8 inches	1/2 inch	<1/32 inch	Peel-off sheet covers adhesive.
PT-UHF-0-0	3-1/8 inches	1-5/8 inches	3/8 inch	Peel-off sheet covers adhesive strip.
VT-UHF-0-0	4-1/2 inches	2-3/8 inches	1/32 inch	Includes U-clip for sunvisor.
HT-UHF-0-0	2-1/4 inches	6-1/2 inches	1/32 inch	With hook to hang on mirror.
ST-UHF-0-0	5-1/2 inches	7-3/4 inches	3/4 inch	Flat back. 4 holes for fasteners.

Slots and Holes

- J WS-UHF, RV-UHF, SV-UHF, PT-UHF, HT-UHF: Must have **no slots or holes**, punched or drilled.
- J VT-UHF: **Contains a slot** for the sunvisor clip (supplied with the tag).
- J MT-UHF, ST-UHF: **Contains holes** at the ends for screws, rivets, cable ties. Must not be punched or drilled.

Applications

- J Use tags on cars, trucks, buses, fire trucks, forklifts, motorcycles, golf carts, transit vehicles, wheel chairs, gurneys, rail cars, etc.
- J For security, **WS-UHF** and **RV-UHF** tags tear when they are ripped from their cured adhesive. **SV-UHF** tag is for one-time use only.
- J For user convenience, all other tags may be moved easily from one vehicle to another vehicle.
- J Tag type and mounting location must be consistent for all readers in a particular installation.
- J If used with a "HiLo" reader (dual antennas), credentials may be different types, in different locations, on different vehicle types.

Custom Graphics

- J For quotation, send original artwork to AWID. J A local printer may be able to print graphics. J Not for ST-UHF tag.

Literature for UHF Credentials

- J Before installing any tag, read AWID's "Installation Instructions" sheet for that tag type.
- Visit AWID's Web site www.AWID.com to download all literature.

Options and Accessories

- J LR-TEK LR Reader Tech Kit: Required -- a one-time purchase for every installing dealer.



18300 Sutter Blvd, Morgan Hill, CA 95037
Tel: (408) 825-1100 Fax: (408) 782-7402