






Wall mount bracket for ultra low-profile vandal dome cameras

DWC-V7WMw

DWC-V7WM



WHAT'S IN THE BOX

Camera Mounting Screws		4	Mounting Pad		1
Screws and Plastic Anchors		4	Mounting Template		1
Quick Setup Guide		1			

NOTE: Download all your support materials and tools in one place.

1. Go to: <http://www.digital-watchdog.com/resources>
2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



INSTALLATION

- 1 Using the mounting template or the mounting bracket itself, mark and drill the necessary holes on the mounting surface.
- 2 Secure the mounting bracket to the mounting surface using the screws and anchors included. Use the mounting pad between the bracket's arm and mounting surface as needed.
- 3 To mount the camera to the mounting accessory, remove the dome from the camera base using the wrench included with the camera.

NOTE: Do not touch the lens when handling the camera.

- 4 Pass wires through and make all necessary connections.
- 5 Secure the camera to the mounting bracket using the two (2) included screws.
- 6 Adjust the camera's lens position and angle and place the cover dome on the camera base to complete the installation.

