

DROP IN™ BOX KITS

NON-METALLIC BOX • 4" METAL COVERS & PLASTIC BLANKS



FLB4360NL

WITH LOW PROFILE METAL COVERS...

CATALOG NUMBER	UPC/DCI/NAED MFG. #018997	DROP IN™ FLOOR BOX KITS FINISH, COVER STYLE	UNIT/STD PKG
METAL COVER w Two FLIP LIDS			
FLB4360MB	00760	Non-metallic box, Brass cover	1
FLB4360NL	00761	Non-metallic box, Nickel-plated Brass cover	1
METAL COVER w Two THREADED PLUGS			
FLB4362MB	09810	Non-metallic box, Brass cover	1
FLB4362NL	09812	Non-metallic box, Nickel-plated Brass cover	1



FLB4362NL

DROP IN BOX Kits include non-metallic box, round 4" diameter metal cover with two flip lids or threaded plugs, non-metallic gasket support plate, gasket, carpet ring, UL Listed 15 amp TR duplex receptacle, mounting bracket, NM94 and NM95 cable connectors, (3) #8 x 1/2" flathead screws and (1) #6 x 1/2" screw.

5 MINUTE Installation

with a Single Hole Saw Cut



- 1 Determine box location** (avoid structural framing members). Use a hole saw to cut a 4-1/4" diameter opening through the floor and subfloor.
- 2 Insert mounting bracket**, using indicator marks to align bracket for proper receptacle orientation. Tighten (3) wing screws to secure bracket to floor.
- 3 Pull cable.** Install in box with supplied cable connector. Attach box to bracket with (3) #8 x 1/2" sheet metal screws (supplied) through the U-shaped cut outs in the box flange.
- 4 Wire receptacle.** Install in box. Attach supplied gasket support plate to receptacle with #6 x 1/2" screw.
- 5 Cover Installation** Install gasket. Attach metal cover (or blank) to box with (3) supplied #8 x 1/2" flathead machine screws.

