CUT IN BOX KITS

NON-METALLIC BOX • 4" METAL COVERS







METAL COVERS WITH FLIP LIDS...



FLB3532NL

CATALOG	UPC/DCI/NAED	CUT IN™	UNIT/STD		
NUMBER	MFG. #018997	FLOOR BOX KITS	PKG		
c: L Fub.u	- N . 11" 1				
Single FLIP LI	Non-metallic box	X			
FLB3531MB	00745	Brass cover	1		
FLB3531NL	00746	Nickel-plated Brass cove	r 1		
Two FLIP LID S	• Non-metallic box				
FLB3532MB	48017	Brass cover	1		
EILBIS 893 28NOLX	KITS 48019	NIckel-plated Brass cove	r 1		
include non-me	tallic box, round 4" o	liameter metal cover with	flip lid(s),		
non-metallic gasket support plate, gasket, gasket, UL Listed 15 amp					
TR duplex receptacle, NM94 and NM95 cable connectors, (3) #8 x 1/2"					
flat head screws and (1) #6 x 1/2" screw.					
	. ,				

CATALOG	UPC/DCI/NAED	METAL COVER	UNIT/STD
NUMBER	MFG. #018997	TRIM KITS	PKG



UNIT/STD

311161C 1 211 2 0 0 1	•			
FLB3531MBTK	00747	Brass cover	1	
FLB3531NLTK	00748	NIckel-plated Brass	1	
Two FLIP LIDS				
FLB3532MBTK	48018	Brass cover	1	

COVER TRIM KITS include round 4" diameter metal cover with flip lid(s), gaskets, UL Listed 15 amp TR duplex receptacle

NUMBER	MFG. #018997	CARPET RING	PKG			
for FLB3531TK and FLB3532TK KITS						
FLB3530MB	16900	Brass	1			
FEB3530NEO	1					

UPC/DCI/NAED METAL



with Two Hole Saw Cuts





1 Using a 4" diameter hole saw, cut opening in floor approximately 1/2" deep. Avoid structural framing members.



2 Next, use a 3-1/2" hole saw to cut through the remaining flooring/subfloor, creating a shelf at the desired box depth..



Single FLID DOOR

CATALOG

3 Remove material that remains between saw cuts.



4 Pull cable. Install in box with supplied cable connector. Attach box to floor with (3) #6 x 1-1/4" wood screws (not supplied) through U-shaped cut outs in box flange.



5 Wire receptacle. Install in

Arlington

800.233.4717 • www.aifittings.com • EMAIL sales@aifittings.com