



INSTALLATION INSTRUCTIONS

- 1. Tape this template to the drywall
Center the template between two studs. Make sure that it's 14.25" W x 15.75" H
- 2. Mark the Location of the holes.
Use a punch or screw to mark holes in each corner.
- 3. Remove the template and drill the holes
Use an 1/8" or smaller bit, drill through all the holes marked in previous step.
- 4. Cut the drywall opening
Use a drywall saw to cut between the holes drilled.

Cutout Dimensions - 14.25" W x 15.75" H

THIS MUST BE PRINTED ON A 17" W x 22" H SHEET OF PAPER AT A 1:1 RATIO!