



END THE WAITING GAME

SECO-LARM's Room Occupancy Monitor

Know at a glance whether a room is in use

The Room Occupancy Monitor (ROM) indicates whether room (like a restroom or fitting room) is occupied or vacant.

Use for any place where you want occupancy notification:



ENFORCER®

ENFORCER®

Room Occupancy Monitor

Fitting Room Application



1-Fitting Room Application



2-Fitting Room Application*



Room Occupancy Monitor

RM-R100-KB1Q

Features:

- Monitor fitting rooms, restrooms, etc.
- Increases sales, safety, customer flow, and satisfaction
- Reduces crowding, theft, and embarrassing situations
- Programmable for PIR sensor (movement), phototransistor (light), or door sensor input (magnetic contact switch) to detect occupancy
- Programmable to flash to alert staff to check on occupant after a set amount of time
- Indicator will flash and beep** if Help Button is pressed
- Each sensor can transmit to an unlimited number of indicators
- Staff and customers can monitor room occupancy from a distance
- Service button available
- Easy to install – Micro USB or terminal block (5~12 VDC)
- Kit includes Sensor, 1-Room Indicator, Micro USB cables, and decals
- Additional accessories available. See back for details



Multiple Decals Included:





ENFORCER®

Room Occupancy Monitor

Restroom Application





1-Restroom Application*



*Additional One-Room Indicator required to recreate Illustration

2-Restroom Application**



Ordering Information

1-Room Occupancy Monitor Kit

RM-R100-KB1Q

- Monitor fitting rooms, restrooms, etc.
- Increases sales, safety, customer flow, and satisfaction
- Programmable to use PIR sensor (movement), phototransistor (light), or door sensor input (switch) to detect occupancy
- Programmable to flash for reminder function
- Indicator will flash and beep if Help Button is pressed
- Each sensor can transmit to an unlimited number of Indicators
- Staff and customers can monitor room from a distance
- Easy to install – Micro USB or terminal block (5~12 VDC)
- Kit includes Sensor, 1-Room Indicator, micro USB cables and decals



Multiple decals included.
See inside for more info.



1-Room Indicator

RM-R100-RB1Q

- Additional 1-Room Indicator
- Programmable to flash after a preset time (3, 5, 10, 15, 20, 30 minutes)
- Indicator will flash and beep if Help Button is pressed
- Multiple decals included
- Micro USB or terminal block (5~12 VDC)

Wall-Mount Help Button

RM-R100-TBQ

- Occupant can signal for help without leaving room
- Wall-mount or for desktop use
- Powered by 9VDC battery (included)
- Includes multiple message plates, or you can print your own custom message



2-Room Indicator

RM-R100-R2Q

- Additional 2-Room Indicator
- Monitor two rooms (requires additional Room Occupancy Monitor)
- Programmable to flash after a preset time (3, 5, 10, 15, 20, 30 minutes)
- Multiple decals included
- Micro USB or terminal block (5~12 VDC)

Indicator Controller

RM-R100-TH2Q

- Allows for easy resetting of 1-Room Indicators and 2-Room Indicators once Wall-Mount Help Button is used
- Includes Belt Clip



Possible Applications:

- Restrooms
- Portable bathrooms
- Fitting rooms
- Conference rooms
- Break rooms
- Changing rooms
- Hallways
- Stairways
- Storage rooms
- Waiting rooms
- Clinic exam rooms
- X-ray rooms
- Sound rooms
- Warehouses
- Loading docks
- Gas station pumps
- Barns and stables
- Boats

SECO-LARM®

Manufacturer of **ENFORCER®**

Phone: (949) 261-2999
(800) 662-0800

Email: sales@seco-larm.com
Website: www.seco-larm.com