


PLASTIC WALL MOUNT BRACKET INSTALLATION

Attach the plastic wall mount bracket to the structure using the tapping screw (PLASTIC ANCHOR, PTS1 M5x30L) as illustrated in the figure. The plastic wall mount bracket must be attached to a structure such as hardwood, wall stud, concrete, or a suitable material capable of supporting the final mount assembly. The installer may need to change the method of mounting or hardware used depending on the wall material.

Use the supplied M4 tapping screws to align the wall mount bracket holes to dome housing holes.



* PLASTIC WALL MOUNT BRACKET PARTS LIST

NO	PART NAME	Q'TY
1	PLASTIC WALL MOUNT BRACKET BASE	1
2	PLASTIC WALL MOUNT BRACKET COVER	1
3	TAPPING SCREW	2
4	TAPPING SCREW	3
5	PLASTIC ANCHOR	2
6	TEMPLATE SHEET	1
7	MANUAL	1

* NOT INVOLVED IN PRODUCT.

PRODUCT FEATURES

- Light duty Plastic Wall Mount
- Maximum load 4.4 lb [2.0 kg]
- Easy and safe to install.

DOME HOUSING TYPE PER MOUNT HOLE

Select the camera dome model being installed. The "N" number corresponds to the mounting holes used.

**** MOUNT HOLE NUMBER ****

N.2 & N5: CDI2H12VIFW, CDI4H12VIFW, CDI8H11VIFW,

N.3: CDI2H12IFW, CDI4H36IW, CDI4H12IFW

N.4: CDI2D28W, CDI2D28IW

N.6: B

N.7: C

N.8: CDI5H360


N.9: D

N.10: CDI2512FW, CDI2512IFW
CDI2D12FW, CDI2D12IFW



N.11: CDT2S12VIFW, CDT2S12VI, CDT2S12IFW

N.12: E

N.13: CDI2528W, CDI2528IW



DIMENSION (mm)



50304556A