



Activation Quick Start Guide



1

Register and establish Telguard Online Account. Request to have ELK-TAP rate plan added to your account.



2

Register and establish ElkLink Account



3

Check cellular signal strength in proposed mounting location



4

Physically mount C1M1, make all wiring connections and apply power



5

Activate C1M1 on Telguard Online Site using device serial or ICCID number



6

Activate C1M1 on ElkLink Site using device MAC address and PIN



7

Program M1 communications settings through ElkRP2



8

Test alarm signals through both cellular and IP pathways



For help or more info, contact us at (800)797-9355 or email techsupport@elkproducts.com