






















AXIS T94K01D Pendant Kit

Installation Guide



AXIS T94K01D Pendant Kit

<p>AXIS M3057-PLVE/ M3058-PLVE</p> 	 <p>1x</p>	 <p>1x</p>	 <p>2x 2x</p>  <p>1.1</p>
<p>AXIS P32-V/-LV</p> 	 <p>1x</p>	 <p>1x</p>	 <p>2x 2x</p>  <p>2.1</p>
<p>AXIS P33-V/-LV</p> 	 <p>1x</p>	 <p>1x</p>	 <p>2x 2x</p>  <p>3.1</p>
<p>AXIS Q35-V/-LV</p> 	 <p>1x</p>	 <p>1x</p>	 <p>2x 2x</p>  <p>4.1</p>


AXIS T94K01D Pendant Kit




1.1




1.2




1.3





1.4







2.1



2.2




2.3








AXIS P32-V




2.4




2.5




2.6




AXIS P3214-V/P3215-V




2.7







3.1




3.2




3.3




3.4



3.5




AXIS T94K01D Pendant Kit






4.1


4x




4x




4.2




4.3




4.4





4.5




4.6






4.7



4.8



4.9



4.10

