

# Quick Start Guide

Kidde Wire-Free Alarm Network Setup

**Please Read All Instructions First!**



2556-7203-02 Rev A

Section 1


**Quick Start Wire-Free Network Setup**

Section 2

**Adding a Device to an Existing Network**

Section 3

**Resetting a Device**



SMOKE ALARM: 3 long beeps, repeating  
CO ALARM: 4 quick beeps, repeating  
STANDBY: Green LED blink every 60 seconds  
FAULT: Amber LED blink with chirp every 60 seconds  
LOW BATTERY: Amber LED blink every 60 seconds  
END OF UNIT LIFE: Amber LED blink every 60 seconds  
Press the test button to test weekly.  
See the user manual for more information.



1

## Power Up All Devices

Locate the red wheel on the back of the device. Turn the red wheel to the "ON" position on ALL devices using the included tool, or a standard screwdriver.

Once powered, the light rings will glow red.



**Coordinator**

*"Searching for other devices."*


**Hold for  
5 seconds**

**DON'T press buttons  
on other devices**

**2**

## Pick One Device

**Press & hold the button on only ONE device until you hear 2 beeps. Release button. You will hear "Searching for other devices." This device will be the "Coordinator" of the network. Keep this unit separated from others. The light will pulse green and device will sound a continuous "sonar" ping until step 4 is completed.**



3

## Relax and Wait

Wait until all devices have connected to network.

Once connected, each device will speak:

*"Success now connected!"*

The non-Coordinator devices are called "RFDs."

Once connected, the lights will  
glow green.



Hold for  
5 seconds


4

## Pick One Device

**Press & hold the button on only ONE device until you hear 2 beeps. Release button. "Sonar" ping will stop.**

Device will announce that setup is complete and the number of connected devices.

*Coordinator*




5

## Setup Complete!

**If all devices flash green and the “sonar” ping has stopped, the devices are now connected. Congratulations!**


For best results, install the Coordinator unit in a central location of the home. Refer to user guide for detailed installation instructions.



Section 2

**Adding a Device  
to an Existing Network**





*SMOKE ALARM: 3 long beeps, repeating*  
*CO ALARM: 4 quick beeps, repeating*  
*STANDBY: Green LED blink every 30s*  
*FAULT: Amber LED blink every 30s*  
*LOW BATTERY: Amber LED blink every 30s*  
*END OF UNIT LIFE: Amber LED blink every 30s*  
*Test button to test weekly.*  
*See manual for more information.*



1

## Power Up New Device


**Locate the red wheel on the back of the device being added to the network. Using the activation tool or a standard screwdriver, turn the red wheel to the "on" position.**

Once powered, the light ring will glow red.

*"Searching for other devices."*



Installed Device



Device Being Added

2

## Pick One Installed Device

**Press & hold the button on only ONE INSTALLED device on your network until you hear 2 beeps. Release button. You will hear "Searching for other devices."**

The light will pulse green and device will sound a continuous "sonar" ping until step 4 is completed.



*"Success, now connected!"*

3

## Relax and Wait


**Wait until the new device has connected to the network. Once connected, the new device will speak: "Success now connected!"**

Once connected, the light ring will glow green.

*"Setup  
complete!"*



Installed Device



Added Device

4

## Pick the Installed Device

Press & hold the button on the INSTALLED device for 5 SECONDS until you hear 2 beeps. Release button. "Sonar" ping will stop.

Device will announce that setup is complete and the number of connected devices.

## Section 3

# Resetting Your Device

If you encounter an issue at any point during the wire-free network setup process, you may reset the device by following the subsequent directions.

*"Resetting  
wireless  
settings."*




**Hold for  
8-9 seconds**

**1**

## Resetting the Device

**Press & hold the button on the device for  
8-9 seconds until you hear 3 beeps.  
Release button. You will hear the words  
"Resetting wireless settings."**



***"Ready to connect, follow Quick Start instructions!"***

**2**

## Resetting the Device

**Light ring will flash green once and then it will pulse red. You will hear the words "Ready to connect, follow quick start instructions."**

Device has been reset.

Need more help  
getting started?

Visit **kidde.com/wirefreealarms**  
to view video tutorials or scan the  
QR code below.



*Consult the User Guide for more detailed  
instructions on product installation and use.*