



5800C2W

The Simplest Way to Convert Hardwired to Wireless

Hardwired to 5800 Wireless Converter
Information for Dealers

Easy, Affordable Hardwired to Wireless Converter

Offers Quick, Easy Upgrades to LYNX Systems!



Offer LYNX all-in-one home and business controllers to more customers

- Upgrade the system to LYNX Touch for connected home and business functionality
 - 4G/Wi-Fi® alarm communications
 - Z-Wave® automation and garage door control
 - Brilliant, intuitive touchscreen display simplifies operation and programming
- Upgrade the system to LYNX Plus for traditional security
- All LYNX systems are compatible with Resideo Total Connect Remote Services—providing your customers with on-the-go remote control of their homes and businesses plus additional RMR opportunities for you!

Save on installation cost, time and materials

- Retrofits existing security control panels of virtually any type or brand
- Convert up to nine hardwired zones into 5800 Series wireless zones—more than any other solution in the industry!
- Works with any hardwired sensors (e.g., glassbreaks, PIRs, etc.) right out of the box
- Eliminates the labor and expense of adding new transmitters to the system's protection points by using existing wired infrastructure

Ideal for retrofits and new construction installations that have been fitted with hardwired systems.

For more information

security.honeywellhome.com/hsc



Resideo Technologies, Inc.

2 Corporate Center Drive, Suite 100
P.O. Box 9040
Melville, NY 11747
1-800-645-7492
resideo.com

L/5800C2DS/D | 06/19
© 2019 Resideo Technologies, Inc.
This product is manufactured by Resideo and its affiliates. The Honeywell Home trademark is used under license from Honeywell International Inc. All rights reserved.

Honeywell Home 5800C2W Hardwired to 5800 Wireless Converter

is simply the easiest, most economical way to convert existing hardwired systems to the Honeywell Home 5800 Series wireless technology. It can help you retain accounts, close more business and provide your customers with all of the amazing benefits of the connected home and business.

Simple, three-step set-up:

1. Disconnect wired zones from old panel, wire sensors to 5800C2W terminals (must have resistor)
 - Plug in wall power
 - Connect backup battery
2. Calibrate/activate the module zones
3. Enroll the module's wireless zones into the control panel

Easy to install and highly flexible

- One-button calibration automatically detects EOL resistor valve
- Power supply included for additional cost savings
- Onboard battery charger for standard backup battery
- ETL Listed
- Programs like any 5800 Series wireless device

For more information, call 1-800-645-7492 today!

Honeywell Home