


# AXIS F4005-E Dome Sensor Unit

## Installation Guide







1x



4x




1x



1x





1x






1x

## AXIS F4005-E Dome Sensor Unit


---









**1.1**




**1.2**







## 2.1



## 2.2




## 2.3







**3.1**




**3.2**




## 3.3



## 3.4




### 3.5




### 3.6



4x



0.5 Nm  
(0.37 lb ft)



### 3.7





Installation Guide

AXIS F4005-E Dome Sensor Unit

© Axis Communications AB, 2016

Ver. M1.4

Date: February 2016

Part No. 1493666