VIVOTEK Mounting Accessories

AM-71H_V2 Conduit Box

Installation Guide

Revison History:

Rev. 1.0: Initial release

Accessory Ordering part no.: VIO900000083

I Compatible VIVOTEK Cameras

Compatible cameras/brackets	
A	FD9368/FD9383-HTV/FD9388/FD9389-V2/FD9389-V3/FD9399
B	IT9383/IT9388
C	FD9360/FD9380/FD9383-HV
D	IT9389-V3/IT9399/FE9380/FE9382-V2/FE9391-V2/FE9191-V2
E	TB9332-E
F	TB9333-E/TT9333-E

Mounting Dimensions



Package Contents



II Installation – Dome Camera Type

1 Remove the top cover.



2 A 3/4" conduit is required for routing the cables with waterproof connection.





3 Attach the included alignment sticker to a preferred position. Drill holes on the wall and install the junction box. If space behind the wall allows, you may also pass cables through the wall.



4 Pass the camera's Ethernet cable through the center hole of the box and the rubber seal.



5 Install the waterproof components of the cable gland to your Ethernet cable following the QIG of your camera. The cable gland will be placed within the protection of the box.



6 Make sure the rubber seal is properly installed to the center hole. The outer rim of the seal must be through and cover the edge of the hole.

Choose the appropriate rubber seal based on diameter of your cable
- ø8 x1
- ø4.5-5.5 x1



7
- **A.** FD9368/FD9383-HTV/FD9388/FD9389-V2/FD9389-V3/FD9399
- **B.** IT9383/IT9388
- **C.** FD9360/FD9380/FD9383-HV
- **D.** IT9389-V3/IT9399/FE9380/FE9382-V2/FE9391-V2/FE9191-V2
- **E.** TB9332-E
- **F.** TB9333-E/TT9333-E



8 Secure the top cover by fastening 4 screws.



9 Secure the top cover by fastening the corresponding mounting holes.



10 Install the camera using the corresponding mounting holes



11 Open a live view console and adjust the shooting direction. Refer to camera QIG for more information. Secure the camera top cover



III Installation – Turret Camera Type

1



2



3



4



5



6



7



IV Installation – Reference Pictures

FD9383-HV, FD9360, FD9380



FD9389-V3, FD9399



IT9389-V3, IT9399



FE9380, FE9382-V2, FE9391-V2, FE9191-V2



Please contact authorized distributors for warranty and RMA service.
Visit https://www.vivotek.com/support/warranty and https://www.vivotek.com/support/rma

All specifications are subject to change without noice.
Copyright © 2025 VIVOTEK INC. All rights reserved.

VIVOTEK INC.
6F, No.192, Lien-Cheng Rd., Chung-Ho, New Taipei City, 235, Taiwan, R.O.C.
| **T:** +886-2-82455282 | **F:** +886-2-82455532 | **E:** sales@vivotek.com