

1.

Remove the protective wrap.




2.

Download the Ring app.




3.

Scan the QR code on your device.



4.


Follow in-app setup.



Installation


1.

Choose a location indoors.



2.



(Optional) Remove the protective strips from the adhesive backing.



3.

Position your sensor on the wall or on a flat, level surface above the ground.

NOTE: For best results, place your sensor where it won't be accidentally kicked or moved.





Amazon Sidewalk-enabled device; requires Amazon Sidewalk coverage for use. Coverage may vary by location. For Amazon Sidewalk information, visit ring.com/sidewalk



ring.com/contact



ring.com/help