DW Cumulus is Digital Watchdog's cloud-based storage service for backup storage of events and object analytics in DW Spectrum Professional.

DW Cumulus

Windows OS Installation

Quick Start Guide

Read Before Continuing

An active DW Spectrum Enterprise subscription is required to use DW Cumulus.

An onsite Internet connection must be available and support the total active camera bitrate. This statistic can be found in the *Storage Analytics* tab in the DW Spectrum Site's *Server Settings* menu.

This document is intended to serve as a quick reference for the initial installation of a DW Cumulus for DW Spectrum Professional. For DW Spectrum features and functionality, refer to the full User Guide.

Tel: +1 (866) 446-3595 / (813) 888-9555
Technical Support Hours: 9:00AM – 8:00PM EST, Mon. – Fri.


digital-watchdog.com

INSTALLATION INSTRUCTIONS


Part 1: Install the DW Cumulus Plugin

The following instructions will guide the reader through installing DW Cumulus for a DW Spectrum Server running on a Windows operating system.


1. Use the *Taskbar System Tray* and stop the DW Spectrum Media Server.



2. Launch the DW Cumulus Installer (e.g., *DW-Cumulus-1.2.3-windows.exe*) and allow the executable to run.



3. Click the "**Install**" button and allow the installation to be completed.




4. Once the installation has been completed, click the **Finish** button to close the window.

Copyright © Digital Watchdog. All rights reserved. Specifications and pricing are subject to change without notice.


Part 2: Integrate the DW Spectrum Site

The following instructions will guide the reader through integrating DW Cumulus with DW Spectrum:

1. Use the *Taskbar System Tray* and start the DW Spectrum Media Server.





2. Launch the DW Spectrum Client and open the **Site Administration** menu.
   In the *General* tab, select the **Integrations** tile.



3. Select "**DW Cumulus Cloud Storage**" from the plugins panel then enter the **Subscription Key** for the DW Cumulus subscription.

4. Click the **Apply** button to save the settings. Verify that the Cloud Storage information is connected and the storage capacity is correct before closing the window.






Copyright © Digital Watchdog. All rights reserved. Specifications and pricing are subject to change without notice.

5. Open the **Server Settings** menu and select the **Storage Management** tab.

   The Cumulus Cloud Storage will appear as drive "Y:\" as a "Network" type storage.


   Use the slider  to **Enable** Cumulus Cloud Storage and set the **Purpose** setting to "**Backup**".



6. Open the **Backup** tab and select the cameras using the toggles in the **What to Backup** setting column.

   Click **Apply** to save the settings.

7. Backup will begin automatically.



Copyright © Digital Watchdog. All rights reserved. Specifications and pricing are subject to change without notice.