DW

Quick Start Guide

MEGAPIX AI

cloudcam

DWC-MPX2A3WDCS

Default login information: admin | admin

When logging into the camera for the first time, you will be prompted to set up a new password. You can set the new password using the DW IP Finder software or directly from the camera's browser menu.

WHAT'S IN THE BOX

Star Wrench (T-20)	1	RJ45 Installation Tool	1
Tool Holster Cable	1	Mounting Template and Installation Guide (Recommended)	1
Screws and Plastic Anchors	1 set	Drywall	1
Quick Setup and Download Guides	1 set	Mounting Template	1
Mounting Bolts & Screws	1 set		

NOTE: Download of your support materials and tools in one place

1. Go to **http://www.digital-watchdog.com/resources/**
2. Enter the model number of your camera and click on **"Search by Product"** search
3. Click **"Installation and Quick Start Guide"** to download the Quick Start Guide
4. Click **"Install"** all supported materials, including manuals
5. Download all applicable software updates in this folder

Attention: This document is intended to serve as a quick reference for the initial set up. It is recommended that you download and review the complete user manual before connecting to the network.

SAFETY AND WARNING INFORMATION

Read through the following safety and warning guidelines carefully. Also, review the installation Guide for future reference. Failure to follow these instructions may result in damage to the unit, fire, electrical shock and the voiding of warranty. These instructions are intended to ensure that the user can operate the product correctly to avoid danger or property loss.

WARNING: Do not use the camera if any of the below conditions occur:

1. In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and area. Please refer to technical parameters for detailed information. Input voltage should meet both SELV (Safety Extra Low Voltage) and the Limited Power Source with 24 VAC or 12 VDC according to the power configuration.
2. Make sure the power supply voltage is correct before using the camera.
3. Do not drop the camera or subject it to physical shock. Do not touch sensor modules with fingers. If cleaning is necessary, use a clean cloth with a little ethanol and wipe it gently. If the camera will not be used for an extended period of time, put the lens cap on to protect the sensor from dirt.
4. Do not place conductive objects (eg., screwdrivers, coins, metal items, etc.) or containers filled with water or top of the camera, to prevent damage caused by falling objects or water seepage (causing a short circuit, fire or electric shock).
5. Securely plug the power cord into the power socket. An improper connection may cause a fire.
6. Shutdown the camera before connecting or disconnecting accessories and peripheral equipment.
7. Do not expose the camera to high electromagnetic radiation environments. Avoid heavy stress.
8. Do not point the camera lens at the sun or extremely bright objects. Otherwise, it may cause irreversible damage to the CCD (CMOS).
9. Do not place conductive objects (eg., screwdrivers, coins, metal items, etc.) or containers filled with water or top of the camera, to prevent damage caused by falling objects or water seepage (causing a short circuit, fire or electric shock).
10. Keep the camera away from liquid while in use. Do not operate the camera beyond the allowed temperature, humidity or dusty environment. Do not expose the camera to high temperature, low temperature or high electromagnetic radiation.
11. If the product does not operate normally, contact the nearest service center. Never disassemble or change the camera in any way.
12. Wipe the camera gently with a clean cloth. Avoid touching any parts of the camera. Doing so may cause fire by damaging the camera.

CAUTION:

1. Avoid the camera getting wet when installing and setting the product.
2. Do not install the camera in humid, dusty or smoky environments. Keep away from a location subject to excessive vibration or magnetic interference.
3. Do not aim the camera lens at strong light sources such as lighting or sunlight.
4. The product shall not be exposed to dripping or splashing, and no objects filled with liquids, such as vases, shall be placed on the product.
5. Do not block the camera directly towards extremely bright objects such as the sun as this may damage the image sensor.
6. The Plan-Vu is used as a disconnect device and shall also readily operable at any time.
7. Do not touch the sensor modules with fingers. If cleaning is necessary, use a clean cloth with a little ethanol and wipe it gently.
8. Do not block any ventilation openings. Install following the manufacturer's instructions.
9. A standard or grounding/polarity plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or third prong are provided for safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.
11. Only use attachments/accessories specified by the product, ensure the service's surface is not exposed to the laser beam, as this may cause damage.
12. Do not connect multiple cameras to a power supply (to avoid overload). It is recommended that the camera is used with its dedicated power supply. Installation and maintenance should be performed by professionals. Any maintenance or repair of the product is the responsibility of the installer and service personnel. Do not attempt to service the product yourself.
13. Do not touch the CCD (CMOS) sensor module with fingers. If cleaning is necessary, use a clean cloth with a little ethanol and wipe it gently. If the camera will not be used for a long time, please cover the lens cap to protect the sensor from dirt.
14. Do not aim the camera lens at strong light sources such as lighting or sunlight.
15. Please use the original packaging materials when repacking to avoid damage. Do not expose the camera to high temperature, low temperature or high electromagnetic radiation.
16. Use only with cart, stand, mount, bracket, or table specified by the manufacturer, or sold with the product.
17. Do not touch the CCD (CMOS) sensor module with fingers. If cleaning is necessary, use a clean cloth with a little ethanol and wipe it gently.
18. Please keep the camera's packing materials properly. In case of malfunction, you can return the item damaged in any way, such as in the shipment, apply cold or play is damaged, must be taken back, objects have fallen into the unit, exposed to rain or moisture, do not operate normally, or dropped, then the unit has been damaged.

STEP 1 - PREPARING TO MOUNT THE CAMERA

1. For the installation, remove the camera cover and camera module from the mounting bracket by loosening the camera module and cover assembly screws.

2. Remove the existing moisture packet and insert the new packet in its place. The camera will be shipped with a new packet. Moisture packets must be replaced if moisture issue, keep the moisture absorber in the camera for up to six months.



WARNING! The moisture absorber prevents moisture buildup inside the camera, which may cause image performance issues and damage the camera.

3. Using the camera mounting bracket or mounting template, mark and drill the necessary holes in the mounting surface.

STEP 2 - POWERING THE CAMERA

Please verify adequate strength and stability of the mounting surface.

Use a PoE Switch or PoE Injector to connect data and power to the camera using a single Ethernet cable.



Use a non-PoE Switch to connect data using an Ethernet cable and a power adapter to power the camera.

Power Information	
Power requirements	DC12V PoE IEEE 802.3af (Adapter not included)
Power consumption	12V DC 10.2W, 850mA, PoE: 5.1W, 239mA
Temperature Alarms	104° (40°)
Connector	RJ-45

STEP 3 - INSTALLING THE CAMERA

4. Attach the camera to the mounting surface using the included anchors and screws.

5. To mount the camera using the mounting bolt and screws:
   a. Secure the mounting screw to the mounting surface.
   b. Use the mounting nuts to secure the camera to the mounting surface.



6. Adjust the camera's pan by rotating the base of the camera module.

7. Assemble the dome cover over the camera body. Align the dome and bottom case to match the case marks.

NOTE: Be careful not to alter the direction of the camera module.



8. Remove the protective film from the dome. Softly wipe the dome with lens tissue or a microfiber cloth to remove any dust or smudges left from the installation process.

STEP 4 - CABLING AND EXTERNAL DEVICES

1. **Network cable** - To connect an RJ45 cable to the camera:
Option A (Recommended):
   a. Remove the grommet plug.
   b. Pass the network cable through the grommet at the base of the camera.
   c. Once the cable is through, add the RJ45 connector.



Option B:
   a. Attach the included RJ45 installation tool to the network cable.
   b. Remove the grommet plug.
   c. Pass the network cable through the grommet. Pay attention to the direction of the installation tool.
   d. Once the cable's connector is through, remove the installation tool.

Once the network cable is passed through the grommet:
   a. Insert the grommet into the bottom of the camera base.

NOTE: Bending the cable may cause water leakage.

   d. Connect the RJ45 to the camera's network input in the camera.

2. **Power** - See STEP 2.

3. **Sensor/Alarm Input (DI)** - Connect an alarm input device to + and - of the Terminal Block.

4. **Relay/Alarm Out (DO)** - Connect alarm lights or siren (normal open or normal close) to the + and - of the Terminal Block.

5. **Audio Input/Output** - Connect an amplifier or speaker to the audio output in the Terminal Block.

+	-	+	-	+	-	IN	COM	OUT
DC12V		GND		DO		AUDIO		

STEP 6 - DW IP FINDER

1. Download and install the DW IP Finder from the DW website
2. Open the DW IP Finder and click 'Scan Devices' to find the camera on the network.
3. A password must be set when connecting to the camera for the first time.
   a. Check the box next to the camera.
   b. Click "Bulk Password Assign" on the left.
   c. Enter admin/admin for the current username and password. Enter a new username and password to be used.
   Password must have at least eight (8) characters and three (3) of the following: combinations of uppercase and lowercase letters, numbers and special characters. Click "Change" to apply all changes.

STEP 7 - WEB VIEWER

1. Find the camera using the DW IP Finder.
2. Double-click on the camera's view in the results table.
3. Select the 'View Camera' option.
4. Enter the camera's username and password you set up in the DW IP Finder.
   If you did not change the default username and password, you will be prompted to set up a new password to view the camera.

STEP 8 - SET UP DW SPECTRUM CLOUDCAM

To complete the DW Spectrum CloudCam server's set up and start recording, see the DW Spectrum CloudCam QSG for additional information.

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: Please see the full product manual for more information of the H.E.V.C. Features listed or presented on a product/camera is not.

Copyright © Digital Watchdog. All rights reserved.
Specifications and pricing are subject to change without notice.

DW-QS-CM