



# Setup Guide

Téléviseur digital a color con pantalla de cristal líquido



5-073-687-11(1)



|    |                         |
|----|-------------------------|
| EN | Setup Guide             |
| FR | Manuel de configuration |
| ES | Guía de configuración   |

## Sony Customer Support

U.S.A.:  
<https://www.sony.com/tvsupport>  
Canada:  
<https://www.sony.ca/support>  
U.S.A. 1.800.222.SONY (7669) Canada 1.877.899.SONY (7669)  
Please Do Not Return the Product to the Store

## Service à la clientèle Sony

Canada :  
<https://www.sony.ca/support>  
États-Unis :  
<https://www.sony.com/tvsupport>  
Canada 1.877.899.SONY (7669) États-Unis 1.800.222.SONY (7669)  
Ne retournez pas le produit au magasin









Lea este manual antes de usar el producto

## Centro de Asistencia de Sony

<https://esupport.sony.com/ES/LA/>  
Llame al número telefónico que aparece en su póliza de garantía.  
Por favor no devuelva el producto a la tienda donde adquirió el producto.

## BRAVIA

K-85XR90M2 / 85XR90SM2 / 85XR70M2  
K-85XR70CM2 / 85XR70SM2 / 75XR90M2  
K-75XR90CM2 / 75XR90SM2 / 75XR70M2  
K-75XR70CM2 / 75XR70SM2 / 65XR90M2  
K-65XR90CM2 / 65XR90SM2 / 65XR70M2  
K-65XR70CM2 / 65XR70SM2




★1 Only for limited region/country/model. / Uniquement pour certaines régions/pays/modèles. / Solo para regiones/países/modelos limitados.


★2 Refer Reference Guide. / Reportez-vous au Manuel de référence. / Consulte la Guía de referencia.




9




10






11




12




13




\*3




\*4



\*6



\*5



\*7

