

# Setup Guide

Téléviseur  
Televisor digital a color con pantalla de cristal líquido

5-073-664-11(1)



|    |                         |
|----|-------------------------|
| EN | Setup Guide             |
| FR | Manuel de configuration |
| ES | Guía de configuración   |

Sony Customer Support

U.S.A.:  
<https://www.sony.com/tvsupport>  
Canada:  
<https://www.sony.ca/support>  
U.S.A. Canada  
1.800.222.SONY (7669) 1.877.899.SONY (7669)  
Please Do Not Return the Product to the Store

Service à la clientèle Sony

Canada :  
<https://www.sony.ca/support>  
États-Unis :  
<https://www.sony.com/tvsupport>  
Canada États-Unis  
1.877.899.SONY (7669) 1.800.222.SONY (7669)  
Ne retournez pas le produit au magasin

Lea este manual antes de usar el producto


Centro de Asistencia de Sony

<https://esupport.sony.com/ES/LA/>  
Llame al número telefónico que aparece en su póliza de garantía.  
Por favor no devuelva el producto a la tienda donde adquirió el producto.


## BRAVIA

K-55XR70M2 / 55XR70CM2 / 50XR70M2


1




2




3




4




5




6



7



8



★1 Only for limited region/country/model. / Uniquement pour certaines régions/pays/modèles. / Solo para regiones/países/modelos limitados.

★2 Refer Reference Guide. / Reportez-vous au Manuel de référence. / Consulte la Guía de referencia.



