my leviton™

decora smart™ Wi-Fi App Guide

ANDROID APP ON Google play

Available on iTunes

SA-11012

decora smart™ Wi-Fi App Guide

LEVITON

Adding a Device

Device Screen

1



Select Device Type

2

Tap 'Continue'

3



4



decora smart™ Wi-Fi App Guide

LEVITON

Adding a Device

5



6



7



Give your device a name. If you can't remember which one it is, tap 'Identify Device.' Once ready, tap 'Continue.'

8



decora smart™ Wi-Fi App Guide

LEVITON

Adding an Activity

1



2



3



4



decora smart™ Wi-Fi App Guide

LEVITON

Adding a Schedule

1



2



3



4



Adding a Schedule

5



6



7

decora smart™ Wi-Fi App Guide

LEVITON

Adding a Room

1



2



3



4



decora smart™ Wi-Fi App Guide

LEVITON

Assign a Device to a Room

1



2



3



4





decora smart™ Wi-Fi App Guide

LEVITON

Advanced Dimmer Settings

To access the advanced Dimmer controls, expand the dimmer card in the UI and tap 'Device Setup & Configuration'.









Advanced Dimmer controls allow granular control.

* Bulb Type
* Fade Rate
* LED Behavior
* Preset Levels