


GV-Control Center



Introduction

GV-Control Center is an integrated security management software that provides a handy tool to maintain a central monitoring station. GV-Control Center is a comprehensive solution for central operators to efficiently control GV-DVR / NVR / VMS, GV-Recording Server, I/O devices and IP cameras. With GV-Control Center, multiple GeoVision surveillance and video management systems can be managed and maintained centrally to enhance their monitoring performance and ensure smooth operation.

Key Features

- **Live View: Remotely monitor videos from 900 camera channels**

The Live View is a single display in which videos from a group of maximum 100 cameras can be shown, e.g. groups of cameras at office areas, exits or on the streets. Depending on surveillance needs, the operator can open up to 9 Live Views, with 100 camera channels for each Live View, on 9 monitors simultaneously. Each Live View supports live monitoring and video playback altogether.

- **Remote Desktop: Remotely access to client GV-DVR/NVR/VMS's desktop**

GV-Control Center can access the desktop of client GV-DVR / NVR / VMS and have full control of the client's monitoring system and Windows operation system.

- **I/O Central Panel: Group and manage I/O devices from different hosts**

GV-Control Center provides a useful I/O Central Panel for the operator to remotely manage I/O devices from various GV-IP devices. The operator can group function-related I/O devices together for ease of control, e.g. groups of IR sensors, alarms or fire exits. In case of building fire, for example, GV-Control Center can simultaneously trigger all alarms in the networked GV-DVR / NVR / VMS and force opening all the fire exits or water spray systems.

- **Remote Playback**

The Remote ViewLog service enables playback of recordings from different hosts. The operator can utilize the service to save video clips for later retrieval as event evidence.

- **Video Wall (optional)**

GV-Video wall, TV wall, is an establishment of multiple monitors on a server. The operator can create a layout with a variety of displays including desired camera channels, zoom windows, scan windows, web pages, video playback and live view popped up from E-Map. A megapixel camera channel can even be placed across monitors.

- Video Motion Detection (VMD) popup
- Face Recognition Watch to monitor FR events from GV-AI FR and FR cameras of GV-VMS
- ASManager View to monitor access control and LPR events from GV-ASManager
- Storyline recording
- Support for GV-Live Streaming for streaming from Android / iOS mobile device cameras

Specifications

Features	Control Center
Host	
GV-ASManager	Unlimited
GV-Authentication Server	
GV-AI FR	
GV-Compact DVR	
GV-DVR / NVR / VMS	
GV-Live Streaming account	
GV-Recording Server / GV-Video Gateway	
GV-SNVR System	
GV-Video Server	
IP Camera	
I/O devices (only for GV-IP Devices)	Unlimited * - One host supports up to 9 sets of 16-in and 16-out I/O modules.
Feature	
Live View / Channel	9 Live View windows / 100 channels per live view
VMD Group / Channel (Only for GV-IP Devices)	1 group / 1200 channels - GV-DVR / NVR / VMS: 1000 channels - GV-Video Server + GV-Compact DVR + GV-IP Camera: 200 channels
Remote DVR	Unlimited host*
Remote Desktop	Unlimited host*
Remote ViewLog	1 player
Remote E-Map / Host	Unlimited map / 500 hosts
Panorama View / Channel	4 Panorama Views / 32 channels per view
FR (Face Recognition) Watch / Host	4 viewing windows / unlimited host*
ASManager View / Host	4 viewing Windows / unlimited host*
GV-Live Streaming account	1 viewing window
Video Wall (optional)	1 to 200 licenses
Language	Arabic, Bulgarian, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hebrew, Hungarian, Indonesian, Italian, Japanese, Lithuanian, Norwegian, Persian, Polish, Portuguese, Romanian, Russian, Serbian, Simplified Chinese, Slovakian, Slovenian, Spanish, Swedish, Thai, Traditional Chinese, Turkish

Note: The maximum number of hosts supported depends on the PC performance of GV-Control Center.

Minimum System Requirements

OS	64-bit	Windows 10 / Server 2016 / Server 2019
CPU	Core i7 2600K, 3.4 GHz	
RAM	16 GB Dual Channels	
Hard Disk	1 GB for software installation	
Processor Graphics	Please see GPU Decoding Specifications below.	
Direct X	9.0c	
LAN Card	Gigabit Ethernet x 2	

Note:

- It is not recommended to install GV-Center V2 (Pro) and GV-Control Center on the same PC. **Running the two software together on the same PC may result in CPU overload or system failure.**
- To display a megapixel IP channel across monitors, make sure the external graphic cards on a server are of the same brand, model and driver version. The capacity of graphic cards must be equivalent to NVIDIA GTS 450 or higher to ensure maximum efficiency.
- When you find CPU usage is high or live view is unsmooth (dropping frames), you may need to increase CPU threads and memory or decrease the number of connected cameras to improve the system performance.
- For GV-Control Center to support up to 9 Live Views, with 100 camera channels for each Live View, higher PC specifications are required than the minimum requirements.

License

Free License	N/A
Maximum License	Unlimited number of hosts
Increment for Each License	N/A
Optional Combinations	<ol style="list-style-type: none"> Control Center Control Center + Video Wall (1 to 200 license) Control Center + Vital Sign Monitor Control Center + Vital Sign Monitor + Video Wall (1 to 200 license) <p>*No. 3 ~No. 4 are not supported by <i>software licensing</i></p>
License Type	GV-USB dongle or software license

Note:

- To upgrade to V4.0.0 or later, a purchased initial license is required to start GV-Control Center software.**
- The licensing comes in two forms: *GV-USB dongle* and *software license*. The two are incompatible. Before using software licensing, make sure to remove the GV-USB dongle if inserted on the PC.
- GV-USB dongle has two types: Internal and External. Internal dongle is recommended for the Hardware Watchdog function, which restarts the PC when Windows crashes or freezes.
- Software licensing:
 - Not support the following software currently: GV-AI Guard, GV-ASManager, GV-DVR / NVR.
 - Support the following products: GV-AI FR V1.2 or later, GV-Recording Server V2.0 or later, GV-SNVR series, GV-VMS V17.4.2 / V18.3.0 or later, IP devices.

GPU Decoding Specifications

A higher total frame rate can be achieved if your CPU comes with onboard GPU or is connected to external GPU for GPU decoding.

Onboard GPU: GPU decoding is only supported when using the following Intel chipsets:

For **H.264** Video Compression

- 2nd~ 8thGeneration Intel Core i3 / i5 / i7 Desktop Processors
- 9th~ 11thGeneration Intel Core i3 / i5 / i7 / i9 Desktop Processors

For **H.265** Video Compression

- 6th~ 8thGeneration Intel Core i3 / i5 / i7 Desktop Processors
- 9th~ 11thGeneration Intel Core i3 / i5 / i7 / i9 Desktop Processors

External GPU: GPU decoding is only supported when using NVIDIA graphics cards with compute capability 3.0 or above and memory 2 GB or above. To look up the compute capability of the NVIDIA graphics cards, refer to:

<https://developer.nvidia.com/cuda-gpus>

Note:

1. Only one external NVIDIA graphic card can be supported by GV-Control Center to perform GPU decoding for free of charge.
2. GeForce GTX1060 is not supported.

Onboard GPU + External GPU: To have both the onboard and external GPU to perform GPU decoding, the GPUs must follow their respective specifications listed above.

Note:

1. If you have both onboard and external GPUs installed, the onboard GPU must be connected to a monitor for activating H.264 / H.265 GPU decoding.
2. CUDA compute capability 5.0 or higher is required to ensure optimal performance.

Compatible GeoVision Products

- GV-DVR / NVR: V8.5 or later
- GV-VMS: V14.1 or later
- GV-ASManager: V4.3 or later
- GV-Recording Server: V1.4 or later
- GV-AI FR: V1.2 or later
- GV-Live Streaming app: V1.0.2
- GV-SNVR0400F / 1600: FW V1.1 or later; GV-SNVR0411: FW V2.0 or later; GV-SNVR0412: FW V1.13 or late; GV-SNVR0811: FW V2.73 or later; GV-SNVR0812: FW V1.03 or later; GV-SNVR1611: FW V3.03 or later
- GV-VS11 / 12 / 14 / 2400 / 2420 / 2800 / 2820: FW V1.01 or later
- GV-VS2401 / VS21600: FW V1.00 or later

Options

Optional Devices	Description
GV-Keyboard V3 for GV-Control Center	GV-Keyboard V3 is designed to program and operate the GeoVision surveillance system with keyboard and function keys, and can be connected to PTZ cameras directly for PTZ control.
GV-Joystick V2	GV-Joystick V2 facilitates PTZ camera control. It can be either plugged into the GeoVision surveillance system for independent use or connected to GV-Keyboard to empower the operation.
GV-IO Box Series	GV-IO Box series provides 4 / 8 / 16 inputs and relay outputs, and supports both DC and AC output voltages, with optional support for Ethernet module and 4E additionally supporting PoE connection.