

AC POWERED SLIM LINE SMOKE & STROBE LIGHT COMBO ALARM WITH SEALED LITHIUM BATTERY BACKUP

Input: 120V AC ~ 60Hz, 0.8A Alarm

IMPORTANT! PLEASE READ CAREFULLY AND SAVE.

This user's manual contains important information about your Smoke Alarm's operation. To help you install this Smoke Alarm for use or copies of it—with the end user.

Printed in Mexico
M08-0218-190203_K1 08/17

CONFORMS TO
UL STD 217 & UL STD 1971 Model 7020BLSL

© 2017 BRK Brands, Inc. All rights reserved. Distributed by BRK Brands, Inc. • BRK Brands, Inc. is a sound of safety brand. (NYSE:NYSE) First Alert® is a registered trademark of The First Alert Trust. •3901 Liberty Street, Aurora, IL 60504-8122 • Consumer Affairs: (800) 323-9005 •www.firstalarml.com • www.brkellectronics.com

All First Alert® and BRK® Smoke Alarms conform to regulatory requirements, including UL217 and are designed to detect particles of combustion. Smoke particles of varying number and size are produced in all fires.

Ionization technology is generally more sensitive than photoelectric technology at detecting large particles, which tend to be produced in greater amounts by flaming fires, which consume combustible materials rapidly and spread quickly. Sources of these fires may include paper burning in a wastebasket, or a grease fire in the kitchen. Photoelectric technology is generally more sensitive than ionization technology at detecting small particles, which tend to be produced in greater amounts by smoldering fires, which may smolder for hours before bursting into flame. Sources of these fires may include cigarettes burning in couches or bedding.

For maximum protection, use both types of Smoke Alarms on each level of in every bedroom of your home.

INTRODUCTION

Thank you for choosing First Alert® for your Smoke Alarm and hearing impaired strobe light needs. You have purchased a state of the art Smoke and Strobe Light Combo Alarm designed to provide hearing impaired individuals with a visual and audible warning of a fire. When used with additional carbon monoxide and carbon monoxide alarms it will also provide hearing impaired individuals with a visual and audible warning of a carbon dioxide danger. Please take the time to read this manual and make this Smoke and Strobe Light Combo Alarm an integral part of your family's safety plan.

Key Features:

Low Profile Design: Half the size of a standard alarm

177 Candela LED Light: Powerful 177 candela LED strobe light provides effective visual warning to awaken hearing impaired residents.

Strobe Signal Synchronization: Horn and LED syncs with other 7020BLSL family of units.

Smart Interconnection: Helps reduce unwanted alarms

Battery Backup: 10 year sealed battery backup provides backup for the smoke alarm during power outage. (Note: will not power the strobe light).

Quick Mounting Action: Twist/lock mounting bracket automatically activates 10 year battery backup.

End of Life Indicator: Alerts user when alarm requires replacement

Integrated Photoelectric Smoke Alarm and Strobe Light: One device includes both a photoelectric smoke alarm and a strobe light. Requires no wiring. Saves installation time.

Smart Strobe: Works with BRK smoke and CO alarms. Separate flash patterns to distinguish between smoke/heat or CO danger.

1Hz Flash Rate: 60 flashes per minute.

Two Latching Features: Alarm Latch - Visually identifies initiating alarm even after alarm condition is over. Low Battery Latch - Visually identifies when unit is in low battery condition.

Two Silence Features: Temporarily silence low battery chirps for up to eight hours before replacing unit or silence an unwanted alarm for several minutes.

FIRE SAFETY TIPS

Prevent and prevent hazardous situations: 1) Use smoking materials properly. Never smoke in bed. 2) Keep matches or lighters away from children; 3) Store flammable materials in proper containers; 4) Keep electrical appliances in good condition and don't overload electrical circuits; 5) Keep stoves, barbecue grills, toasters and chimneys clean and debris-free; 6) Never leave anything cooking on the stove unattended; 7) Keep portable heaters and open flames, like candles, away from flammable materials; 8) Don't let rubbish accumulate.

Keep alarms clean, and test them weekly. Replace alarms immediately if they are not working properly. Smoke Alarms that do not work cannot alert you to a fire. Keep at least one working fire extinguisher on every floor, and an additional one in the kitchen. Have fire escape ladders, or other reliable means of escape from an upper floor in case stairs are blocked.

BEFORE YOU INSTALL THIS SMOKE AND STROBE LIGHT COMBO ALARM

IMPORTANT! Read "Recommended Locations for Smoke Alarms" and "Locations to Avoid for Smoke Alarms" before beginning. This unit must be installed in a separate, fire rated sensing chamber, it alarms. It can give you more time to escape before fire spreads. This unit can ONLY give an early warning of developing fires if it is installed, maintained and located where smoke can reach it, and where residents can hear it. See details as described in this manual. This unit will not sense gas, heat, or flame. It cannot prevent or extinguish fires.

UNDERSTAND THE DIFFERENT TYPE OF SMOKE ALARMS
Battery powered or electrical? Different Smoke Alarms provide different types of protection. See "About Smoke Alarms" for details.

KNOW WHERE TO INSTALL YOUR SMOKE ALARMS
Fire Safety Professionals recommend at least one Smoke Alarm on every level of your home, in every bedroom, and in every bedroom hallway or separate sleeping area. See "Recommended Locations For Smoke Alarms" and "Locations To Avoid For Smoke Alarms" for details.

KNOW WHAT SMOKE ALARMS CAN AND CAN'T DO
A Smoke Alarm can help alert you to fire, giving you precious time to escape. It can only sound an alarm once smoke reaches the sensor. See "Limitations of Smoke Alarms" for details.

CHECK YOUR LOCAL BUILDING CODES
This Smoke Alarm is designed to be used in a typical single-family home. It alone will not meet requirements for boarding houses, apartment buildings, hotels or motels. See "Special Compliance Considerations" for details.

CAUTION! Electrical shock hazard. Turn off the power to the area where the Smoke Alarm is installed before removing it from the mounting bracket. Failure to turn off the power may result in serious electrical shock, injury or death.

WARNING! Installation of this unit must conform to the electrical codes in your area; Articles 210 and 300, 318) of NFPA 70 (NEC), NFPA 72, NFPA101; SBC (SBC/CCI, UBC (ICBO), NBC (BOCA), OTC (CASI) and any other local or building codes that may apply. Wiring and installation must be performed by a licensed electrician. Failure to follow these guidelines may result in injury or property damage.

This unit must be powered by a 24-hour, 120VAC pure sine wave 60Hz circuit. Be sure the circuit cannot be turned off by a switch, dimmer, or ground fault circuit interrupter. Failure to connect this unit to a 24-hour circuit may prevent it from providing constant protection.

This Alarm must have AC or battery power to operate. If the AC power fails, battery back-up will allow the alarm to sound for at least 4 minutes. If AC power fails and the battery is weak, protection should last for at least 7 days. If AC power fails and the battery is dead or missing, the alarm cannot operate.

Never disconnect the power from an AC powered unit to stop an unwanted alarm. Doing so will disable the unit and remove your protection. In the case of a true unwanted alarm open a window or fan the smoke away from the unit. The alarm will reset automatically when it returns to normal operation. Never remove the batteries from a battery operated unit to stop an unwanted alarm (caused by cooking smoke, etc.). Instead open a window or fan the smoke away from the unit. The alarm will reset automatically.

CAUTION! Connect this unit ONLY to other compatible units. See "How To Install This Alarm" for details. Do not connect it to any other type of alarm or auxiliary device. Connecting anything else to this unit may damage it or prevent it from operating properly.

This Alarm has a sealed lithium battery.

- Do not stand too close to the unit when the alarm is sounding. It is loud to wake you in an emergency. Exposure to the horn at close range may harm your hearing. Do not stare directly into light source. Direct exposure to light may harm eyesight.

Do not paint over the unit. Paint may clog the openings to the sensing chambers and prevent the unit from operating properly.

HOW TO INSTALL THIS ALARM

This Alarm is designed to be mounted on any standard wiring junction box up to a 4-inch (10 cm) size, on either the ceiling or wall (if allowed by local codes). Read "Recommended Locations For Smoke Alarms" and "Locations to Avoid For Smoke Alarms" before you begin installation.

Tools you need: Standard Flathead Screwdriver, Wire Strippers

WARNING! Make sure the Alarm is not receiving excessively noisy power. Examples of noisy power could be major appliances on the same circuit, power from a generator or solar light, dimmer on the same circuit or mounted near fluorescent lighting. Excessively noisy power may cause damage to your Alarm.

THE PARTS OF THIS SMOKE ALARM

The Mounting Bracket:

The mounting bracket installs onto the junction box. It has a vast of screws to fit most boxes.

The Power Connector:

The power connector plugs into a power input block on the Alarm. It supplies the unit with AC power.

If you need to remove the power connector, turn POWER OFF first. Insert a flat screwdriver blade between the power connector and the security tab inside the power input block. Gently pry back the tab and pull the connector free.

The black wire is "hot."

The white wire is neutral.

The orange wire is used for interconnect.

The Parts of This Unit

1. Mounting Bracket
2. Mounting Slots
3. Disable Switch
4. Hot (Black) AC Wire
5. Neutral (White) AC Wire
6. Interconnect (Orange) Wire
7. Quick-Connect Power Connector
8. Turn this way to remove from bracket (Counter-clockwise)
9. Turn this way to attach to bracket (Clockwise)

FOR THESE INSTALLATION STEPS

The basic installation of this Alarm is similar whether you want to install one Alarm, or interconnect more than one Alarm. If you are interconnecting more than one Alarm, you MUST read "Special Requirements For Interconnected Alarms" below before you begin installation.

DANGER! ELECTRICAL SHOCK HAZARD. Turn off the power to the area where you will install this unit at the circuit breaker or fuse box before beginning installation. Failure to turn off the power before installation may result in serious electrical shock, injury or death.

1. Position the screw slots on the mounting bracket over the screws in the junction box. Tighten screws until screw head recesses in mounting bracket. Do not over tighten.

2. Using wire nuts, connect the power connector to the household wiring.

STAND-ALONE ALARM ONLY:

- Connect the white wire on the power connector to the neutral wire in the junction box.
- Connect the black wire on the power connector to the hot wire in the junction box.
- Tuck the orange wire inside the junction box. It is used for interconnect only.

INTERCONNECTED UNITS ONLY: Strip off about 1/2" (12 mm) of the plastic coating on the orange wire on the power connector.

- Connect the white wire on the power connector to the neutral wire in the junction box.
- Connect the black wire on the power connector to the hot wire in the junction box.
- Connect the orange wire on the power connector to the interconnect wire in the junction box. Repeat for each unit you are interconnecting. Never connect the hot or neutral wires in the junction box to the orange interconnect wire. Never cross hot and neutral wires between Alarms.

3. Plug the power connector into the back of the Alarm.

4. Position the base of the Alarm over the mounting bracket and turn. The Alarm can be positioned over the bracket every 90°. Turn the Alarm clockwise (right) until the unit locks into place. If this is the first time turning the Alarm, an activation chirp will be heard.

5. Check all connections.

CAUTION! Electrical shock hazard. Turn off the power to the area where the Smoke Alarm is installed before removing it from the mounting bracket. Failure to turn off the power may result in serious electrical shock, injury or death.

WARNING! Improper wiring of the power connector or the wiring leading to the power connector will cause damage to the Alarm and may lead to a non-functioning Alarm.

STAND-ALONE ALARM ONLY:

- If you are only installing one Alarm, restore power to the junction box.

INTERCONNECTED ALARMS ONLY:

- If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

DANGER! Electrical shock hazard. Do not restore power until all Alarms are completely installed. Restoring power before installation is complete may result in serious electrical shock, injury or death.

6. Make sure your Alarm is receiving AC power. Under normal operation, the Green power indicator light will shine continuously.

7. If the Green power indicator light does not light, TURN OFF POWER TO THE JUNCTION BOX and check all connections. If all connections are correct and the Green power indicator still does not light when you restore the power, the unit should be replaced immediately.

8. Test each Alarm. Press and hold the Test/Silence button until the unit alarms. When testing a series of interconnected units you must test each unit individually. Make sure all units alarm when each one is tested.

DANGER! If you are only installing one Alarm, restore power to the junction box.

WARNING! If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

INTERCONNECTED ALARMS ONLY:

- If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

DANGER! Electrical shock hazard. Do not restore power until all Alarms are completely installed. Restoring power before installation is complete may result in serious electrical shock, injury or death.

6. Make sure your Alarm is receiving AC power. Under normal operation, the Green power indicator light will shine continuously.

7. If the Green power indicator light does not light, TURN OFF POWER TO THE JUNCTION BOX and check all connections. If all connections are correct and the Green power indicator still does not light when you restore the power, the unit should be replaced immediately.

8. Test each Alarm. Press and hold the Test/Silence button until the unit alarms. When testing a series of interconnected units you must test each unit individually. Make sure all units alarm when each one is tested.

DANGER! If you are only installing one Alarm, restore power to the junction box.

WARNING! If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

INTERCONNECTED ALARMS ONLY:

- If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

DANGER! Electrical shock hazard. Do not restore power until all Alarms are completely installed. Restoring power before installation is complete may result in serious electrical shock, injury or death.

6. Make sure your Alarm is receiving AC power. Under normal operation, the Green power indicator light will shine continuously.

7. If the Green power indicator light does not light, TURN OFF POWER TO THE JUNCTION BOX and check all connections. If all connections are correct and the Green power indicator still does not light when you restore the power, the unit should be replaced immediately.

8. Test each Alarm. Press and hold the Test/Silence button until the unit alarms. When testing a series of interconnected units you must test each unit individually. Make sure all units alarm when each one is tested.

DANGER! If you are only installing one Alarm, restore power to the junction box.

WARNING! If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

INTERCONNECTED ALARMS ONLY:

- If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

DANGER! Electrical shock hazard. Do not restore power until all Alarms are completely installed. Restoring power before installation is complete may result in serious electrical shock, injury or death.

6. Make sure your Alarm is receiving AC power. Under normal operation, the Green power indicator light will shine continuously.

7. If the Green power indicator light does not light, TURN OFF POWER TO THE JUNCTION BOX and check all connections. If all connections are correct and the Green power indicator still does not light when you restore the power, the unit should be replaced immediately.

8. Test each Alarm. Press and hold the Test/Silence button until the unit alarms. When testing a series of interconnected units you must test each unit individually. Make sure all units alarm when each one is tested.

DANGER! If you are only installing one Alarm, restore power to the junction box.

WARNING! If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

INTERCONNECTED ALARMS ONLY:

- If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

DANGER! Electrical shock hazard. Do not restore power until all Alarms are completely installed. Restoring power before installation is complete may result in serious electrical shock, injury or death.

6. Make sure your Alarm is receiving AC power. Under normal operation, the Green power indicator light will shine continuously.

7. If the Green power indicator light does not light, TURN OFF POWER TO THE JUNCTION BOX and check all connections. If all connections are correct and the Green power indicator still does not light when you restore the power, the unit should be replaced immediately.

8. Test each Alarm. Press and hold the Test/Silence button until the unit alarms. When testing a series of interconnected units you must test each unit individually. Make sure all units alarm when each one is tested.

DANGER! If you are only installing one Alarm, restore power to the junction box.

WARNING! If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

INTERCONNECTED ALARMS ONLY:

- If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

DANGER! Electrical shock hazard. Do not restore power until all Alarms are completely installed. Restoring power before installation is complete may result in serious electrical shock, injury or death.

6. Make sure your Alarm is receiving AC power. Under normal operation, the Green power indicator light will shine continuously.

7. If the Green power indicator light does not light, TURN OFF POWER TO THE JUNCTION BOX and check all connections. If all connections are correct and the Green power indicator still does not light when you restore the power, the unit should be replaced immediately.

8. Test each Alarm. Press and hold the Test/Silence button until the unit alarms. When testing a series of interconnected units you must test each unit individually. Make sure all units alarm when each one is tested.

DANGER! If you are only installing one Alarm, restore power to the junction box.

WARNING! If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

INTERCONNECTED ALARMS ONLY:

- If you are interconnecting multiple Alarms, repeat steps 1-5 for each Alarm in the series. When you are finished, restore power to the junction box.

DANGER! Electrical shock hazard. Do not restore power until all Alarms are completely installed. Restoring power before installation is complete may result in serious electrical shock, injury or death.

REGULAR MAINTENANCE

WARNING! This unit has been designed to be a maintenance-free as possible, but there is a few simple things you should do to keep it working properly.

- Test it at least once a week.
- Clean the Alarm at least once a month; gently vacuum the outside of the Alarm using your household vacuum's soft brush attachment. Test the Alarm. Never use water, cleaners or solvents since they may damage the unit.
- If the Alarm becomes contaminated by excessive dirt, dust and/or grime, and cannot be cleaned to avoid unwanted alarms, replace the unit immediately.
- Relocate the unit if it sounds frequent unwanted alarms. See "Locations To Avoid For Smoke Alarms." If you press the Test/Silence on any other Alarm, it will only silence that unit, not the whole interconnected series.
- When the battery back-up becomes weak, the Alarm will "chirp" about once a minute (the low battery warning). This warning should last 7 days, but you should replace the unit immediately to continue your protection.

CAUTION! If the strobe light lens is loose or broken, the entire unit should be replaced immediately. Never attempt to clean the light lens. For any reason, Doing so can permanently damage the unit and will void your warranty.

IMPORTANT! Actual battery service life depends on the alarm and the environment in which it is installed.

WEEKLY TESTING

WARNING! NEVER use an open flame of any kind to test this unit. You might accidentally damage or set fire to the unit or to your home. The built-in test switch operates every 15 seconds. It will continue to flash or "chirp" if testing the alarm.

- If the Alarm ever fails to test properly, replace it immediately. Products under warranty may be returned to the manufacturer for replacement. See "Limited Warranty" at the end of this manual.

It is important to test this unit every week to make sure it is working properly. Using the test button is the recommended way to test this Alarm. Press and hold the Test/Silence button on the front of the unit until the alarm sounds (the unit may continue to alarm for a few seconds after you release the button). If it does not alarm, make sure the unit is receiving power and test it again. If it still does not alarm, replace it immediately. During testing, you will hear a loud, 3 beeps, pause, 3 beeps again. The strobe light will begin flashing.

When testing a series of interconnected units you must test each unit individually. Make sure all units alarm when each one is tested.

Note: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

CAUTION! If you have interconnected this alarm with a BRK combination smoke & carbon monoxide alarm, when you test that alarm you will hear a loud continuous beeping sound and the strobe light will flash constant approximately 1 flash per second. Then you will hear a loud repeating horn pattern from this alarm: 4 rapid beeps, pause, 4 rapid beeps, pause and the strobe light will flash approximately 1 flash per second for four flashes, then 3 seconds off. The pattern is repeated.

NOTE: If you have interconnected this alarm with a BRK carbon monoxide alarm, when you test that alarm you will hear a loud repeating horn pattern from this alarm

