

# GV-PoE Switch

---

## *GV-APOE4813 User's Manual*





© 2023 GeoVision, Inc. All rights reserved.

Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of GeoVision.

Every effort has been made to ensure that the information in this manual is accurate. GeoVision, Inc. makes no expressed or implied warranty of any kind and assumes no responsibility for errors or omissions. No liability is assumed for incidental or consequential damages arising from the use of the information or products contained herein. Features and specifications are subject to change without notice.

GeoVision, Inc.  
9F, No. 246, Sec. 1, Neihu Rd.,  
Neihu District, Taipei, Taiwan  
Tel: +886-2-8797-8377  
Fax: +886-2-8797-8335  
<http://www.geovision.com.tw>

Trademarks used in this manual: *GeoVision*, the *GeoVision* logo and *GV* series products are trademarks of GeoVision, Inc. *Windows* is the registered trademark of Microsoft Corporation.

July 2023

**Scan the following QR codes for product warranty and technical support policy:**



[Warranty]



[Technical Support Policy]

# Content

Getting Start.....	1
Web-based Switch Configuration .....	5
Console Port Interface.....	6
1. Switch basic configuration.....	7
1.1. Switch basic configuration .....	7
<b>1.1.1. Login user configuration</b> .....	7
<b>1.1.2. Login user authentication method configuration</b> .....	7
<b>1.1.3. Login user Security IP management</b> .....	8
<b>1.1.4. Basic configuration</b> .....	9
<b>1.1.5. Save current running-configuration</b> .....	10
1.2. SNMP authentication .....	10
<b>1.2.1. SNMP authentication</b> .....	10
<b>1.2.1.1. Users</b> .....	10
<b>1.2.1.2. Groups</b> .....	11
<b>1.2.1.3. Views</b> .....	12
<b>1.2.1.4. SNMP engineid configuration</b> .....	12
<b>1.2.2. SNMP management</b> .....	13
<b>1.2.3. Community managers</b> .....	13
<b>1.2.4. Configure snmp manager security IP</b> .....	14
<b>1.2.5. SNMP statistics</b> .....	14
1.3. SSH management.....	15
<b>1.3.1. Switch on-off SSH</b> .....	15
<b>1.3.2.SSH management</b> .....	15
1.4. Firmware update.....	16
<b>1.4.1. TFTP service</b> .....	16
<b>1.4.1.1. TFTP client service</b> .....	16
<b>1.4.1.2. TFTP server service</b> .....	16
<b>1.4.2. FTP service</b> .....	17
<b>1.4.2.1. FTP client service</b> .....	17
<b>1.4.2.2. FTP server service</b> .....	17
<b>1.4.3. HTTP service</b> .....	18
<b>1.4.3.1. HTTP Upgrade</b> .....	18
<b>1.4.3.2. HTTP Configuration</b> .....	19
1.5. Telnet server configuration .....	20
<b>1.5.1. Telnet server state</b> .....	20
<b>1.5.2. Max numbers of telnet access connection</b> .....	20
1.6. Maintenance and debugging command .....	21
<b>1.6.1. Debug command</b> .....	21
<b>1.6.2. Show clock</b> .....	21
<b>1.6.3. Show CPU usage</b> .....	22
<b>1.6.4. Show memory usage</b> .....	22

1.6.5. Show flash .....	22
1.6.6. Show running-config .....	22
1.6.7. Show switchport interface.....	23
1.6.8. Show TCP .....	23
1.6.9. Show UDP .....	23
1.6.10. Show telnet login .....	23
1.6.11. Show version .....	24
1.7. RMON.....	25
1.7.1. RMON statistics.....	25
1.7.2. RMON history.....	25
1.7.3. RMON alarm .....	26
1.7.4. RMON event.....	27
2. Module management .....	28
2.1. Show boot-files .....	28
2.2. Set Boot IMG and Startup-Config .....	28
3. Port configuration.....	29
3.1. Ethernet port configuration .....	29
3.1.1. Port layer 1 attribution configuration .....	29
3.1.2. Bandwidth control configuration.....	31
3.1.3. Switchport description .....	32
3.1.4. Port combo forced mode config.....	33
3.1.5. Port 10G mode .....	34
3.1.6. Port scan mode .....	35
3.2. VLAN interface configuration .....	35
3.2.1. Add interface VLAN .....	35
3.2.2. L3 interface IP address mode configuration .....	36
3.3. SPAN configuration .....	37
3.4. Loopback-detection configuration .....	40
3.4.1. Port Loopback-detection mode configuration.....	40
3.4.2. VLAN Loopback-detection configuration.....	41
3.4.3. Loopback-detection interval-time configuration.....	42
3.4.4. Loopback-detection control recovery configuration .....	43
3.5. Isolate-port configuration .....	43
3.5.1. Isolate-port group configuration.....	43
3.5.2. Interface join group config .....	44
3.5.3. show Isolate-port group.....	44
3.6. Port storm-control config.....	45
3.6.1. Port storm-control config .....	45
3.6.2. storm-control bypass configuration.....	46
3.7. Port rate-violation config .....	47
3.7.1. rate-violation configuration.....	47
3.8. Port virtual-cable-test config .....	47
3.8.1. virtual-cable-test configuration.....	48

3.9. Port debug and maintenance.....	48
<b>3.9.1. Show port information</b> .....	48
<b>3.9.2. Show entire traffic information</b> .....	49
<b>3.9.3. Show rate violation port</b> .....	49
3.10. uldp configuration.....	50
<b>3.10.1. uldp enable config</b> .....	50
<b>3.10.2. uldp Hello message config</b> .....	51
<b>3.10.3. uldp recovery time config</b> .....	51
<b>3.10.4. show uldp configuration</b> .....	52
3.11. LLDP configuration .....	52
<b>3.11.1. LLDP configuration</b> .....	52
<b>3.11.2. LLDP port status config</b> .....	53
<b>3.11.3. LLDP tx-interval config</b> .....	54
<b>3.11.4. LLDP msgTxHold config</b> .....	54
<b>3.11.5. LLDP transmit delay config</b> .....	55
<b>3.11.6. LLDP notification interval config</b> .....	55
<b>3.11.7. LLDP neighbors max-num config</b> .....	56
<b>3.11.8. LLDP too many neighbors config</b> .....	56
<b>3.11.9. LLDP transmit optional tlv config</b> .....	57
<b>3.11.10. show LLDP configuration</b> .....	58
3.12. LED shutoff configuration .....	60
<b>3.12.1. Time Range configuration</b> .....	60
<b>3.12.2. LED shutoff config</b> .....	61
3.13. Jumbo packet forwarding configuration .....	62
4. MAC address table configuration .....	63
4.1. MAC address table configuration.....	63
<b>4.1.1. MAC address aging-time configuration</b> .....	63
<b>4.1.2. Configure MAC address</b> .....	63
<b>4.1.3. Delete MAC address</b> .....	65
<b>4.1.4. MAC address query</b> .....	65
5. VLAN configuration.....	67
5.1. VLAN configuration .....	67
<b>5.1.1. Create/Remove VLAN</b> .....	67
<b>5.1.2. Assign ports for VLAN</b> .....	68
<b>5.1.3. Port type configuration</b> .....	69
<b>5.1.4. Hybrid port configuration</b> .....	69
<b>5.1.5. Trunk port configuration</b> .....	71
<b>5.1.6. Private-vlan configuration</b> .....	72
5.2. GVRP configuration .....	73
<b>5.2.1. Enable global GVRP</b> .....	73
<b>5.2.2. Enable GVRP on port</b> .....	73
<b>5.2.3. GARP configuration</b> .....	73
5.3. VLAN-translation configuration .....	74

<b>5.3.1. Enable/Disable VLAN-translation</b> .....	74
<b>5.3.2. Add/Delete VLAN-translation</b> .....	75
<b>5.3.3. VLAN-translation miss drop configuration</b> .....	75
<b>5.3.4. show VLAN-translation</b> .....	76
5.4. dynamic VLAN configuration.....	77
<b>5.4.1. VLAN protocol configuration</b> .....	77
5.5. Dot1q tunnel configuration .....	78
<b>5.5.1.Enable dot1q tunnel</b> .....	78
<b>5.5.2. dot1q tunnel tpid configuration</b> .....	78
6. IGMP Snooping configuration.....	80
6.1. Switch on-off IGMP Snooping.....	80
6.2. IGMP Snooping port enable.....	80
6.3. IGMP Snooping configuration .....	81
6.4. IGMP Snooping mrouter port configuration.....	82
6.5. IGMP Snooping query configuration.....	82
7. MLD Snooping configuration.....	84
7.1. Switch on-off MLD Snooping .....	84
7.2. MLD Snooping port enable .....	84
7.3. MLD Snooping configuration .....	85
7.4. MLD Snooping mrouter port configuration .....	86
7.5. MLD Snooping query configuration .....	86
8. Time Range configuration .....	88
8.1. Time Range configuration .....	88
9. ACL configuration.....	89
9.1. Numeric ACL.....	89
<b>9.1.1. Standard numeric ACL</b> .....	89
<b>9.1.1.1. IP standard ACL</b> .....	89
<b>9.1.1.2. MAC standard ACL</b> .....	89
<b>9.1.2. Extended numeric ACL</b> .....	90
<b>9.1.2.1. IP extended ACL</b> .....	90
<b>9.1.2.2. MAC-IP extended ACL</b> .....	91
<b>9.1.3. Delete Numeric ACL</b> .....	93
9.2. Name ACL.....	94
<b>9.2.1. Standard name ACL</b> .....	94
<b>9.2.1.1. IP standard ACL</b> .....	94
<b>9.2.2. Extended name ACL</b> .....	94
<b>9.2.2.1. IP extended ACL</b> .....	94
<b>9.2.2.2. MAC extended ACL</b> .....	96
<b>9.2.2.3. MAC-IP extended ACL</b> .....	97
<b>9.2.3. Delete Name ACL</b> .....	99
9.3. Filter configuration.....	100
<b>9.3.1. Firewall configuration</b> .....	100
9.4. Show ACL configuration .....	100

<b>9.4.1. Show access list</b> .....	100
<b>9.4.2. Show firewall</b> .....	100
<b>9.4.3. Show time range</b> .....	101
9.5. ACL binding configuration .....	101
<b>9.5.1. Attach ACL to port</b> .....	101
<b>9.5.2. Show access group</b> .....	101
<b>9.5.3. Clear Pacl Statistic</b> .....	102
<b>9.5.4. Attach ACL to vlan</b> .....	102
<b>9.5.5. show vacl configuration</b> .....	103
<b>9.5.6. clear vlan acl statistic</b> .....	103
10. IPv6 ACL configuration .....	104
10.1. IPv6 standard access-list configuration .....	104
10.2. IPv6 name access-list configuration .....	104
10.3. Show IPv6 access list .....	105
10.4. Attach IPv6 ACL to port .....	105
10.5. Attach IPv6 ACL to vlan .....	106
11. AM configuration .....	107
11.1. AM global configuration .....	107
<b>11.1.1. Enable/Disable AM</b> .....	107
11.2. AM port configuration .....	107
<b>11.2.1. Enable/Disable AM port</b> .....	107
<b>11.2.2. AM IP-Pool configuration</b> .....	107
<b>11.2.3. AM MAC-IP-Pool configuration</b> .....	108
11.3. Show AM port configuration .....	108
<b>11.3.1. Show AM port configuration</b> .....	108
<b>11.3.2. Clear port AM Pool</b> .....	109
12. Port channel configuration .....	110
12.1. LACP port group configuration .....	110
12.2. Delete port group .....	111
12.3. Show port group info .....	112
12.4. Show interface port-channel .....	113
12.5. Add member port .....	113
12.6. Del member port .....	114
12.7. Set lacp port priority .....	114
12.8. Set lacp system priority .....	115
13. DHCP configuration .....	116
13.1. DHCP management .....	116
<b>13.1.1. Enable DHCP</b> .....	116
13.2. DHCP server configuration .....	117
<b>13.2.1. Dynamic pool configuration</b> .....	117
<b>13.2.1.1. Dynamic address pool configuration</b> .....	117
<b>13.2.1.2. Client's default gateway configuration</b> .....	118
<b>13.2.1.3. Client DNS server configuration</b> .....	119

13.2.1.4. Client WINS server configuration .....	120
13.2.1.5. DHCP file server address configuration .....	121
13.2.1.6. DHCP network parameter configuration .....	122
13.2.1.7. Excluded address configuration .....	123
13.2.2. Manual DHCP IP pool configuration .....	124
13.2.2.1. Static address pool configuration .....	124
13.2.3. Address pool name configuration .....	125
13.2.4. DHCP packet statistics .....	126
13.3. DHCP relay configuration .....	126
13.3.1. DHCP relay configuration .....	126
13.4. DHCP debugging .....	127
13.4.1. Delete record .....	127
13.4.1.1. Delete binding log .....	127
13.4.1.2. Delete conflict log .....	128
13.4.1.3. Delete DHCP server statistics log .....	128
13.4.2. Show IP-MAC binding .....	128
13.4.3. Show conflict-logging .....	129
14. DHCP Snooping configuration .....	130
14.1. DHCP Snooping global configuration .....	130
14.1.1. Enable/Disable DHCP Snooping .....	130
14.1.2. DHCP Snooping binding configuration .....	130
14.1.3. DHCP Snooping binding user configuration .....	130
14.1.4. DHCP Snooping action count config .....	131
14.1.5. DHCP Snooping limit-rata config .....	132
14.1.6. DHCP Snooping helper-server config .....	132
14.2. DHCP Snooping port configuration .....	133
14.2.1. Enable/Disable DHCP Snooping binding dot1x .....	133
14.2.2. Enable/Disable DHCP Snooping binding user .....	134
14.2.3. Enable/Disable DHCP Snooping trust .....	135
14.2.4. DHCP Snooping action config .....	136
14.3. Show DHCP Snooping configuration .....	137
14.3.1. Show DHCP Snooping configuration .....	137
15. SNTP configuration .....	138
15.1. SNTP server configuration .....	138
15.2. Request interval configuration .....	138
15.3. Time difference configuration .....	139
15.4. Show SNTP .....	139
16. NTP configuration .....	140
16.1. NTP global configuration .....	140
16.1.1. NTP global switch configuration .....	140
16.1.2. NTP server configuration .....	140
16.1.3. NTP broadcast or multicast address count configuration .....	140

<b>16.1.4. NTP access group configuration</b> .....	141
<b>16.1.5. NTP authenticate configuration</b> .....	141
16.2. NTP interface configuration .....	142
<b>16.2.1. NTP interface switch configuration</b> .....	142
16.3. NTP configuration display .....	142
<b>16.2.1. NTP status display</b> .....	142
17. QOS configuration .....	143
17.1. QOS port configuration .....	143
<b>17.1.1. QOS port trust state configuration</b> .....	143
<b>17.1.2. QOS port COS parameters configuration</b> .....	143
<b>17.1.3. QOS port select queue schedule algorithm configuration</b> .....	144
<b>17.1.4. QOS port wrr algorithm queue weight configuration</b> ....	145
<b>17.1.5. QOS port wdr algorithm queue weight configuration</b> ..	146
<b>17.1.6. QOS service policy configuration</b> .....	147
17.2. QOS class-map configuration .....	147
<b>17.2.1. Class map-configuration</b> .....	147
<b>17.2.2. Classification criteria configuration</b> .....	148
17.3. QoS policy configuration .....	152
<b>17.3.1. QoS policy configuration</b> .....	152
17.4. QOS policy-map configuration .....	153
<b>17.4.1. Policy-map configuration</b> .....	153
<b>17.4.2. Class-map use to policy-map config</b> .....	153
17.5. QoS policy-class-map configuration.....	154
<b>17.5.1. Policy-class-map accounting configuration</b> .....	154
<b>17.5.2. Aggregate policy configuration</b> .....	155
<b>17.5.3. Policy-class-map policy configuration</b> .....	156
<b>17.5.4. Policy-class-map set configuration</b> .....	157
17.6. QoS mapping configuration .....	158
<b>17.6.1. COS-to-IntP mapping</b> .....	158
<b>17.6.2. COS-to-DP mapping</b> .....	159
<b>17.6.3. DSCP-to-DSCP mapping</b> .....	159
<b>17.6.4. DSCP-to-IntP mapping</b> .....	160
<b>17.6.5. DSCP-to-DP mapping</b> .....	161
<b>17.6.6. EXP-to-IntP mapping</b> .....	162
<b>17.6.7. EXP-to-DP mapping</b> .....	163
<b>17.6.8. IntP-to-DSCP mapping</b> .....	163
<b>17.6.9. IntP-to-EXP mapping</b> .....	164
17.7. QoS aggregate policy configuration .....	164
17.8. QoS service policy configuration.....	165
18. L3 forward configuration .....	166
18.1. IP route Aggregation configuration.....	166
<b>18.1.1. Route aggregate configuration</b> .....	166

18.2. ARP configuration .....	166
<b>18.2.1. ARP configuration</b> .....	166
<b>18.2.2. Clear ARP cache</b> .....	167
<b>18.2.3. Show ARP</b> .....	167
18.3. Gratuitous arp config .....	168
<b>18.3.1. gratuitous-arp interval time configuration</b> .....	168
<b>18.3.2. interface gratuitous-arp interval time configuration</b> .....	168
<b>18.3.3. show gratuitous-arp configuration</b> .....	169
18.4. ARP protection configuration.....	169
<b>18.4.1. ARP GUARD configuration</b> .....	169
18.4.1.1. ARP GUARD configuration .....	169
<b>18.4.2. ANTI-ARPSCAN configuration</b> .....	169
<b>18.4.2.3. ANTI-ARPSCAN IP-based threshold configuration</b> .....	171
<b>18.4.2.4. ANTI-ARPSCAN trust port configuration</b> .....	172
<b>18.4.2.5. ANTI-ARPSCAN trust IP configuration</b> .....	172
<b>18.4.2.6. ANTI-ARPSCAN recovery on-off configuration</b> ....	173
<b>18.4.2.7. ANTI-ARPSCAN recovery time configuration</b> .....	173
<b>18.4.2.8. Show ANTI-ARPSCAN information</b> .....	174
18.5. Show IP Traffic.....	174
19. Route configuration .....	175
19.1. Policy based routing.....	175
19.2. Static route configuration .....	175
<b>19.2.1. Static route configuration</b> .....	175
20. IPv6 Route configuration .....	176
20.1. IPv6 configuration .....	176
<b>20.1.1. IPv6 basic configuration</b> .....	176
<b>20.1.2. IPv6 ND configuration</b> .....	177
<b>20.1.3. Show IPv6 neighbor</b> .....	179
20.2. Show IPv6 route .....	180
<b>20.2.1. Show IPv6 route database</b> .....	180
<b>20.2.2. Show IPv6 NSM route</b> .....	181
<b>20.2.3. Show IPv6 FIB</b> .....	182
<b>20.2.4. Show IPv6 route statistics</b> .....	185
21. DCSCM configuration .....	186
21.1. DCSCM Source-control enable/disable configuration .....	186
21.2. DCSCM destination-control enable/disable configuration .....	186
21.3. DCSCM Source-control access-group configuration .....	187
21.4. DCSCM destination-control access-group configuration .....	187
21.5. DCSCM destination-control access-group configuration(sip).....	188
21.6. DCSCM destination-control access-group configuration(vMAC).....	189
21.7. Multicast policy configuration .....	190
21.8. ACL multicast source control .....	190

22. Spanning-tree configuration.....	193
22.1. Spanning-tree field configuration .....	193
<b>22.1.2. Field name configuration</b> .....	194
<b>22.1.3. Revision-level configuration</b> .....	194
22.2. Spanning-tree Port configuration .....	195
<b>22.2.1. PortFast configuration</b> .....	195
<b>22.2.2. Port priority configuration</b> .....	196
<b>22.2.3. Port cost configuration</b> .....	196
<b>22.2.4. Spanning-tree port mode</b> .....	197
<b>22.2.5. Link-type configuration</b> .....	197
<b>22.2.6. Spanning-tree agreement port configuration</b> .....	199
22.3. Spanning-tree global configuration .....	199
<b>22.3.1. Spanning-tree global agreement port configuration</b> .....	199
<b>22.3.2. Forward-time configuration</b> .....	200
<b>22.3.3. Hello-time configuration</b> .....	200
<b>22.3.4. Max age time configuration</b> .....	201
<b>22.3.5. Max hop time configuration</b> .....	202
<b>22.3.6. Spanning tree mode configuration</b> .....	203
<b>22.3.7. Spanning tree cost-format configuration</b> .....	203
<b>22.3.8. Priority configuration</b> .....	204
22.4. Show spanning-tree .....	204
<b>22.4.1. Instance information</b> .....	204
<b>22.4.2. Revision-Level information</b> .....	205
23. MRPP configuration .....	206
23.1. MRPP global configuration.....	206
<b>23.1.1. MRPP global switch configuration</b> .....	206
<b>23.1.2. MRPP poll time configuration</b> .....	206
<b>23.1.3. MRPP domain id configuration</b> .....	207
23.2. MRPP port configuration .....	208
<b>23.2.1. MRPP port property configuration</b> .....	208
23.3. MRPP domain configuration .....	209
<b>23.3.1. MRPP control vlan config</b> .....	209
<b>23.3.2. MRPP node mode config</b> .....	210
<b>23.3.3. MRPP hello timer config</b> .....	210
<b>23.3.4. MRPP fail timer config</b> .....	211
<b>23.3.5. MRPP domain switch config</b> .....	212
23.4. MRPP configuration display .....	213
<b>23.4.1. MRPP display</b> .....	213
<b>23.4.2. MRPP statistics display</b> .....	213
<b>23.4.3. Clear MRPP statistics</b> .....	214
24. ULPP configuration .....	215
24.1. ULPP global configuration.....	215
<b>24.1.1. ULPP group configuration</b> .....	215

24.2. ULPP port configuration .....	215
<b>24.2.1. ULPP port property configuration</b> .....	215
24.3. ULPP group configuration .....	216
<b>24.3.1. ULPP group description configuration</b> .....	216
<b>24.3.2. ULPP group property configuration</b> .....	217
24.4. ULPP configuration display .....	219
<b>24.4.1. ULPP group configuration display</b> .....	219
<b>24.4.2. ULPP port statistics display</b> .....	219
<b>24.4.3. ULPP port property display</b> .....	219
<b>24.4.4. ULPP port statistics clear</b> .....	221
25. ULSM configuration .....	222
25.1. ULSM global configuration .....	222
<b>25.1.1. ULSM group configuration</b> .....	222
25.2. ULSM port configuration .....	222
<b>25.2.1. ULSM port property configuration</b> .....	222
25.3. ULSM configuration display .....	224
<b>25.3.1. ULSM display</b> .....	224
26. Authentication configuration .....	225
26.1. RADIUS client configuration .....	225
<b>26.1.1. RADIUS global configuration</b> .....	225
<b>26.1.2. RADIUS authentication configuration</b> .....	225
<b>26.1.3. RADIUS accounting configuration</b> .....	226
26.2. TACACS server configuration .....	227
<b>26.2.1. TACACS global configuration</b> .....	227
<b>26.2.2. TACACS server host configuration</b> .....	227
26.3. 802.1x configuration .....	228
<b>26.3.1. 802.1x Global configuration</b> .....	228
<b>26.3.2. 802.1x port authentication configuration</b> .....	229
<b>26.3.3. 802.1x port MAC configuration</b> .....	229
<b>26.3.4. 802.1x port status list</b> .....	230
26.4. MAB configuration .....	230
<b>26.4.1. MAB ENABLE configuration</b> .....	230
<b>26.4.2. MAB Authentication configuration</b> .....	231
<b>26.4.3. MAB parameter configuration</b> .....	231
<b>26.4.4. MAB show</b> .....	233
27. PoE Config .....	234
27.1. PoE Global Config .....	234
<b>27.1.1 PoE Global Config</b> .....	234
27.2 PoE Port Config .....	235
<b>27.2.1 PoE Port Config</b> .....	235
28. DOS attack protection configuration .....	237
28.1. Source IP equal destination IP DOS attack protection configuration .....	237
28.2. Source port equal destination port DOS attack protection configuration .....	237

28.3. TCP DOS attacks on invalid flags configuration .....	238
28.4. ICMP DOS attack protection configuration .....	238
28.5. ICMP packet-size configuration .....	238
28.6. First fragment IP packet DOS attack protection configuration .....	239
29. SSL config .....	240
29.1. IP HTTP server configuration .....	240
29.2. SSL global configuration .....	240
29.3. SSL server monitor port configuration .....	241
29.4. SSL secure-ciphersuite configuration .....	241
30. sFlow configuration .....	242
30.1. sFlow collector global address configuration .....	242
30.2. sFlow collector port address configuration .....	242
30.3. sFlow agent address configuration .....	243
30.4. sFlow priority configuration .....	243
30.5. sFlow header length configuration .....	244
30.6. sFlow data length configuration .....	245
30.7. sFlow rate configuration .....	245
30.8. sFlow counter interval configuration .....	246
30.9. sFlow analyzer configuration .....	246
31. IPv6 security ra configuration .....	248
31.1. IPv6 security ra global configuration .....	248
31.2. IPv6 security ra port configuration .....	248
31.3. show IPv6 security ra .....	249
32. Device log message .....	250
32.1. Show device log message .....	250
32.2. Clear logging in logbuff channel .....	250
33. ONVIF configuration .....	251
33.1. ONVIF server config .....	251
33.2. ONVIF detect config .....	251
Appendix: DHCP Settings .....	252

## Getting Start

This section provides an introduction to the web-based configuration utility, and covers the following topics:

- Powering on the device
- Connecting to the network
- Starting the web-based configuration utility

### ● Power



Power down and disconnect the power cord before servicing or wiring a switch.



Do not disconnect modules or cabling unless the power is first switched off. The device only supports the voltage outlined in the type plate. Do not use any other power components except those specifically designated for the switch.



Disconnect the power cord before installation or cable wiring.

The switch is powered by the AC 100-240 V 50/60Hz internal high-performance power supply. It is recommended to connect the switch with a single-phase three-wire power source with a neutral outlet, or a multifunctional computer professional source.

Connect the AC power connector on the back panel of the switch to the external power source with the included power cord, and check the power LED is on.



Rear View AC Power Socket

## ● Connecting to the Network

To connect the switch to the network:

1. Connect an Ethernet cable to the Ethernet port of a computer.
2. Connect the other end of the Ethernet cable to one of the numbered Ethernet ports of the switch. The LED of the port lights if the device connected is active.
3. Repeat Step 1 and Step 2 for each device to connect to the switch.



We strongly recommend using CAT-5E or better cable to connect network devices. When connecting network devices, do not exceed the maximum cabling distance of 100 meters (330 feet). It can take up to one minute for attached devices or the LAN to be operational after it is connected. This is normal behavior.

Connect the switch to end nodes using a standard Cat 5/5e Ethernet cable (UTP/STP) to connect the switch to end nodes as shown in the illustration below.

Switch ports will automatically adjust to the characteristics (MDI/MDI-X, speed, duplex) of the device to which the switch is connected.

## ● Starting the Web-based Configuration Utility

This section describes how to navigate the web-based switch configuration utility. Be sure to disable any pop-up blocker.

### Browser Restrictions

- If you are using older versions of Internet Explorer, you cannot directly use an IPv6 address to access the device. You can, however, use the DNS (Domain Name System) server to create a domain name that contains the IPv6 address, and then use that domain name in the address bar in place of the IPv6 address.
- If you have multiple IPv6 interfaces on your management station, use the IPv6 global address instead of the IPv6 link local address to access the device from your browser.

### Launching the Configuration Utility

To open the web-based configuration utility:

1. Open a Web browser.



2. Enter the IP address of the device you are configuring in the address bar on the browser (factory default IP address is 192.168.2.1) and then press Enter.



When the device is using the factory default IP address, its power LED flashes continuously. When the device is using a DHCP assigned IP address or an administrator-configured static IP address, the power LED is lit a solid color. Your computer's IP address must be in the same subnet as the switch. For example, if the switch is using the factory default IP address, your computer's IP address can be in the following range: 192.168.2.x (whereas x is a number from 2 to 254).

After a successful connection, the login window displays.

GeoVision Inc.

USERNAME

PASSWORD

Login In

Copyright © 2023 Geovision Inc. All Rights Reserved

Login Window


## ● Logging In

The default username is admin and the default password is admin. The first time that you log in with the default username and password, you are required to enter a new password.

To log in to the device configuration utility:

1. Enter the default user ID (admin) and the default password (admin).
2. If this is the first time that you logged on with the default user ID (admin) and the default password (admin), it is recommended that you change your password immediately.

When the login attempt is successful, the System Information window displays.



System Information

If you enter an incorrect username or password, an error message appears and the Login page remains displayed on the window. If you are having problems logging in, please see the Launching the Configuration Utility section for additional information.

## ● Logging Out

By default, the application logs out after ten minutes of inactivity.


To log out, click Logout in the top right corner of any page. The system logs out of the device.

When a timeout occurs or you intentionally log out of the system, a message appears and the Login page appears, with a message indicating the logged-out state. After you log in, the application returns to the initial page.

## Web-based Switch Configuration

The smart switch software provides rich Layer 3 functionality for switches in your networks. This chapter describes how to use the web-based management interface (Web UI) to configure the switch's features.


For the purposes of this manual, the user interface is separated into four sections, as shown in the following figure:




## Console Port Interface

The PoE smart switch has a monitor port (Console port). Rate 9600bps, standard RJ-45 plug.

Use a dedicated monitoring cable to lead the port to the PC serial port connection, as follows:



The RJ-45 connector used by the Console port is shown in the figure below, and the RJ-45 plug corresponds to the RJ-45 socket, from left to right numbered from 1 to 8.



This cable is used to connect the console port of the switch to the external monitoring terminal. One end of the RJ-45 eight-pin plug, the other end is a 25-hole plug (DB25) and 9-hole plug (DB9), RJ-45 head into the switch's console port socket, DB25 and DB9 can be used according to the requirements of the terminal serial port, the cable internal connection schematic as follows:

	RJ45	<===>	DB9		
[	RTS 1	~	8	CTS	]
[	DTR 2	~	6	DSR	]
[	TXD 3	~	2	RXD	]
[	GND 4	~	5	GND	]
[	GND 5	~	5	GND	]
[	RXD 6	~	3	TXD	]
[	DSR 7	~	4	DTR	]
[	CTS 8	~	7	RTS	]

# 1 Switch basic configuration

## 1. Switch basic configuration

### 1.1. Switch basic configuration

#### 1.1.1. Login user configuration

Login user management module, users in this module can add or delete user operations.

Login username and password configuration	
User	<input type="text"/>
Password	<input type="text"/> <input type="checkbox"/> Encrypted text
Priority	<input type="text"/>
Operation	Remove ▼
<input type="button" value="Apply"/>	

User			
User name	Password	State	Priority
admin	admin	Plain text	15

<b>User</b>	User name to operate ,1-32 characters	
<b>Password</b>	User password, choose the password encryption, otherwise no encryption of 1-32 characters	
<b>Priority</b>	Used to specify permission level, default level 15	
<b>Operation</b>	Add	Create new users
	Remove	Delete the specified user (password and priority cannot be entered)

#### 1.1.2. Login user authentication method configuration

Login user authentication method configuration module, the user can configure console/vty/web authentication method used in login, authentication method can be any one or combination of Local.RADIUS and TACACS.preferences from left to right when the login method is combined configuration. If the user has passed the authentication method, the authentication method of the lower preference is ignored. As long as you pass an authentication method, the user can log in.AAA functions and RADIUS servers should be configured before using RADIUS authentication. If local authentication is configured without configuring a local user, the user will be able to log on to the switch through the console method.

Login user authentication method configuration	
Login method	Console ▾
Authentication method1	None ▾
Authentication method2	None ▾
Authentication method3	None ▾
<input type="button" value="Apply"/> <input type="button" value="Default"/>	

Login user authentication method				
Login method	Authentication method1	Authentication method2	Authentication method3	
console	None	None	None	None
vty	local	None	None	None
web	local	None	None	None

Login method	Authentication method	
<b>console</b>	<b>local</b>	Authentication using the local user account database
<b>vty</b>	<b>radius</b>	Authentication using remote Radius server
<b>web</b>	<b>TACACS</b>	Authentication using remote TACAS server
<b>Default</b>		Default console no authentication, vty and web local authentication

### 1.1.3. Login user Security IP management

Login user security IP configuration module, where users can configure the security IP. IPv6 address for login switch, or configure access control list.

Login user Security IP Set	
Security IP address	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

Login Access control list Set	
Ipv4 access control list ▾	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

Login user Security IPv4 List
end of security IPv4
Login user Security IPv6 List
end of security IPv6
Login Ipv4 access control list
end of ipv4 access list
Login Ipv6 access control list
end of ipv6 access list

## 1 Switch basic configuration

<b>Security IP address</b>	Fill in the specified security IP or IPv6 address (the access control list is valid until the IPv6 address is filled in)	
<b>IPv4/IPv6access control list</b>	Standard access control list number, scope 1-64	
<b>Operation</b>	Add	Add address or list number
	Remove	Delete address or list number

### 1.1.4. Basic configuration

Basic configuration module, in which users can configure switch current time, exit privilege mode timeout and switch name respectively.

Basic clock configuration		
HH:MM:SS	<input type="text"/>	<input type="text"/>
YYYY.MM.DD	<input type="text"/>	<input type="text"/>
Apply		

Configure exec timeout		
Timeout(minute)	<input type="text"/>	<input type="text"/>
Timeout(second)	<input type="text"/>	<input type="text"/>
Operation	Configuration	▼
Apply		

Switch name configuration		
Switch name	<input type="text"/>	<input type="text"/>
Operation	Configuration	▼
Apply		

<b>HH:MM:SS</b>	Current time, format hours: minutes: seconds
<b>YYYY.MM.DD</b>	Current date, format year. Month. Day

<b>Timeout (minute)</b>	Exit privilege mode timeout score 0-35791	
<b>Timeout (second)</b>	Seconds of exit privilege mode timeout (not set separately), 0-59 seconds	
<b>Operation</b>	Configuration	Configuration operations
	Default	Restore default (default timeout 10 minutes)
<b>Switch name</b>	Fill in the new name of the switch to be changed, 1-64 characters	
<b>Operation</b>	Configuration	Configuration operations
	Default	Do recovery default (default name Switch)

### 1.1.5. Save current running-configuration

Save the current configuration module, the user can save the current set configuration, can also leave the factory initial settings restart, but also choose whether to save the current set configuration before restart.

<b>Save current running-configuration</b>	
<input type="text"/>	Apply
<b>Reboot with the default configuration</b>	
<input type="text"/>	Apply
<b>Save current configuration before reboot?</b>	
Yes <input type="button" value="v"/>	<input type="text"/>
<input type="text"/>	Apply

## 1.2. SNMP authentication

### 1.2.1. SNMP authentication

#### 1.2.1.1. Users

SNMP user management module, users can add or delete SNMP user operations in this module.

<b>Users</b>	
SNMP username	<input type="text"/>
SNMP group	<input type="text"/>
Security level	noAuthNoPriv <input type="button" value="v"/>
Authentication protocol:	MD5 <input type="button" value="v"/>
Authentication password:	<input type="text"/>
Privacy protocol:	DES <input type="button" value="v"/>
Privacy password:	<input type="text"/>
Ipv4 access control list	<input type="text"/>
Ipv6 access control list	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="text"/>	Apply

<b>SNMP username</b>	User name to operate ,1-32 characters	
<b>SNMP group</b>	User group to join,1-32 characters	
<b>Security level</b>	noAuthNoPriv	Uncertified non-encrypted level
	authNoPriv	Authentication but not encryption level
	authpriv	Authentication and encryption level
<b>Authentication protocol:</b>	MD5	HMAC MD5 algorithm for authentication
	SHA	Authentication uses HMAC SHA algorithms

## 1 Switch basic configuration

<b>Authentication password:</b>	Password for authentication	
<b>Privacy protocol:</b>	DES	Encryption DES algorithm
	AES	Encryption AES algorithm
	3DES	Encryption with 3 DES algorithm
<b>Privacy password:</b>	Password for encryption	
<b>Ipv4 access control list</b>	Standard IPv4 access control list number, range 1-64 characters	
<b>Ipv6 access control list</b>	Standard IPv6 access control list number, range 1-64 characters	
<b>Operation</b>	Add	Add SNMP users
	Remove	Delete SNMP users

### 1.2.1.2. Groups

SNMP group management module in which users can add or delete SNMP group operations.

Groups	
SNMP group	<input type="text"/>
Security level	noAuthNoPriv ▼
Read SNMP view	<input type="text"/>
Write SNMP view	<input type="text"/>
Notify SNMP view	<input type="text"/>
Operation	Add ▼
<input type="button" value="Apply"/>	

<b>SNMP group</b>	User group name to operate,1-32 characters	
<b>Security level</b>	noAuthNoPriv	Uncertified non-encrypted level
	authNoPriv	Authentication but not encryption level
	authpriv	Authentication and encryption level
<b>Read SNMP view</b>	Name of readable view, including 1-32 characters	
<b>Write SNMP view</b>	Name of writable view, including 1-32 characters	
<b>Notify SNMP view</b>	Notice the name of the view, including 1-32 characters	
<b>Operation</b>	Add	Add SNMP groups
	Remove	Delete SNMP groups

### 1.2.1.3. Views

SNMP view management module in which users can add or delete SNMP view operations.

Views	
SNMP view	<input type="text"/>
OID	<input type="text"/>
Type:	Include ▼
Operation	Add ▼
<input type="button" value="Apply"/>	

SNMP view	OID	Type
v1defaultviewname	1.0.	Include
v1defaultviewname	1.2.	Include
v1defaultviewname	1.3.	Include

<b>SNMP view</b>	User view name to operate, 1-32 characters	
<b>OID</b>	OID number to operate, decimal	
<b>Type:</b>	Include	Include this OID
	Exclude	Exclude this OID
<b>Operation</b>	Add	Add view
	Remove	Delete View

### 1.2.1.4. SNMP engineid configuration

SNMP Engineid configuration module, the user can configure SNMP Engineid operation in this module.

SNMP engineid configuration	
Engineid	<input type="text"/>
Operation	Configuration ▼
<input type="button" value="Apply"/>	

Engineid	<input type="text"/>
	18c308c6b3c91aab

<b>Engineid</b>	Engine id, Hex, 1-32 characters	
<b>Operation</b>	configuration	Configuration operations
	Default	Restore default (default is company ID plus local MAC address)

## 1 Switch basic configuration

### 1.2.2. SNMP management

SNMP network management function switch module, users can enable or disable SNMP functions.

SNMP management	
SNMP Agent state	Open ▾
RMON state	Open ▾
Trap state	Open ▾
Security IP state	Open ▾
Apply	

### 1.2.3. Community managers

The group string management module where users can SNMP group string management and configure TRAP management settings.

Community managers	
Community string	<input type="text"/>
Access priority	Read only ▾
Operation	Add ▾
Apply	


TRAP manager configuration	
Trap receiver	<input type="text"/>
Community string	<input type="text"/>
Version	1 ▾
Security level	noAuthNoPriv ▾
Operation	Add ▾
Apply	

<b>Community string</b>	Community string name ,1-255 characters	
<b>Access priority</b>	Read only	Read-only permission level
	Read and write	Read and write permission level
<b>Operation</b>	Add	Do Community string add operations
	Remove	Do Community string delete operations
<b>Trap receiver</b>	Recipient IPv4/IPv6 address of Trap information	
<b>Community string</b>	Community string name, V1/V2 version: 1-255 characters, V3 version: 1-24 characters	
<b>Version</b>	Three versions: V1/V2C/V3	
<b>Security level (V3 version support only)</b>	noAuthNoPriv	Uncertified non-encrypted level
	authNoPriv	Authentication but not encryption level
	authpriv	Authentication and encryption level

<b>Operation</b>	Add	For Trap information receiver add operation
	Remove	For Trap information receiver remove operation

### 1.2.4. Configure snmp manager security IP

The administrator IP the address setting module, where the user can add or delete the SNMP manager's safe IP address.



<b>Security IP address</b>	SNMP Management Security IPv4/IPv6 Address	
<b>Operation</b>	Add	Add a Security IP
	Remove	Remove a Security IP

### 1.2.5. SNMP statistics

SNMP statistical information module, users in this module can view the SNMP function feedback information.

```

Information feedback window
SW1# show snmp
0 SNMP packets input
  0 Bad SNMP version errors
  0 Unknown community name
  0 Illegal operation for community name supplied
  0 Encoding errors
  0 Number of requested variables
  0 Number of altered variables
  0 Get-request PDUs
  0 Get-next PDUs
  0 Set-request PDUs
0 SNMP packets output
  0 Too big errors (Max packet size 1500)
  0 No such name errors
  0 Bad values errors
  0 General errors
  0 Get-response PDUs
  0 SNMP trap PDUs
  
```

# 1 Switch basic configuration

## 1.3. SSH management

### 1.3.1. Switch on-off SSH

SSH function switch module in which the user can enable or disable switches by SSH.

Switch on-off SSH	
Switch on-off SSH	Open ▾
Apply	

### 1.3.2.SSH management

SSH management configuration module, the user can configure the SSH timeout, SSH authentication times and SSH RSA secret key modulus, and can also view the user login status of the SSH server.

SSH timeout management	SSH reauthentication management
SSH timeout	SSH reauthentication
Operation	Operation
Configuration ▾	Configuration ▾
Apply	Apply

Create SSH RSA key	
SSH RSA key	1024
Apply	

SSH timeout	SSH reauthentication
600	3

Show SSH Server's State			
Num	Version	Status	SSH username

<b>SSH timeout</b>	timeout of exit SSH login status, 10-600 seconds	
<b>Operation</b>	Configuration	Configuration operations
	Default	Recovery default (default 180 s)

<b>SSH reauthentication</b>	SSH number of re-authentications when logged in, 1-10	
<b>Operation</b>	Configuration	Configuration operations
	Default	Restore default (default re-authentication 3 times)

<b>SSH RSA key</b>	A module for calculating Rsa keys, ranging from 768-2048, default 1024
--------------------	--

## 1.4. Firmware update

### 1.4.1. TFTP service

#### 1.4.1.1. TFTP client service

TFTP client service module, the user can upload or download files by TFTP way, and can upgrade the firmware of the switch by this method.

TFTP client service	
Server IP address	<input type="text"/>
Local file name	<input type="text"/>
Server file name	<input type="text"/>
Operation type	Upload ▼
Transmission type	binary ▼
Apply	

<b>Server IP address</b>	TFTP address IP peer server, point decimal	
<b>Local file name</b>	Name of destination file to upload or download, 1-100 characters	
<b>Server file name</b>	Source name to upload or download, 1-100 characters	
<b>Operation type</b>	Upload	To upload files
	Download	To download files
<b>Transmission type</b>	binary	Transfer files in binary format (default)
	ascii	Transfer files in ascii format

#### 1.4.1.2. TFTP server service

TFTP server-side service module, users can configure the TFTP server settings in this module.

TFTP server service	
Server state	Close ▼
TFTP Timeout	600
TFTP Retransmit times	5
Operation	Configuration ▼
Apply	

<b>Server state</b>	Open	Enable TFTP server functionality
	Close	Disable TFTP server functionality (default)
<b>TFTP Timeout</b>	TFTP service exit timeout, range 5-3600 s (default 600 s)	
<b>TFTP Retransmit times</b>	TFTP number of retransmissions after transmission failure, range 1-20 (default 5)	

## 1 Switch basic configuration

<b>Operation</b>	Configuration	Configuration operations
	Default	Restore default

### 1.4.2. FTP service

#### 1.4.2.1. FTP client service

FTP client service module, the user can upload or download files by FTP way, and can upgrade the firmware of the switch by this method.

FTP client service	
Server IP address	<input type="text"/>
User	<input type="text"/>
Password	<input type="text"/>
Local file name	<input type="text"/>
Server file name	<input type="text"/>
Operation type	Upload <input type="button" value="v"/>
Transmission type	binary <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Server IP address</b>	FTP address IP peer server, point decimal	
<b>User</b>	FTP server-to-server username, 1-100 characters	
<b>Password</b>	FTP server-side user password 1-100 characters	
<b>Local file name</b>	Name of destination file to upload or download ,1-100 characters	
<b>Server file name</b>	Source name to upload or download, 1-100 characters	
<b>Operation type</b>	Upload	To upload files
	Download	To download files
<b>Transmission type</b>	binary	Transfer files in binary format (default)
	ascii	Transfer files in ascii format

#### 1.4.2.2. FTP server service

FTP server service module, the user can configure various settings of FTP server.

FTP server service	
FTP server State	Close <input type="button" value="v"/>
FTP Timeout	600 <input type="text"/>
Operation	Configuration <input type="button" value="v"/>
<input type="button" value="Apply"/>	

FTP user name and password setting	
User	<input type="text"/>
Password	<input type="text"/>
State	Plain text <input type="button" value="v"/>
Operation type	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	


<b>FTP server State</b>	Open	Enable FTP server functionality
	Close	Disable FTP server functionality (default)
<b>FTP Timeout</b>	FTP service exit timeout, range 5-3600s (default 600 s)	
<b>Operation</b>	Configuration	Configuration operations
	Default	Restore default

<b>User</b>	FTP service username to operate, 1-32 characters	
<b>Password</b>	FTP service user password to operate, 1-16 characters	
<b>State</b>	Plain text	Do not encrypt FTP service password
	Encrypted	Encryption of FTP service passwords
<b>Operation type</b>	Add	Add operations
	Remove	Delete operations

### 1.4.3. HTTP service

#### 1.4.3.1. HTTP Upgrade


HTTP upgrade module, the user can upload or download files by HTTP way, and can upgrade the firmware of the switch by this method.



# 1 Switch basic configuration

## 1.4.3.2. HTTP Configuration

HTTP upgrade module, the user can upload or download configuration by HTTP way.



<b>Operation type</b>	Upload	To upload configuration files
	Download	To download configuration files
<b>File type</b>	Running Configuration	Running configuration of the switch
	Startup Configuration	Startup configuration of the switch

## 1.5. Telnet server configuration

### 1.5.1. Telnet server state

Telnet server status module, where users can enable or disable login switches by Telnet.

Telnet server state	
Telnet server state	Open ▾
Apply	

### 1.5.2. Max numbers of telnet access connection

Telnet connect the maximum number module, and the user can configure the maximum number of connections to the switch by Telnet.

Max numbers of telnet access connection	
Telnet access connection number	<input type="text"/>
Operation	Configuration ▾
Apply	

Information feedback window	
Telnet access connection number	5

<b>Telnet access connection number</b>	Maximum number of connections logged in by Telnet, range 1-16 (default 5)	
<b>Operation</b>	Configuration	Configuration operations
	Default	Restore default

# 1 Switch basic configuration

## 1.6. Maintenance and debugging command

### 1.6.1. Debug command

Maintenance and debugging command module. The user can configure the mapping relationship between host and IP, also can run ping command and route tracking command.

Basic host configuration	
Host name	<input type="text"/>
IP address	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

PING	
Host name	<input type="text"/>
IP address	<input type="text"/>
<input type="button" value="Apply"/>	

Traceroute	
IP address	<input type="text"/>
Host name	<input type="text"/>
Hops	<input type="text"/>
timeout	<input type="text"/>
<input type="button" value="Apply"/>	

<b>Host name</b>	Host name for mapping, 1-64 characters	
<b>IP address</b>	IP address for mapping, point decimal	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

<b>Host name</b>	To ping the host name, configure the mapping relationship between the host and the IP
<b>IP address</b>	IP address to ping, decimal

<b>IP address</b>	IP address for routing tracing, point decimal
<b>Host name</b>	Host name for routing tracing, 1-64 characters
<b>Hops</b>	Number of hops, route, range 1-255
<b>Timeout</b>	Tracking timeout ,100-10000

### 1.6.2. Show clock

This module is used to display the current system time and date.

```

Information feedback window
SW1# show clock
Current time: Wed Jan 01 01:03:21 2020 [UTC]
    
```

### 1.6.3. Show CPU usage

This module is used to display resource usage CPU current system.

```
Information feedback window
SW1# show cpu usage
Last 5 second CPU IDLE: 83%
Last 30 second CPU IDLE: 92%
Last 5 minute CPU IDLE: 92%
From running CPU IDLE: 91%
```

### 1.6.4. Show memory usage

This module is used to display the current system memory resource usage.

```
Information feedback window
SW1# show memory usage
The memory total 128 MB , free 68009984 bytes , usage is 49.33%
```

### 1.6.5. Show flash

This module is used to display the current system flash storage resource usage.

```
Information feedback window
SW1# show flash
total 22789K
-rw-      10817705      mantest.img
-rw-      12514223      nos.img
-rw-       1384        startup.cfg
-rw-       1361        test1.cfg
Drive : flash:
Size:30.0M Used:23.5M Available:6.5M Use:78%
```

### 1.6.6. Show running-config

This module is used to display configuration information in the current system run.

```
Information feedback window
SW1# show run
!
no service password-encryption
!
hostname SW1
sysLocation Russia, Moscow, Ryabinovaya st, 26 bld 2
sysContact +7(495)797-3311
!
username admin privilege 15 password 0 admin
!
!
!
ssh-server enable
ssh-server timeout 600
!
web language english
!
snmp-server enable
snmp-server enable traps
!
```

## 1 Switch basic configuration

### 1.6.7. Show switchport interface

This module is used to display the port information of the current switch.

```
Information feedback window
SW1# show switchport interface
Ethernet1/0/1
Type :Universal
Mode :Trunk
Port VID :1
Trunk allowed Vlan: 1-4094
Ethernet1/0/2
Type :Universal
Mode :Trunk
Port VID :1
Trunk allowed Vlan: 1-4094
```

### 1.6.8. Show TCP

This module is used to display TCP connection information for the current switch.

```
Information feedback window
SW1# show tcp
LocalAddress      LocalPort  ForeignAddress  ForeignPort  State      IF  VRF
192.168.2.1       80         192.168.2.200  54216       ESTABLISHEDO  0
127.0.0.1         2650      127.0.0.1      32785       ESTABLISHEDO  0
127.0.0.1         32785     127.0.0.1      2650       ESTABLISHEDO  0
0.0.0.0           80        0.0.0.0        0           LISTEN       0  0
0.0.0.0           22        0.0.0.0        0           LISTEN       0  0
0.0.0.0           23        0.0.0.0        0           LISTEN       0  0
127.0.0.1         2650     0.0.0.0        0           LISTEN       0  0
```

### 1.6.9. Show UDP

This module is used to display UDP connection information for the current switch.

```
Information feedback window
SW1# show udp
LocalAddress      LocalPort  ForeignAddress  ForeignPort  State
0.0.0.0           161       0.0.0.0        0           CLOSE
0.0.0.0           3071     0.0.0.0        0           CLOSE
```

### 1.6.10. Show telnet login

This module is used to display the user information that is currently logged in to the switch by telnet.

```
Information feedback window
SW1# show telnet login
Authenticate login by local.
Login user:
```

### 1.6.11. Show version

This module is used to display the user information that is currently logged in to the switch by telnet.

Client IP address:192.168.2.200

System Version Information	
Device:	Switch, sysLocation: Russia, Moscow, Rybinovaya st, 26 bld 2.
CPU MAC	08-c6-b3-c9-1a-ab
VLAN MAC	08-c6-b3-c9-1a-ac
SoftWare Version	8.101.30
BootRom Version	2011.12.16
HardWare Version	1.2
CPLD Version	N/A
Serial No.:	7135070820200001
Last reboot was cold reset.	
Uptime is 0 weeks, 0 days, 1 hours, 9 minutes	

## 1 Switch basic configuration

### 1.7. RMON

#### 1.7.1. RMON statistics

RMON statistics user management module, users can display or clear RMON statistics in this module.

RMON statistics	
Port	Ethernet1/0/1 ▾
<input type="button" value="clear"/> <input type="button" value="display"/>	

#### 1.7.2. RMON history

RMON history user management module, users can configure RMON history in this module.

RMON history control config				
History control ID	<input type="text"/>			
Port	Ethernet1/0/1 ▾			
Buckets	<input type="text"/>	<input type="checkbox"/>		
Interval	<input type="text"/>	<input type="checkbox"/>		
Owner	<input type="text"/>	<input type="checkbox"/>		
Operation	Add ▾			
<input type="button" value="Apply"/>				

RMON history control table				
History control ID	Port	Buckets	Interval	Owner
finish				

<b>History control ID</b>	History control ID to add,1-65535
<b>Port</b>	Ethernet port name
<b>Buckets</b>	Buckets to add, 1-50
<b>Interval</b>	Interval to add, 1-3600
<b>Owner</b>	Owner to operate, 1-32 characters
<b>Operation</b>	Add/Remove

### 1.7.3. RMON alarm

RMON alarm user management module, users can configure RMON alarm in this module.

RMON alarm config	
Alarm ID	<input type="text"/>
Port	Ethernet1/0/1 ▾
Sample variable	Drop-Events ▾
Sample interval	<input type="text"/>
Sample type	absolute ▾
Alarm type	Falling ▾
Rising threshold	<input type="text"/>
Rising event	<input type="text"/>
Falling threshold	<input type="text"/>
Falling event	<input type="text"/>
Owner	<input type="text"/> <input type="checkbox"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

RMON alarm table										
Alarm ID	Port	Sample variable	Sample interval	Sample type	Alarm type	Rising threshold	Rising event	Falling threshold	Falling event	Owner

<b>Alarm ID</b>	Alarm ID to add, 1-65535
<b>Port</b>	Ethernet port name
<b>Sample variable</b>	Broadcast-Pkts Collision CRC-Align-Errors DropEvents Fragments Jabbers Multicast-Pkts Octets OverSizePkts Pkts Pkts1024to1518Octets Pkts128to255Octets Pkts256to511Octets Pkts512to1023Octets Pkts64Octets Pkts65to127Octets UnderSizePkts
<b>Sample interval</b>	Sample Interval to add, 1-65535
<b>Sample type</b>	Absolute/delta
<b>Alarm type</b>	Falling/Rising/Rising or Falling
<b>Rising threshold</b>	Rising threshold to add, 0-2147483647
<b>Rising event</b>	Rising event to add, 1-65535
<b>Falling threshold</b>	Falling threshold to add, 0-2147483647
<b>Falling event</b>	Falling event to add, 1-65535

## 1 Switch basic configuration

<b>Owner</b>	Owner to add, 1-31 characters
<b>Operation</b>	Add/Remove

### 1.7.4. RMON event

RMON event user management module, users can configure RMON event in this module.

RMON event table					
Alarm ID	Event type	Community	Event description	Last sent	Owner

<b>Event ID</b>	Event ID to add, 1-65535
<b>Event type</b>	Log/SNMP-Trap/Log and Trap
<b>Community</b>	Community Set
<b>Event description</b>	Event description to set, 1-31 characters
<b>Owner</b>	Owner to add, 1-31 characters
<b>Operation</b>	Add/Remove

## 2. Module management

### 2.1. Show boot-files

This module is used to display system firmware and configuration files for the next restart of the switch.

Information feedback window	
Booted files on switch	
The primary img file at the next boot time:	flash:/nos.img
The backup img file at the next boot time:	flash:/nos.img
Current booted img file:	flash:/nos.img
The startup-config file at the next boot time:	flash:/startup.cfg
Current booted startup-config file:	flash:/startup.cfg

### 2.2. Set Boot IMG and Startup-Config

This module is used to configure the system firmware and configuration files for the next restart of the switch.

Set boot files in Active Master		
Primary IMG	<input type="text"/>	Set
Backup IMG	<input type="text"/>	Set
Startup-config	<input type="text"/>	Set

<b>Primary IMG</b>	System firmware first boot item when switch restarts
<b>Backup IMG</b>	System firmware second boot item when switch restarts
<b>Startup-config</b>	Start configuration file on switch restart

### 3 Port configuration

## 3. Port configuration

### 3.1. Ethernet port configuration

This chapter mainly configures the related port function of Ethernet port.

#### 3.1.1. Port layer 1 attribution configuration

This page is mainly used to configure the basic properties of physical ports.

To display the “Port layer 1 attribution configuration” page, click Port configuration ->Ethernet port configuration->Port layer 1 attribution configuration, click "Apply" to configure.

Port configuration		
Port	Ethernet1/0/1 ▾	
mdi	auto ▾	<input type="checkbox"/>
Admin status	no shutdown ▾	<input type="checkbox"/>
Speed/Duplex status	Auto ▾	<input type="checkbox"/>
Module type	auto-detected ▾	<input type="checkbox"/>
1000M Mode	▾	<input type="checkbox"/>
Fiber portMode	Auto ▾	<input type="checkbox"/>
Flow control status	Invalid flow control ▾	<input type="checkbox"/>
Loopback	no loopback ▾	<input type="checkbox"/>
		<input type="button" value="Apply"/>

Entry	Describe
<b>Mdi</b>	Invalid settings
<b>Admin status</b>	Port status: Shutdown: enable No shutdown: disable
<b>Speed/Duplex status</b>	Port rate and Working mode
<b>Module type</b>	Port types such as Ethernet port, Gigabit optical port, etc.
<b>1000M Mode</b>	Mode configuration in Gigabit port configuration
<b>Fiber portMode</b>	Invalid settings
<b>Flow control status</b>	Port Flow Control
<b>Loopback</b>	Port loop detection: Loopback: enable No Loopback: disable

<b>Port rate</b>	Port rate:10: 10M 100: 100M 1000: 1000M Auto: Automatic negotiation rate
<b>Working mode</b>	Working mode: Auto: Automatic negotiation mode Half: Half duplex mode Full: Full duplex mode

Port list									
Port	mdi	managementStatus	Speed	Mode	1000M Mode	Fiber portMode	Flow control	loopback	
Ethernet1/0/1	auto	No Shutdown	10M	full	NULL	Auto	Non flow control status	no loopback	
Ethernet1/0/2	auto	No Shutdown	auto	auto	NULL	Auto	Non flow control status	no loopback	
Ethernet1/0/3	auto	No Shutdown	auto	auto	NULL	Auto	Non flow control status	no loopback	
Ethernet1/0/4	auto	No Shutdown	auto	auto	NULL	Auto	Non flow control status	no loopback	
Ethernet1/0/5	auto	No Shutdown	auto	auto	NULL	Auto	Non flow control status	no loopback	
Ethernet1/0/6	auto	No Shutdown	auto	auto	NULL	Auto	Non flow control status	no loopback	
Ethernet1/0/7	auto	No Shutdown	auto	auto	NULL	Auto	Non flow control status	no loopback	
Ethernet1/0/8	auto	No Shutdown	auto	auto	NULL	Auto	Non flow control status	no loopback	

<b>Entry</b>	<b>Describe</b>
<b>Mdi</b>	Invalid settings
<b>managementStatus</b>	Port enable status: Shutdown: enable no shutdown: disable
<b>Speed</b>	Port rate: 10: 10M 100: 100M 1000: 1000M Auto: Automatic negotiation rate

### 3 Port configuration

<b>Mode</b>	Working mode: Auto: Automatic negotiation mode Half: Half duplex mode Full: Full duplex mode
<b>1000M Mode</b>	Mode configuration in Gigabit port configuration
<b>Fiber portMode</b>	Invalid settings
<b>Flow control</b>	Port Flow Control
<b>Loopback</b>	Port loop detection: Loopback: enable No Loopback: disable

#### 3.1.2. Bandwidth control configuration

The page is configured for bandwidth control.

To display the "Bandwidth control configuration" page, click Port configuration -> Ethernet port configuration -> Bandwidth control configuration, click "Apply" to configure.

Bandwidth control configuration			
Port	Bandwidth control level	Control type	Operation
Ethernet1/0/1 ▾		Transmit ▾	Configuration ▾
			Apply

<b>entry</b>	describe
<b>Bandwidth control level</b>	Bandwidth control rate in the range of Kbps 1-1000000
<b>Control type</b>	Control type: Transmit: send Receive: receive Both: send and receive
<b>Operation</b>	Configuration: User-defined configuration Default: Restore default configuration

Port list		
Port	Ingress bandwidth threshold(Kb)	Egress bandwidth threshold(Kb)
Ethernet1/0/1	1000000	1000000
Ethernet1/0/2	1000000	1000000
Ethernet1/0/3	1000000	1000000
Ethernet1/0/4	1000000	1000000
Ethernet1/0/5	1000000	1000000
Ethernet1/0/6	1000000	1000000
Ethernet1/0/7	1000000	1000000
Ethernet1/0/8	1000000	1000000

<b>Port</b>	Ethernet port name
<b>Ingress bandwidth threshold(Kb)</b>	Displays the current received data bandwidth limit in the range of Kbps 1-1000000
<b>Egress bandwidth threshold(Kb)</b>	Displays the bandwidth limit of the current sending data, ranging from 1-1000000kbps

### 3.1.3.Switchport description

This page can be used to set the port name.

To display the "Switchport description" page, click Port configuration ->Ethernet port configuration->Switchport description, click "Apply" to configure.

Switchport description	
Port	Ethernet1/0/1 ▾
Description	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>Port</b>	Ethernet port name
<b>Description</b>	Port description name, length 1-200 characters
<b>Operation</b>	Configuration: User-defined configuration Default: Restore default configuration

### 3 Port configuration

Port list	
Port	Description
Ethernet1/0/1	
Ethernet1/0/2	
Ethernet1/0/3	
Ethernet1/0/4	
Ethernet1/0/5	
Ethernet1/0/6	
Ethernet1/0/7	
Ethernet1/0/8	

<b>Port</b>	Ethernet port name
<b>Description</b>	Port description name, length 1-200 characters

#### 3.1.4.Port combo forced mode config

This page can be used to configure the combo port interface type to switch. To display the "Port combo forced mode config" page, click Port configuration ->Ethernet port configuration->Port combo forced mode config, click "Apply" to configure.

Port combo forced mode config	
Port	Ethernet1/0/1 ▾
forced mode	copper-forced ▾
Apply	

<b>Port</b>	Ethernet port name
<b>forced mode</b>	Configure combo port current interface type: Copper-forced: copper Sfp-forced: fiber sfp-preferred-auto: Automatic switching

Information feedback window	
Port	forced mode
Ethernet1/0/1	no support
Ethernet1/0/2	no support
Ethernet1/0/3	no support
Ethernet1/0/4	no support
Ethernet1/0/5	no support
Ethernet1/0/6	no support
Ethernet1/0/7	no support
Ethernet1/0/8	no support

Port	Ethernet port name
<b>forced mode</b>	Configure combo port current interface type: Copper-forced: copper Sfp-forced: fiber sfp-preferred-auto: Automatic switching

### 3.1.5. Port 10G mode

This page can be used to configure the combo port interface type to switch. To display the "Port 10G Mode" page, click Port configuration -> Ethernet port configuration -> Port 10G Mode, click "Apply" to configure.



System IP address: 192.168.19.200    Current system time: Wed Jun 7 00:10:01 2023    System description: Switch    [Exit] [Save & Exit] [Reboot]

Default

- GV-APOE4813
  - Switch basic configuration
  - Module management
  - Port configuration
    - Ethernet port configuration
      - Port layer 1 attribution configuration
      - Bandwidth control configuration
      - Switchport description
      - Port combo forced mode config
      - Port 10G Mode
      - port scan mode
    - VLAN interface configuration
    - SPAN configuration
    - Loopback-detection configuration
    - Isolate-port configuration
    - Port storm-control config
    - Port rate-violation config
    - Port virtual-cable-test config
    - Port debug and maintenance
    - uldp configuration
    - LLDP configuration
    - LED shutoff configuration
    - Jumbo packet forwarding configuration

**Port 10G Mode**

Port: Ethernet1/0/49

Port 10G Mode: dac-50cm

[Apply]

**Information feedback window**

Port	Port 10G Mode
Ethernet1/0/49	fiber-10g
Ethernet1/0/50	fiber-10g
Ethernet1/0/51	fiber-10g
Ethernet1/0/52	fiber-10g
Ethernet1/0/53	fiber-10g
Ethernet1/0/54	fiber-10g

### 3 Port configuration

Port	Ethernet port name
<b>forced mode</b>	Configure port 10G Mode current interface type: Copper: Select Copper dac-100cm: Select 100cm DAC dac-300cm: Select 300cm DAC dac-500cm: Select 500cm DAC dac-50cm: Select 50cm DAC fiber: Select Fiber fiber-10g: Select 10G fiber fiber-1g: Select 1G fiber sfp-preferred-auto: Automatic switching

#### 3.1.6. Port scan mode

This function switch is not supported for the time being.

## 3.2. VLAN interface configuration

This chapter mainly realizes the creation of VLAN interface and the configuration of interface address.

#### 3.2.1. Add interface VLAN

This page is mainly used to create VLAN interfaces.

To display the "add interface VLAN" page, click Port configuration ->VLAN interface configuration->add interface VLAN, click "Apply" to configure.

Add interface VLAN	
VLAN ID	1 ▾
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>VLAN ID</b>	VLAN ID created
<b>Operation</b>	Action: Add/Remove

Vlan ID	State
Vlan1	Layer 3 interface
Vlan5	Non layer 3 interface

<b>entry</b>	describe
<b>VLAN ID</b>	VLAN ID added
<b>State</b>	Is VLAN a layer 3 interface

### 3.2.2. L3 interface IP address mode configuration

The page can be used to configure IP address and subnet mask for the VLAN interface.

To display the “L3 interface IP address mode configuration” page, click Port configuration ->VLAN interface configuration->L3 interface IP address mode configuration, click "Apply" to configure.

L3 interface IP address mode configuration	
VLAN interface	Vlan1 ▾
IP mode	Specify IP address ▾
Interface IP address	<input type="text"/>
Interface network mask	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

Entry	Describe
<b>VLAN interface</b>	VLAN ID of layer 3 interface created
<b>IP mode</b>	Access to interface IP address: bootp-client: bootp-client Automatic acquisition dhcp-client: dhcp-client Automatic acquisition Specify IP address: User self configuration
<b>Interface IP address</b>	IP address, e.g. A.B.C D
<b>Interface network mask</b>	Network mask: for example :255.255.255.0
<b>Operation</b>	Action: Add/Remove

### 3 Port configuration

#### 3.3.SPAN configuration

This section can be used for port mirroring function configuration.

To display the "SPAN configuration" page, click Port configuration ->VLAN interface configuration->SPAN configuration, click "Apply" to configure.

Destination port (SPAN) configuration	
Session	1 ▾
Destination port (SPAN)	1/0/1 ▾
Operation	Add ▾
Apply	

<b>entry</b>	describe
<b>Session</b>	Mirror Session
<b>Destination port (SPAN)</b>	Mirror destination port
<b>Operation</b>	Action: Add/Remove

SPAN configuration	
Session	Destination port (SPAN)
1	Ethernet1/0/1

<b>entry</b>	describe
<b>Session</b>	Mirror Session
<b>Destination port (SPAN)</b>	Mirror destination port

Source port (SPAN) configuration	
Session	1 ▾
Source port (SPAN) list	1/0/1 ▾
CPU to be used for source port	<input type="checkbox"/>
Access list	
Mirror direction	both ▾
Operation	Add ▾
Apply	

<b>entry</b>	describe
<b>Session</b>	Mirror Session
<b>Source port (SPAN) list</b>	Mirror Source Port
<b>CPU to be used for source port</b>	CPU used as the source of data
<b>Access list</b>	The access control list set for the mirror source port

<b>Mirror direction</b>	What kind of data is needed to filter to the destination port: Both: Sending and receiving Rx: receive Tx: send
<b>Operation</b>	Add: Add configuration for the corresponding operation Remove: Delete the corresponding configuration

Rspan vlan configuration	
VLAN ID	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>VLAN ID</b>	VLAN ID
<b>Operation</b>	Add: Add configuration for the corresponding operation Remove: Delete the corresponding configuration

reflector port (SPAN) configuration	
Session	1 <input type="button" value="v"/>
Port	Ethernet1/0/1 <input type="button" value="v"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Entry</b>	Describe
<b>Session</b>	Mirroring Session
<b>Port</b>	Ethernet port number
<b>Operation</b>	Add: Add configuration for the corresponding operation Remove: Delete the corresponding configuration

### 3 Port configuration

remote vlan configuration	
Session	1 ▾
VLAN ID	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Session</b>	Mirroring Session
<b>VLAN ID</b>	VLAN ID
<b>Operation</b>	Add: Add configuration for the corresponding operation Remove: Delete the corresponding configuration

sample rate configuration	
Session	1 ▾
rate	<input type="text"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Session</b>	Mirroring Session
<b>rate</b>	It indicates how many packets are mirrored to the destination port

Source port (SPAN) list							
session 1		session 2		session 3		session 4	
Tx	Rx	Tx	Rx	Tx	Rx	Tx	Rx
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

<b>Entry</b>	Describe
<b>Session</b>	Mirroring Session
<b>Tx/Rx</b>	Direction of source port mirror data
<b>Ethernet1/0/10</b>	Mirror Source Port for Session

### 3.4. Loopback-detection configuration

This chapter is mainly for port loop detection function configuration.

#### 3.4.1. Port Loopback-detection mode configuration

The configuration of the page is used to set the loop detection control method. To display the "Port Loopback-detection mode configuration" page, click Port configuration ->Port Loopback-detection configuration->Port Loopback-detection mode configuration, click "Apply" to configure.

Port Loopback-detection mode configuration	
Port	Ethernet1/0/1 ▾
Loopback-detection mode	shutdown ▾
Operation	Add ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Port</b>	Ethernet port name
<b>Loopback-detection mode</b>	Operation in case of loop: Shutdown: Disable port Block: Block port
<b>Operation</b>	Operation of loop detection function: Add: Open loop detection and configure control mode Remove: Disable loop detection

**3 Port configuration**

Information feedback window	
Port	Loopback-detection mode
Ethernet1/0/1	no control mode
Ethernet1/0/2	no control mode
Ethernet1/0/3	no control mode
Ethernet1/0/4	no control mode
Ethernet1/0/5	no control mode
Ethernet1/0/6	no control mode
Ethernet1/0/7	no control mode
Ethernet1/0/8	no control mode

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>Loopback-detection mode</b>	Shutdown: Disable port Block: Block port no control mode: Disable port loop detection

**3.4.2. VLAN Loopback-detection configuration**

This page can be used to configure VLAN loop detection function enabled or disabled. To display the "VLAN Loopback-detection configuration" page, click Port configuration ->Port Loopback-detection configuration->VLAN Loopback-detection configuration, click "Apply" to configure.

VLAN Loopback-detection configuration	
Port	Ethernet1/0/1 <input type="button" value="v"/>
VLAN ID	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>VLAN ID</b>	VLAN ID, range 1-4094
<b>Operation</b>	Add: Enable VLAN loop detection Remove: Disable VLAN loop detection

### 3.4.3. Loopback-detection interval-time configuration

This page can be used to configure the loop detection interval.

To display the "Loopback-detection interval-time configuration" page, click Port configuration ->Port Loopback-detection configuration->Loopback-detection interval-time configuration, click "Apply" to configure.

Loopback-detection interval-time configuration	
Loopback-detection interval time	<input type="text"/>
no Loopback-detection interval time	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Loopback-detection interval time</b>	Interval time between loops, size 5-300 seconds
<b>no Loopback-detection interval time</b>	No loop interval, size 1-30 seconds
<b>Operation</b>	Configuration: Set the test time by yourself. Default: Restore the default configuration, there is a loop detection interval of 5 seconds, there is no loop detection interval of 3 seconds.

### 3 Port configuration

#### 3.4.4. Loopback-detection control recovery configuration

This page is used to configure loop detection to automatically return to an uncontrolled state.

To display the "Loopback-detection control recovery configuration" page, click Port configuration ->Port Loopback-detection configuration -> Loopback-detection control recovery configuration, click "Apply" to configure.

Loopback-detection control recovery configuration	
Recovery switch timeout	<input type="text"/>
<input type="button" value="Apply"/>	

entry	describe
Recovery switch timeout	When a port is disabled or blocked due to a loop, it automatically recovers to an uncontrolled time, the size range is 0-3600 seconds. When it is configured as 0, the auto recovery function is disabled.

#### 3.5. Isolate-port configuration

This section can set up port isolation related functions.

##### 3.5.1. Isolate-port group configuration

This page can be used to add or delete isolated groups.

To display the "Isolate-port group configuration" page, click Port configuration -> Isolate-port configuration -> Isolate-port group configuration, click "Apply" to configure.

Isolate-port group configuration	
Group name	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Group name</b>	Isolation group name, example: aaaa
<b>Operation</b>	Add: Create an isolation group Remove: Delete an isolation group

### 3.5.2. Interface join group config

This page can be used to add ports for isolation groups.

To display the “Interface join group config” page, click Port configuration ->Isolate-port configuration->Interface join group config, click "Apply" to configure.

Interface join group config	
Group name	<input type="text"/>
Port	Ethernet1/0/1 <input type="button" value="v"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Group name</b>	Created isolation group name, example: aaaa
<b>Port</b>	Ethernet port name
<b>Operation</b>	Add: Add ports to the isolation group Remove: Delete ports in isolation groups

### 3.5.3. show Isolate-port group

This page is used to display isolation group information.

To display the “show Isolate-port group” page, click Port configuration ->Isolate-port configuration->show Isolate-port group, click "Apply" to view.

show Isolate-port group	
Group name	<input type="text"/>
<input type="button" value="Apply"/>	

### 3 Port configuration

<b>entry</b>	describe
<b>Group name</b>	Created isolation group name, example: aaaa

## 3.6. Port storm-control config

This chapter can set up storm control related functions.

### 3.6.1. Port storm-control config

This page can be configured for the storm control function of the port.

To display the "Port storm-control config" page, click Port configuration ->Port storm-control config->Port storm-control config, click "Apply" to configure.

storm-control configuration	
Port	Ethernet1/0/1 ▾
storm-control type	broadcast ▾
storm-control value	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>storm-control type</b>	Broadcast/Multicast/Unicast
<b>storm-control value</b>	storm control rate, ranging from 1-1000000 kbps or pps 1-1488095
<b>Operation</b>	Add: Turn on the storm control function and configure the speed limit Remove: Disable Storm Control

Information feedback window	
Port	storm-control type
Ethernet1/0/1	None
Ethernet1/0/2	None
Ethernet1/0/3	None
Ethernet1/0/4	None
Ethernet1/0/5	None
Ethernet1/0/6	None
Ethernet1/0/7	None
Ethernet1/0/8	None

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>storm-control type</b>	Broadcast/Multicast/Unicast

### 3.6.2. storm-control bypass configuration

This page can configure storm control unit, filter protocol, filter protocol status and other functions.

To display the "storm-control bypass configuration" page, click Port configuration ->Port storm-control config->storm-control bypass configuration, click "Apply" to configure.

storm-control configuration	
storm-control type:	bypass ▾
storm-control bypass protocol:	arp ▾
storm-control bypass protocol status:	disable ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>storm-control type</b>	Bypass: Bypass Protocol Kbps: Storm control rate units Pps: Storm control rate units
<b>storm-control bypass protocol</b>	Broadcast Storm Filter Agreement
<b>storm-control bypass protocol status</b>	Disable: Disable protocol filtering Enable: Enable protocol filtering

### 3 Port configuration

#### 3.7. Port rate-violation config

This chapter is mainly used for the configuration of rate limiting functions.

##### 3.7.1. rate-violation configuration

This page is mainly used to configure the rate limit function.

To display the "rate-violation configuration" page, click Port configuration ->Port rate-violation config -> rate-violation configuration, click "Apply" to configure.

Port rate-violation config	
Port	Ethernet1/0/1 ▾
rate-violation type	all ▾
rate-violation value	
rate-violation sub type	shutdown ▾
rate-violation recover time	
Operation	Add ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Port</b>	Ethernet port name
<b>rate-violation type</b>	Type of breach: All/Broadcast/Multicast/Unicast/ Control: Operation violation
<b>rate-violation value</b>	Limit rate, range 200-2000000
<b>rate-violation sub type</b>	Overspeed operation: Shutdown: Disable port Block: Block port
<b>rate-violation recover time</b>	The time when the port overspeed is automatically resumed after it is disabled, if the size is 0-86400 seconds, configuring 0 seconds means no automatic recovery
<b>Operation</b>	Add: Function Enable Remove: Function disabled

#### 3.8. Port virtual-cable-test config

This chapter can be used to detect port link lines.

### 3.8.1. virtual-cable-test configuration

This chapter can be used to detect port link lines.

To display the “virtual-cable-test configuration” page, click Port configuration ->Port virtual-cable-test config ->virtual-cable-test configuration, click "Apply" to configure.

**virtual-cable-test configuration**

<b>Port</b>	Ethernet1/0/1 <span style="font-size: small;">v</span>
<input type="button" value="Apply"/>	

**Information feedback window**

```
Switch# virtual-cable-test interface Ethernet1/0/14
Interface Ethernet1/0/14:
-----
Cable pairs      Cable status      Length (meters)
-----
(1, 2)           well              13
(3, 6)           well              13
(4, 5)           well              13
(7, 8)           well              13
```

<b>entry</b>	describe
<b>Port</b>	Ethernet port name

### 3.9. Port debug and maintenance

This section is mainly used to view port, overall traffic statistics, port rate violation configuration and other information view.

#### 3.9.1. Show port information

This page can be used to view port details.

To display the “Show port information” page, click Port configuration ->Port debug and maintenance->Show port information, click "Apply" to view.

### 3 Port configuration

Please select port: Ethernet1/0/1 ▾

---

**Information feedback window**

Interface brief:

```

Ethernet1/0/1 is down, line protocol is down
Ethernet1/0/1 is layer 2 port, alias name is (null), index is 1
Hardware is Gigabit-TX, address is 00-1f-ce-10-b0-1b
PVID is 1
MTU 1500 bytes, BW 10000 Kbit
Time since last status change: 0w-0d-0h-36m-32s (2192 seconds)
Encapsulation ARPA, Loopback not set
Auto-duplex , Auto-speed
FlowControl is off, MDI type is auto
    
```

#### 3.9.2. Show entire traffic information

This page can be used to view statistics of overall traffic.

To display the “Show entire traffic information” page, click Port configuration ->Port debug and maintenance->Show entire traffic information, click "Apply" to view.

Show entire traffic information										
Port	Receiving statistics					Transmitting statistics				
	Total packets	Error packets	Dropped packets	5 minute rate(packets/sec)	Last 5 second rate(packets/sec)	Total packets	Error packets	Dropped packets	5 minute rate(packets/sec)	Last 5 second rate(packets/sec)
Ethernet1/0/1	0	0	0	0	0	0	0	0	0	0
Ethernet1/0/2	0	0	0	0	0	0	0	0	0	0
Ethernet1/0/3	0	0	0	0	0	0	0	0	0	0
Ethernet1/0/4	0	0	0	0	0	0	0	0	0	0
Ethernet1/0/5	0	0	0	0	0	0	0	0	0	0
Ethernet1/0/6	0	0	0	0	0	0	0	0	0	0
Ethernet1/0/7	0	0	0	0	0	0	0	0	0	0
Ethernet1/0/8	0	0	0	0	0	0	0	0	0	0

#### 3.9.3. Show rate violation port

This page can be used to view port rate violation function configuration information.

To display the “Show rate violation port” page, click Port configuration ->Port debug and maintenance->Show rate violation port, click "Apply" to view.

Rate-violation port state information		
Port	Port rate-violation control mode	Rate-violation port state
Ethernet1/0/1	shutdown	down

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>Port rate-violation control mode</b>	Shutdown: Disable port Block: Block port
<b>Rate-violation port state</b>	Status of current port: Down: Not connected Up: Connected Forwarding: forward Block: block

### 3.10. uldp configuration

This chapter is mainly used for the configuration of single link detection function.

#### 3.10.1. uldp enable config

This page can be used to enable or disable single link detection protocols.

To display the “uldp enable config” page, click Port configuration -> uldp configuration-> uldp enable config, click "Apply" to configure.

uldp global enable configuration	
uldp global enable type	uldp enable ▾
Operation	Enable ▾
<input type="button" value="Apply"/>	

entry	describe
<b>uldp global enable type</b>	uldp enable: Turn on the ULDP function of all ports that support ULDP functions. uldp aggressive-mode: Configure all ports ULDP working mode for positive mode. uldp manual shutdown: global close auto disable port, switch to manual close port.
<b>Operation</b>	Enable: Function Enable Disable: Function Disable

uldp port enable configuration	
Port	Ethernet1/0/1 ▾
uldp port enable type	uldp port enable ▾
Operation	Enable ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Port</b>	Ethernet port name

### 3 Port configuration

<b>uldp port enable type</b>	uldp port enable: Turn on the ULDP function of the specified port. uldp port aggressive-mode: Configure the specified port ULDP working mode to positive mode.
<b>Operation</b>	Enable: Function Enable Disable: Function Disable

#### 3.10.2. uldp Hello message config

This page is used to Hello the message sending interval.

To display the “uldp Hello message config” page, click Port configuration -> uldp configuration->uldp Hello message config, click "Apply" to configure.

uldp Hello message config	
uldp Hello message time	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>uldp Hello message time</b>	Message sending interval, range 5-100 seconds
<b>Operation</b>	Configuration: User self-configuration Default: Restore the default configuration, the default configuration is 10 seconds.

#### 3.10.3. uldp recovery time config

This page can be used to configure ULDP auto recovery time.

To display the “uldp recovery time config” page, click Port configuration -> uldp configuration->uldp recovery time config, click "Apply" to configure.

uldp recovery time config	
uldp Hello message time	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>uldp Hello message time</b>	Automatic recovery time after the port is disabled, ranging from 30-86400 seconds to 0 seconds without automatic recovery
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration, default configuration is 0 seconds.

### 3.10.4. show uldp configuration

This page can be used to view port ULDP configuration information.

To display the “uldp recovery time config” page, click Port configuration -> uldp configuration->uldp recovery time config, click "Apply" to view.

**show uldp configuration**

Port

Information feedback window						
Switch# show uldp						
uldp enable						
uldp hello interval is 10						
uldp shut down mode is AUTO						
uldp global work mode is NORMAL						
the total number of the port is 4						
-----						
PortName	PhyLink	LineProto	WorkMode	PortState	NeighborNum	
-----						
Ethernet1/0/25	UP	DOWN	NORMAL	INACTIVE	0	
Ethernet1/0/26	UP	DOWN	NORMAL	INACTIVE	0	
Ethernet1/0/27	UP	DOWN	NORMAL	INACTIVE	0	
Ethernet1/0/28	UP	DOWN	NORMAL	INACTIVE	0	
-----						

## 3.11. LLDP configuration

This chapter can be used to configure LLDP related functions.

### 3.11.1. LLDP configuration

This page can be configured to enable or disable LLDP functionality.

To display the “LLDP configuration” page, click Port configuration ->LLDP configuration->LLDP configuration, click "Apply" to configure.

### 3 Port configuration

LLDP global enable configuration	
lldp enable	Enable ▾
Apply	

<b>entry</b>	describe
<b>lldp enable</b>	Enable: Global On LLDP Function Disable: Global Off LLDP Function

LLDP port enable configuration	
Port	Ethernet1/0/1 ▾
LLDP port enable type	LLDP port enable ▾
Operation	Enable ▾
Apply	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>LLDP port enable type</b>	Enable or disable LLDP functions
<b>Operation</b>	Turn on or off LLDP function

#### 3.11.2. LLDP port status config

This page can configure port status.

To display the "LLDP port status config" page, click Port configuration ->LLDP configuration->LLDP port status config, click "Apply" to configure.

LLDP port status config	
Port	Ethernet1/0/1 ▾
LLDP port status	send ▾
Apply	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name

<b>LLDP port status</b>	Send: Send only data Receive: Receive only data Both: Sending and receiving data simultaneously Disable: Both sending and receiving are prohibited
-------------------------	---

### 3.11.3. LLDP tx-interval config

This page can configure the interval between sending updates.

To display the “LLDP tx-interval config” page, click Port configuration ->LLDP configuration->LLDP tx-interval config, click "Apply" to configure.

LLDP tx-interval config	
LLDP Hello message time	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
<b>LLDP Hello message time</b>	Update message sending interval between 5-32768 seconds
<b>Operation</b>	Configuration: User self-configuration Default: Restore the default configuration, the default configuration is 30 seconds.

### 3.11.4. LLDP msgTxHold config

This page can configure the value of the message aging time multiplier.

To display the “LLDP msgTxHold config” page, click Port configuration ->LLDP configuration->LLDP msgTxHold config, click "Apply" to configure.

LLDP msgTxHold config	
LLDP msgTxHold value	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

**3 Port configuration**

<b>entry</b>	describe
<b>LLDP msgTxHold value</b>	Numerical magnitude between 2-10
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration, default configuration is 4

**3.11.5. LLDP transmit delay config**

This page can configure the sending delay time of the update message.

To display the “LLDP transmit delay config” page, click Port configuration ->LLDP configuration->LLDP transmit delay config, click "Apply" to configure.

LLDP transmit delay config	
LLDP transmit delay value	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>LLDP transmit delay value</b>	Value between 1-8192 seconds
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration for 2 seconds

**3.11.6. LLDP notification interval config**

This page can configure the interval between sending Trap messages.

To display the “LLDP notification interval config” page, click Port configuration ->LLDP configuration->LLDP notification interval config, click "Apply" to configure.

LLDP notification interval config	
LLDP notification interval value	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>LLDP notification interval value</b>	Value between 5 and 3600 seconds
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration for 5 seconds

### 3.11.7. LLDP neighbors max-num config

This page can be used to Remote Table the settings for save entries.

To display the “LLDP notification interval config” page, click Port configuration ->LLDP configuration->LLDP notification interval config, click "Apply" to configure.

LLDP neighbors max-num config	
Port	Ethernet1/0/1 ▾
LLDP neighbors max-num value	
Operation	Configuration ▾
<input type="button" value="Apply"/>	
<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>LLDP neighbors max-num value</b>	Remote table maximum save entry size 5-500
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration, default configuration is 100

### 3.11.8. LLDP too many neighbors config

This page can be used to set up operations after Remote Table is full.

To display the “LLDP too many neighbors config” page, click Port configuration ->LLDP configuration->LLDP too many neighbors config, click "Apply" to configure.

**3 Port configuration**

LLDP too mangy neighbors config	
Port	Ethernet1/0/1 ▾
LLDP too mangy neighbors value	discard ▾
Apply	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>LLDP too mangy neighbors value</b>	Discard: Discard new neighbor information  Delete: Delete the neighbor information with the least aging time in the remote table, and then add new neighbor information

**3.11.9. LLDP transmit optional tlv config**

This page can configure port TLV properties.

To display the “LLDP transmit optional tlv config” page, click Port configuration ->LLDP configuration->LLDP transmit optional tlv config, click "Apply" to configure.

LLDP transmit optional tlv config	
Port	Ethernet1/0/1 ▾
LLDP Port description	<input type="checkbox"/>
LLDP System capability	<input type="checkbox"/>
LLDP System description	<input type="checkbox"/>
LLDP System name	<input type="checkbox"/>
Apply	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>LLDP Port description</b>	Port description name information needs to be configured
<b>LLDP System capability</b>	Information describing system capabilities
<b>LLDP System description</b>	Message describing the system

<b>LLDP System name</b>	System name information
-------------------------	-------------------------

### 3.11.10. show LLDP configuration

This page can be used to view LLDP configuration messages.

To display the “show LLDP configuration” page, click Port configuration ->LLDP configuration->show LLDP configuration, click "Apply" to view.

show LLDP configuration	
LLDP too many neighbors value	show LLDP <input type="button" value="v"/>
Port	all <input type="button" value="v"/>
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show lldp
-----LLDP GLOBAL INFORMATIONS-----
LLDP has been disabled globally.
LLDP enabled port : NULL
LLDP interval :30
LLDP txTTL :120
LLDP NotificationInterval :5
LLDP txDelay :2
LLDP-MED FastStart Repeat Count :4
-----END-----
  
```

show LLDP configuration	
LLDP too many neighbors value	show LLDP port <input type="button" value="v"/>
Port	Ethernet1/0/14 <input type="button" value="v"/>
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show lldp
-----LLDP GLOBAL INFORMATIONS-----
LLDP has been disabled globally.
LLDP enabled port : NULL
LLDP interval :30
LLDP txTTL :120
LLDP NotificationInterval :5
LLDP txDelay :2
LLDP-MED FastStart Repeat Count :4
-----END-----
  
```

### 3 Port configuration

show LLDP configuration	
LLDP too many neighbors value	show LLDP ▼
Port	all ▼
<input type="button" value="Apply"/>	

Information feedback window							
Switch# show lldp traffic							
PortName	Ageouts	FramesDiscarded	FramesInErrors	FramesIn	FramesOut	TLVsDiscarded	TLVsUnrecognized
Ethernet1/0/14	0	0	0	0	0	0	0

show LLDP configuration	
LLDP too many neighbors value	show LLDP ▼
Port	all ▼
<input type="button" value="Apply"/>	

```
Information feedback window
Switch# show lldp neighbors interface Ethernet1/0/14
Port name : Ethernet1/0/14
Port Remote Counter : 1
TimeMark :3596
ChassisIdSubtype :4
ChassisId :00-0e-c6-bf-ad-7a
PortIdSubtype :MAC address
PortId :00-0e-c6-bf-ad-7a
*****:
```

### 3.12. LED shutoff configuration

This chapter can be used to set the timing of led lights out.

#### 3.12.1. Time Range configuration

This page can be used to set the time range for led lights to go out.

To display the "Time Range configuration" page, click Port configuration ->LED shutoff configuration->Time Range configuration, click "Apply" to configure.

Time range configuration	
Time range name	<input type="text"/>
Time range type	absolute <input type="checkbox"/>
Start Time	
Week	<input type="text"/>
Time	<input type="text"/>
Date	<input type="text"/>
End Time	
Week	<input type="text"/>
Time	<input type="text"/>
Date	<input type="text"/>
Operation type	Add <input type="checkbox"/>
<input type="button" value="Apply"/>	

entry	describe
<b>Time range name</b>	Time range name, length 1-64 characters
<b>Time range type</b>	Absolute: Absolute time range, date required Absolute-periodic: Absolute cycle time range Periodic: Period Time Range
<b>Week</b>	Range: 1-7
<b>Time</b>	Time format: 14:00
<b>Date</b>	Date Scope: 2001.1.1-2038.12.31

### 3 Port configuration

#### 3.12.2. LED shutoff config

This page can be used for LED timing extinguishing configuration.

To display the "LED shutoff config" page, click Port configuration ->LED shutoff configuration->LED shutoff config, click "Apply" to configure.

LED shutoff configuration	
Time range name	<input type="text" value=""/>
LED state	Open <input type="button" value="v"/>
Operation	Configuration <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
<b>Time range name</b>	With the configured time range name
<b>LED state</b>	LED lamp status
<b>Operation</b>	Configuration: User self-configuration Default: Function disabled

### 3.13. Jumbo packet forwarding configuration

This section can be used for the configuration of super packet forwarding.

To display the “LED shutoff config” page, click Port configuration ->LED shutoff configuration->LED shutoff config, click "Apply" to configure.

Jumbo packet forwarding configuration	
Jumbo packet size	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Jumbo packet size</b>	Range: 1500-12270
<b>Operation</b>	Configuration: User self-configuration Default: Function disabled

## 4 MAC address table configuration

### 4. MAC address table configuration

#### 4.1. MAC address table configuration

##### 4.1.1. MAC address aging-time configuration

Each time the switch learns a MAC address, it will store the address and set the aging time. When the time is over, the address will be removed from the switch.

MAC address aging-time configuration	
MAC address aging-time	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>MAC address aging-time</b>	The aging time range is 10-1000000, 0 means no aging	
<b>Operation</b>	Configuration	Set the aging time into the switch
	Default	Restore the aging time of the switch to the default state

MAC address aging-time
300

Display the current MAC address aging time.

##### 4.1.2. Configure MAC address

Configure static or Blackhole MAC addresses, and establish the mapping relationship between MAC addresses and ports and VLANs.

Configure static MAC address	
MAC address	<input type="text"/>
VLAN ID	1 ▾
Port list	Ethernet1/0/1 ▾
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>MAC address</b>	Hexadecimal MAC address, the format is xx-xx-xx-xx-xx-xx
<b>VLAN ID</b>	Created VLAN ID
<b>Port list</b>	Mapped port

<b>Operation</b>	Add	The mapping relationship between MAC address and port and VLAN will be added
	Remove	Delete the mapping relationship of the specified MAC address, VLAN, and port

Configure blackhole MAC address	
MAC address	<input type="text"/>
VLAN ID	1 ▾
Blackhole based type	▾
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>MAC address</b>	Hexadecimal MAC address, the format is xx-xx-xx-xx-xx-xx, packets with this address will be discarded and will not be forwarded to the network by the switch	
<b>VLAN ID</b>	Created VLAN ID	
<b>Blackhole based type</b>	source	Source based on source address filter
	destination	Target based on target address filter
	both	Both are based on source address and destination address filters, and the default value is both
<b>Operation</b>	Add	The mapping relationship between MAC address and port and VLAN will be added
	Remove	Delete the mapping relationship of the specified MAC address, VLAN, and port

MAC address	VLAN ID	Port
00-11-22-cc-bb-dd	1	Ethernet1/0/1
00-11-55-cc-bb-df	1	Blackhole

Display current existing MAC address, port, VALN mapping relationship

## 4 MAC address table configuration

### 4.1.3. Delete MAC address

Quickly delete the MAC address in the switch.

Delete MAC address		
Port status	Static ▼	
Delete by VLAN ID	1 ▼	<input type="checkbox"/> Select
Delete by MAC		<input type="checkbox"/> Select
Delete by port	Ethernet1/0/1 ▼	<input type="checkbox"/> Select
		<input type="button" value="Delete"/>

<b>Port status</b>	Static	User-created and assigned MAC address
	Dynamic	The MAC address automatically learned by the switch through the message
	Blackhole	The user creates the assigned MAC address, but the packet of this address will not be forwarded by the switch
<b>Delete by VLAN ID</b>	The created VLAN ID, delete the selected address type in the VLAN	
<b>Delete by MAC</b>	Hexadecimal MAC address, the format is xx-xx-xx-xx-xx-xx	
<b>Delete by port</b>	Delete all MAC addresses under the port	

MAC address	VLAN ID	Status
00-1a-33-44-de-fd	1	Ethernet1/0/1
10-55-df-98-77-55	1	Blackhole

Display the current mapping relationship between MAC address, VLAN ID, and port

### 4.1.4. MAC address query

Quickly query the MAC address in the switch.

MAC address query		
Port status	Static ▼	<input type="checkbox"/> Select
Query by MAC		<input type="checkbox"/> Select
Query by VLAN ID	1 ▼	<input type="checkbox"/> Select
Query by port	Ethernet1/0/1 ▼	<input type="checkbox"/> Select
		<input type="button" value="Apply"/>

<b>Port status</b>	Static	User-created and assigned MAC address
	Dynamic	The MAC address automatically learned by the switch through the message
	Blackhole	The user creates the assigned MAC address, but the packet of this address will not be forwarded by the switch
<b>Query by MAC</b>	Hexadecimal MAC address, the format is xx-xx-xx-xx-xx-xx	
<b>Query by VLAN ID</b>	The created VLAN ID, showing the address in the VLAN	
<b>Query by port</b>	Find the MAC address by port	

Note: Check the small box at the back to make the condition take effect. By default, there is no condition. When there is no condition, all MAC address information will be displayed.

Information feedback window				
Read mac address table....				
Vlan	Mac Address	Type	Creator	Ports
1	00-0e-c6-c7-93-15	STATIC	App	Ethernet1/0/8
1	10-f0-13-f1-72-3a	STATIC	System	CPU
2	00-11-33-55-88-66	STATIC	User	Ethernet1/0/4

Display the results of the query

**5 VLAN configuration**

**5. VLAN configuration**

**5.1. VLAN configuration**

**5.1.1. Create/Remove VLAN**

VLAN configuration function module, users add or delete VLANs in this module.

VLAN ID configuration	
VLAN ID	<input type="text"/>
VLAN Name	<input type="text"/>
VLAN Type	<input type="text" value="▼"/>
Operation	<input type="text" value="Add ▼"/>
<input type="button" value="Apply"/>	

<b>VLAN ID</b>	The serial number of the VLAN, range: 2-4094	
<b>VLAN name</b>	By default, the default is VLAN plus four-digit serial number, range: 1-64 characters.	
<b>VLAN type</b>	Private VLAN (isolated). Private VLAN (community). Private VLAN (primary). universal VLAN; There are three dedicated VLANs in the Primary port: Primary VLAN, Isolated VLAN and Community VLAN can communicate with the ports of the Isolated VLAN and Community VLAN related to this Primary VLAN; the ports in the Isolated VLAN are isolated from each other and are only related to it. The ports in the Primary VLAN communicate with each other; the ports in the Community VLAN can communicate with each other or with the related Primary VLAN ports; there is no communication between the ports in the Community VLAN and the ports in the Isolated VLAN. There is no communication between the ports in the Community VLAN and the ports in the Isolated VLAN.	
<b>Operation</b>	Add	Add VLAN
	Remove	Remove VLAN

VLAN ID information		
VLAN ID	VLAN Name	VLAN Type
1	default	universal vlan

### 5.1.2. Assign ports for VLAN

Assign ports to the VLAN, and users add and remove ports in the VLAN in this module.

Assign ports for VLAN	
VLAN ID	1 ▾
Port	Ethernet1/0/1 ▾
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>VLAN ID</b>	Created VLAN	
<b>Port</b>	Port name	
<b>Operation</b>	Add	Add port to VLAN
	Remove	Remove the port from the VLAN port list

Information feedback window					
Universal vlan:					
VLAN Name	Type	Media	Ports		
1	default	Static	ENET	Ethernet1/0/3 Ethernet1/0/5 Ethernet1/0/7 Ethernet1/0/9 Ethernet1/0/11 Ethernet1/0/13 Ethernet1/0/15 Ethernet1/0/17 Ethernet1/0/19 Ethernet1/0/21 Ethernet1/0/23 Ethernet1/0/25 Ethernet1/0/27	Ethernet1/0/4 Ethernet1/0/6(T) Ethernet1/0/8 Ethernet1/0/10  Ethernet1/0/14 Ethernet1/0/16 Ethernet1/0/18 Ethernet1/0/20 Ethernet1/0/22 Ethernet1/0/24 Ethernet1/0/26 Ethernet1/0/28
Private vlan:					
VLAN Name	Type	Asso VLAN	Ports		
2	test	Primary	4	Ethernet1/0/18 (T) Ethernet1/0/22 (T)	Ethernet1/0/20 (T)
4	R&D	Isolate	2	Ethernet1/0/2 (T) Ethernet1/0/6 (T) Ethernet1/0/20 (T)	Ethernet1/0/5 Ethernet1/0/18 (T) Ethernet1/0/22 (T)

## 5 VLAN configuration

### 5.1.3. Port type configuration

Switch port type setting, the user can change the switch port type in this module.

Port mode configuration	
Port	Ethernet1/0/1 ▼
Type	access ▼
State	Enable VLAN ingress check ▼
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>Type</b>	access	
	trunk	
	hybrid	
<b>State</b>	Enable VLAN ingress check	When a data packet enters the switch, the VLAN ingress filter checks whether the ingress port of the data packet belongs to the given (forwarded) VLAN
	Disable VLAN ingress check	When a data packet enters the switch, the VLAN ingress filter does not check whether the ingress port of the data packet belongs to the given (forwarded) VLAN

Port mode configuration		
Port	Type	State
Ethernet1/0/1	access	Open
Ethernet1/0/2	access	Open
Ethernet1/0/3	access	Open
Ethernet1/0/4	access	Open
Ethernet1/0/5	access	Open
Ethernet1/0/6	access	Open
Ethernet1/0/7	access	Open
Ethernet1/0/8	access	Open

### 5.1.4. Hybrid port configuration

Switch Hybrid port VLAN configuration, the user changes the attributes of the switch's Hybrid port type in this module

Set hybrid native VLAN	
Port	Ethernet1/0/4 ▼
Hybrid native VLAN	<input type="text"/>
Operation	Add ▼
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>Hybrid native VLAN</b>	PVID of the port, VLAN TAG when the port is sending and receiving data frames	
<b>Operation</b>	Add	Add port to VLAN
	Remove	Remove the port from the VLAN port list

Set hybrid allow VLAN	
Port	Ethernet1/0/4 ▼
Hybrid allowed VLAN list	<input type="text"/>
Operation	Add all ▼
Tagged	Untag ▼
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>Hybrid allowed VLAN list</b>	List of allowed VLANs, connected with "-" and ";"	
<b>Operation</b>	Add all	Add port to all VLANs, 1-4094
	Add	Add a VLAN to the list of existing passed VLANs
	Except add	Add the port to all VLANs outside the specified VLAN
	Cover add	Clear the original passed VLAN list, and then add the specified VLAN list to the VLAN list
	Remove	Remove the specified VLAN list from the existing passed VLAN list
<b>Tagged</b>	Untag method to join	
	Tag way to join	

## 5 VLAN configuration

Port	Hybrid native VLAN	Hybrid Tagged allowed VLAN list	Hybrid UnTagged allowed VLAN list
Ethernet1/0/4	1		

Display detailed information of Hybrid port

### 5.1.5. Trunk port configuration

Switch trunk port VLAN configuration, the user can change the attributes of the trunk port type of the switch in this module.

Set trunk native VLAN	
Port	Ethernet1/0/6 ▾
Trunk native VLAN	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>Trunk native VLAN</b>	PVID of the port, VLAN TAG when the port is sending and receiving data frames	
<b>Operation</b>	Add	Add port to VLAN
	Remove	Remove the port from the VLAN port list

Set trunk allow VLAN	
Port	Ethernet1/0/6 ▾
Trunk allowed VLAN list	<input type="text"/>
Operation	Add all ▾
<input type="button" value="Apply"/>	

<b>Port</b>	Port name
<b>Trunk allowed VLAN list</b>	List of allowed VLANs, connected with "-" and ";"

<b>Operation</b>	Add all	Add port to all VLANs, 1-4094
	Add	Add a VLAN to the list of existing passed VLANs
	Except add	Add the port to all VLANs outside the specified VLAN
	Cover add	Clear the original passed VLAN list, and then add the specified VLAN list to the VLAN list
	Remove	Remove the specified VLAN list from the existing passed VLAN list

Port	Trunk native VLAN	Trunk allowed VLAN list
Ethernet1/0/6	1	1-4094

Display the detailed information of the trunk port

### 5.1.6. Private-vlan configuration

Switch Private-vlan binding operation, the user binds the private-vlan relationship in this module.

Private-vlan association	
Designate Primary-vlan	<input type="text" value="v"/>
Association VLAN list	<input type="text"/>
Operation	Configuration <input type="text" value="v"/>
<input type="button" value="Apply"/>	

<b>Designate Primary-vlan</b>	Created Primary-vlan	
<b>Association VLAN list</b>	The secondary VLAN associated with the Primary-vlan, the secondary VLAN includes private vlan (isolated), private vlan (community)	
<b>Operation</b>	Configuration	Associate the secondary VLAN with the primary VLAN
	Default	Clear the primary-vlan association

Primary-vlan	Association VLAN list
2	4

Display the related information of Primary-vlan

## 5 VLAN configuration

### 5.2. GVRP configuration

#### 5.2.1. Enable global GVRP

The switch starts the global GVRP setting, and the user turns on or off the global GVRP.

Enable global GVRP	
Enable/Disable global GVRP	Disable ▾
<input type="button" value="Apply"/>	

<b>Enable/Disable global GVRP</b>	Enable	Start the global GVRP module function
	Disable	Disable the global GVRP module function

Enable global GVRP	
GVRP status	Disable

#### 5.2.2. Enable GVRP on port

The switch port starts GVRP settings, and the user opens or closes the port GVRP.

Enable GVRP on port	
Port	Ethernet1/0/4 ▾
Enable/Disable GVRP	Enable ▾
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>Enable/Disable GVRP</b>	Enable	Start the port GVRP module function
	Disable	Disable the port GVRP module function

Port	GVRP Status
Ethernet1/0/4	Disable
Ethernet1/0/6	Disable

Display the GVRP status of each port

#### 5.2.3. GARP configuration

The switch configures GARP parameters, and the user sets the value of various timers to manage GARP.

GARP parameters configuration	
Join timer	200
Leave timer	600
Leaveall timer	10000
Operation	Configuration ▾
Apply	

<b>Join timer</b>	200-500ms	
<b>Leave timer</b>	500-1200ms	
<b>Leaveall timer</b>	500-60000ms	
<b>Operation</b>	configuration	Modify the value of the timer
	default	Restore the timer value to the default configuration

### 5.3. VLAN-translation configuration

#### 5.3.1. Enable/Disable VLAN-translation

The switch port starts the VLAN-translation setting, and the user opens or closes the port VLAN-translation.

Enable/Disable VLAN-translation	
Port	Ethernet1/0/1 ▾
Enable/Disable VLAN-translation	Enable ▾
Apply	

Port	Port name	
<b>Enable/Disable VLAN-translation</b>	Enable	Enable the VLAN-translation function of the port
	Disable	Disable the VLAN-translation function of the port

## 5 VLAN configuration

Port	VLAN-translation Status
Ethernet1/0/1	Disable
Ethernet1/0/2	Disable
Ethernet1/0/3	Disable
Ethernet1/0/4	Disable
Ethernet1/0/5	Disable
Ethernet1/0/6	Disable
Ethernet1/0/7	Disable
Ethernet1/0/8	Disable

Display the VLAN-translation status of each port

### 5.3.2. Add/Delete VLAN-translation

Switch VLAN-translation conversion settings, the user sets the VLAN-translation conversion relationship.

Add/Delete VLAN-translation	
Port	Ethernet1/0/1 ▼
source vlan ID	Vlan1 ▼
destination vlan ID	Vlan1 ▼
dirction	in ▼
Operation	Add ▼
Apply	

<b>Port</b>	Port name	
<b>Source vlan ID</b>	Configured VLAN	
<b>Destination vlan ID</b>	Configured VLAN	
<b>dirction</b>	in	Configure the conversion direction of VLAN-translation as the ingress conversion function
	out	Configure the conversion direction of VLAN-translation as the egress conversion function
<b>Operation</b>	Add	Add VLAN-translation conversion relationship
	Remove	Remove VLAN-translation conversion relationship

### 5.3.3. VLAN-translation miss drop configuration

When the switch VLAN-translation fails to find the translation relationship, the packet loss settings are set. The user sets the direction of the packet loss configuration when the VLAN-translation finds the translation relationship.

VLAN-translation miss drop configuration	
Port	Ethernet1/0/1 ▾
dirction	both ▾
Operation	Configuration ▾
Apply	

Port	Port name	
<b>dirction</b>	both	The port performs VLAN-translation search and translation relationship configuration for packet loss at both the egress and the ingress
	in	Packet loss configuration when the port performs VLAN-translation lookup translation relationship at the ingress

	Out	Packet loss configuration when the port performs VLAN-translation lookup translation relationship at the egress
<b>Operation</b>	Configuration	Add VLAN-translation to find the packet loss configuration when searching for translation relations
	Cancel	Delete the configuration of packet loss when searching for translation relationship in VLAN-translation

#### 5.3.4. show VLAN-translation

The display of switch VLAN-translation related configuration, the user can check the switch VLAN-translation configuration.

show VLAN_translation	
Apply	

<b>Apply</b>	Confirm that you want to view VLAN-translation related configuration information
--------------	--

```

Information feedback window
Switch# show vlan-translation
Interface Ethernet1/0/1:
  vlan-translation is enable, miss drop is not set
    
```

Display VLAN-translation related configuration information

## 5 VLAN configuration

### 5.4. dynamic VLAN configuration

#### 5.4.1. VLAN protocol configuration

Switch VLAN protocol table entry configuration, user configuration protocol VLAN parameters to generate VLAN.

protocol vlan mode configuration	
VLAN interface	Vlan1 ▾
protocol mode	ethernetII ▾
protocol mode ID	<input type="text"/>
SSAP ID	<input type="text"/>
priority ID	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>VLAN interface</b>	Created VLAN	
<b>Protocol mode</b>	ethernetII	VLAN is divided according to data packets in ethernetII format
	snap	VLAN is divided according to data packets in snap format
	llc	VLAN is divided according to data packets in the LLC format
	all	Used when cancel operation, restore all protocol VLAN to static VLAN
<b>Protocol mode ID</b>	The ID range of ethernetII and snap is 1536-65535, and the ID range of llc is 0-255	
<b>SSAP ID</b>	It is only set in the llc protocol, range: 0-255	
<b>Priority ID</b>	Queue priority, range: 0-7	
<b>Operation</b>	configuration	Modify VLAN parameters and configure to dynamic protocol VLAN
	cancel	Restore VLAN from dynamic VLAN to static

```
Information feedback window
Switch# config
Switch(config)# protocol-vlan mode ethernetII etype 1536 vlan 1 priority 0
```

Display configuration info

## 5.5. Dot1q tunnel configuration

### 5.5.1.Enable dot1q tunnel

Switch dot1q tunnel configuration, the user configures the port to enable the dot1q tunnel function.

Enable dot1q tunnel	
Port	Ethernet1/0/1 ▾
Operation	Enable ▾
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>Operation</b>	Enable	Enable dot1q tunnel
	Disable	Disable dot1q tunnel

```

Information feedback window
Switch# config
Switch(config)# interface Ethernet1/0/1
Switch(config-if-ethernet1/0/1)# dot1q-tunnel enable
  
```

Display the execution process and results

### 5.5.2. dot1q tunnel tpid configuration

Switch port dot1q tunnel tpid configuration, users configure port dot1q tunnel tpid parameters.

Dot1q tunnel tpid configuration	
Port	Ethernet1/0/1 ▾
protocol	0x8100 ▾
protocol ID	<input type="text"/>
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>Protocol</b>	0x8100	Set the outer TPID to 0x8100
	0x9100	Set the outer TPID to 0x9100
	0x9200	Set the outer TPID to 0x9200
	protocol ID	Set a custom TPID
<b>Protocol ID</b>	The value of the custom TPID	

## 5 VLAN configuration

```
Information feedback window
Switch# config
Switch(config)# interface Ethernet1/0/1
Switch(config-if-ethernet1/0/1)# dot1q-tunnel tpid 0x8100
QinQ enabled in Ethernet1/0/1, please disable it first!
ERROR: set dot1q-tunnel tpid on Ethernet1/0/1 error
```

Display the execution process and results

## 6. IGMP Snooping configuration

### 6.1. Switch on-off IGMP Snooping

Switch IGMP Snooping global switch, snooping IGMP messages

Switch on-off IGMP Snooping	
Switch on-off IGMP Snooping	Close ▾
Apply	

<b>Switch on-off IGMP Snooping</b>	Open	Turn on the global switch of IGMP Snooping on the switch
	Close	Turn off the global switch of IGMP Snooping on the switch

Switch on-off IGMP Snooping	
Switch on-off IGMP Snooping	Close

Display the current global status of IGMP Snooping

### 6.2. IGMP Snooping port enable

Configure IGMP Snooping port switch.

IGMP Snooping VLAN config	
VLAN ID	vlan 1 ▾
Operation type	Open ▾
Apply	

<b>VLAN ID</b>	Created VLAN ID	
<b>Operation type</b>	Open	Open VLAN interface IGMP Snooping
	Close	Close VLAN interface IGMP Snooping

IGMP Snooping VLAN config	
VLAN ID	Operation type
1	OPEN

Display the current existing VLAN interface and the running status of IGMP Snooping under the VLAN interface

## 6 IGMP Snooping configuration

### 6.3. IGMP Snooping configuration

Configure IGMP Snooping based on VLAN interface.

Igmp Snooping Configuration		
VLAN ID	vlan 1 ▾	
Immediate leave configuration	immediate leave ▾	<input type="checkbox"/>
L2-general-querier configuration	L2-general-querier ▾	<input type="checkbox"/>
Group number	<input type="text"/>	<input type="checkbox"/>
Source table number	<input type="text"/>	<input type="checkbox"/>
Operation	Configuration ▾	
		Apply

<b>VLAN ID</b>	Created VLAN ID	
<b>Immediate leave configuration</b>	IGMP fast leave function in VLAN	
<b>L2-general-querier configuration</b>	Used to send regular queries regularly to help switches in this network segment learn the mrouter port	
<b>Group number</b>	The upper limit of the total number of groups. When the number of joined groups reaches the limit, the newly joined groups will be rejected to prevent hostile attacks. The default is 50, and the range: 1-65535.	
<b>Source table number</b>	The maximum number of source entries in each group, including include sources and exclude sources. The default is 40, and the range: 1-65535.	
<b>Operation</b>	Configuration	Configure the checked parameters into the selected VLAN
	Default	Restore the checked parameters to the default state

Note: Whether it is to configure parameters or restore the default state, it is required to check the box at the back to take effect. The group number and the number of source table entries are unified functions, so the two function parameters will take effect together (when one parameter is set, the other will be set to the default value).

VLAN ID	Immediate leave configuration	L2-general-querier configuration	Group number	Source table number
1	Disable	Disable	50	40

Display the configuration parameters of the existing VLAN

## 6.4. IGMP Snooping mrouter port configuration

IGMP Snooping mrouter port parameter configuration.

IGMP Snooping mrouter port configuration		
VLAN ID	vlan 1 ▼	
Mrouter port	Ethernet1/0/1 ▼	<input type="checkbox"/>
MRouter port alive time		<input type="checkbox"/>
Operation type	Add ▼	
		Apply

<b>VLAN ID</b>	Created VLAN ID	
<b>Mrouter port</b>	Port name	
<b>Mrouter port alive time</b>	Time to live of the port, range: 1-65535	
<b>Operation type</b>	Add	Add the mrouter port parameter configuration checked under the selected VLAN
	Remove	Delete the mrouter port parameter configuration checked under the selected VLAN

VLAN ID	Mrouter port	MRouter port alive time
1		255

Display current configuration information

## 6.5. IGMP Snooping query configuration

IGMP Snooping query parameter configuration.

IGMP Snooping query configuration		
VLAN ID	vlan 1 ▼	
Query-Interval		<input type="radio"/>
Query-mrsp configuration		<input type="radio"/>
Query-robustness configuration		<input type="radio"/>
Suppression-query-time configuration		<input type="radio"/>
Operation type	Add ▼	
		Apply

## 6 IGMP Snooping configuration

<b>VLAN ID</b>	Created VLAN ID	
<b>Query-Interval</b>	IGMP Snooping query interval, range: 1-65535	
<b>Query-mrsp configuration</b>	Maximum response time for group query	
<b>Query-robustness configuration</b>	IGMP Snooping robustness, range: 2-10	
<b>Suppression-query-time configuration</b>	Prohibited query time, range: 1-65535	
<b>Operation type</b>	Add	Add the mrouter port parameter configuration checked under the selected VLAN
	Remove	Delete the mrouter port parameter configuration checked under the selected VLAN

VLAN ID	Query-Interval	Query-mrsp configuration	Query-robustness configuration	Suppression-query-time configuration
1	125	10	2	255

Display current configuration information

## 7. MLD Snooping configuration

### 7.1. Switch on-off MLD Snooping

Configure MLD Snooping global status switch.

Switch on-off MLD Snooping	
Switch on-off MLD Snooping	Open ▼
Apply	

<b>Switch on-off MLD Snooping</b>	Open	Turn on the global switch of the switch MLD Snooping
	Close	Turn off the global switch of the switch MLD Snooping

### 7.2. MLD Snooping port enable

Configure MLD Snooping port switch.

MLD Snooping VLAN config	
VLAN ID	vlan 1 ▼
Operation type	Open ▼
Apply	

<b>VLAN ID</b>	Created VLAN ID	
<b>Operation type</b>	Open	Open VLAN interface MLD Snooping
	Close	Close VLAN interface MLD Snooping

## 7 MLD Snooping configuration

### 7.3. MLD Snooping configuration

MLD Snooping configuration based on VLAN interface.

MLD Snooping Configuration		
VLAN ID	vlan 1 ▾	
Immediate leave configuration	immediate leave ▾	<input type="checkbox"/>
L2-general-querier configuration	L2-general-querier ▾	<input type="checkbox"/>
Group number	<input type="text"/>	<input type="checkbox"/>
Source table number	<input type="text"/>	<input type="checkbox"/>
Operation	Configuration ▾	
		Apply

<b>VLAN ID</b>	Create VLAN ID	
<b>Immediate leave configuration</b>	MLD fast leave function in VLAN	
<b>L2-general-querier configuration</b>	Used to send regular queries regularly to help switches in this network segment learn the mrouter port	
<b>Group number</b>	The upper limit of the total number of groups. When the number of joined groups reaches the limit, the newly joined groups will be rejected to prevent hostile attacks. The default is 50, and the range: 1-65535.	
<b>Source table number</b>	The maximum number of source entries in each group, including include sources and exclude sources. The default is 40, and the range: 1-65535.	
<b>Operation</b>	Configuration	Configure the checked parameters into the selected VLAN
	Default	Restore the checked parameters to the default state

Note: Whether it is to configure parameters or restore the default state, it is required to check the box at the back to take effect. The group number and the number of source table entries are unified functions, so the two function parameters will take effect together (when one parameter is set, the other will be set to the default value).

## 7.4. MLD Snooping mrouter port configuration

MLD Snooping MRouter port parameter configuration.

MLD Snooping mrouter port configuration		
VLAN ID	vlan 1 ▼	
Mrouter port	Ethernet1/0/1 ▼	<input type="checkbox"/>
MRouter port alive time		<input type="checkbox"/>
Operation type	Add ▼	
		Apply

<b>VLAN ID</b>	Created VLAN ID	
<b>Mrouter port</b>	Port name	
<b>MRouter port alive time</b>	Time to live of the port, range: 1-65535	
<b>Operation type</b>	Add	Add the mrouter port parameter configuration checked under the selected VLAN
	Remove	Delete the mrouter port parameter configuration checked under the selected VLAN

## 7.5. MLD Snooping query configuration

MLD Snooping query parameter configuration.

MLD Snooping query configuration		
VLAN ID	vlan 1 ▼	
Query-Interval		<input type="radio"/>
Query-mrsp configuration		<input type="radio"/>
Query-robustness configuration		<input type="radio"/>
Suppression-query-time configuration		<input type="radio"/>
Operation type	Add ▼	
		Apply

<b>VLAN ID</b>	Created VLAN ID
<b>Query-Interval</b>	MLD Snooping query interval, range: 1-65535
<b>Query-mrsp</b>	Maximum response time for group query

## 7 MLD Snooping configuration

<b>configuration</b>		
<b>Query-robustness configuration</b>	MLD Snooping robustness, range: 2-10	
<b>Suppression-query-time configuration</b>	Prohibited query time, range: 1-65535	
<b>Operation type</b>	Add	Add the mrouter port parameter configuration checked under the selected VLAN
	Remove	Delete the mrouter port parameter configuration checked under the selected VLAN

## 8. Time Range configuration

### 8.1. Time Range configuration

Time Range configuration module, the user can add or delete the operation of this module, which can be applied to various ACL.

In the absolute mode you must input the start-time, end-time is not necessary.

You must input the weeks, start-time and end-time, but need not input the date including start and end time in the absolute-periodic.

You must input the weeks, start-time and end-time, but need not input the date including start and end time, and may input multi-week values, separate them with ",", such as: 1-7: Monday-Sunday; 31: daily; 96: weekdays; 127: weekend.

Input date format: YYYY.MM.DD. Input week format: number (1: Monday etc.), if input multi-week values, separate them with ",", such as: 1, 2 identify Monday & Tuesday.

Input time format: HH:MM:SS.

Time range configuration	
Time range name	<input type="text"/>
Time range type	absolute <input type="checkbox"/>
Start Time	<input type="text"/>
Week	<input type="text"/>
Time	<input type="text"/>
Date	<input type="text"/>
End Time	<input type="text"/>
Week	<input type="text"/>
Time	<input type="text"/>
Date	<input type="text"/>
Operation type	Add <input type="checkbox"/>
<input type="button" value="Apply"/>	

<b>Time range name</b>	Time period names must begin with alphabetic or numeric characters, 1-64 characters	
<b>Time range type</b>	absolute	Absolutely
	absolute-periodic	Absolute-periodic
	periodic	periodic
<b>Week</b>	Start or end weeks, "1-7": "monday-sunday"; "31": "daily"; "96": "weekdays"; "127": "weekend"	
<b>Time</b>	Start or end time, HH:MM:SS	
<b>Date</b>	Start or end date, YYYY.MM.DD, range 2001.1.1-2038.12.31	
<b>Operation type</b>	Add	Add operations
	Remove	Delete operations

## 9. ACL configuration

### 9.1. Numeric ACL

#### 9.1.1. Standard numeric ACL

##### 9.1.1.1. IP standard ACL

The digital standard IP access list configuration module, where users can create or modify parameters for the digital standard IP access list.

IP standard ACL(Number)	
List name	
Rule	permit ▼
Source address type	Any IP ▼
Source IP	
Reverse network mask	
tpid	
VLANID	
VLANID mask	
dscp	
Apply	

<b>List name</b>	Digital Standard IP Access List Number 1-99	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Source IP</b>	Source IP address, decimal point	
<b>Reverse network mask</b>	Source IP address mask, decimal point	
<b>tpid</b>	Label Protocol Identification, 0-65535	
<b>VLANID</b>	VLAN ID, 1-4094	
<b>VLANID mask</b>	VLAN mask, 0-4095	
<b>dcsp</b>	IP message priority, 0-63	

##### 9.1.1.2. MAC standard ACL

The digital standard MAC access list configuration module, where users can create or modify parameters for the digital standard MAC access list.

MAC standard ACL(Number)	
List name	
Rule	permit ▼
Source address type	Any MAC ▼
Source MAC	
Reverse network mask	
Apply	

<b>List name</b>	Digital Standard MAC Access List Number 700-799	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Any MAC	Match any MAC address
	Specified MAC	Match MAC specified address
	Host MAC	Match the specified host MAC
<b>Source MAC</b>	Source MAC address	
<b>Reverse network mask</b>	source MAC address inverse mask	

## 9.1.2. Extended numeric ACL

### 9.1.2.1. IP extended ACL

Digital extension IP access list configuration module, where users can create or modify parameters for digital extension IP access list.

IP extended ACL(Number)	
Operation type	ICMP ▼
List name	
Rule	permit ▼
Fragment packet	<input type="checkbox"/>
Source address type	Any IP ▼
Source IP	
Reverse network mask	
Destination address type	Any IP ▼
Destination IP	
Reverse network mask	
IP precedence	
TOS	
Time range name	▼
ICMP extended	
ICMP type	
ICMP code	
Apply	

## 9 ACL configuration

<b>Operation type</b>	Extended operation type: ICMP/IGMP/TCP/UDP/EIGRP/GRE/IGRP/IPINIP/OSPF/IP or Specified_protocol	
<b>List name</b>	Digital extensions IP access list numbers, 100-199	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Fragment packet</b>	Optional whether long messages are transmitted in pieces	
<b>Source address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Source IP</b>	Source IP address, decimal point	
<b>Reverse network mask</b>	Source IP address mask, decimal point	
<b>Destination address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Destination IP</b>	Destination IP, decimal points	
<b>Reverse network mask</b>	Destination IP address mask, decimal point	
<b>IP precedence</b>	IP priority, 0-7	
<b>TOS</b>	Service type, 0-15	
<b>Time range name</b>	Time period names to be applied must begin with alphabetic or numeric characters, 1-64 characters	
<b>ICMP type</b>	ICMP message type, 0-255	
<b>ICMP code</b>	ICMP message code, 0-255	

### 9.1.2.2. MAC-IP extended ACL

Digital extension MAC-IP access list configuration module, where users can create or modify parameters for digital extension MAC-IP access list.

MAC-IP extended ACL(Number)	
Operation type	ICMP ▾
List name	
Rule	permit ▾
Source address type	Any MAC ▾
Source MAC	
Reverse network mask	
Destination address type	Any MAC ▾
Destination MAC	
Reverse network mask	
Source address type	Any IP ▾
Source IP	
Reverse network mask	
Destination address type	Any IP ▾
Destination IP	
Reverse network mask	
tpid	
VLANID	
VLANID mask	
dscp	
IP precedence	
TOS	
Time range name	
ICMP extended	
ICMP type	
ICMP code	
Apply	

<b>Operation type</b>	Extension operation type: ICMP/IGMP/TCP/UDP/EIGRP/GRE/IGRP/IPINIP/OSPF/IP or Specified_protocol	
<b>List name</b>	Digital Extension MAC-IP Access List Number, 3100-3199	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Any MAC	Match any MAC address
	Specified MAC	Match MAC specified address
	Host MAC	Match the specified host MAC
<b>Source MAC</b>	Source MAC address	
<b>Reverse network mask</b>	source MAC address inverse mask	

## 9 ACL configuration

<b>Destination address type</b>	Any MAC	Match any MAC address
	Specified MAC	Match MAC specified address
	Host MAC	Match the specified host MAC
<b>Destination MAC</b>	Destination MAC address	
<b>Reverse network mask</b>	Destination MAC address inverse mask	
<b>Source address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Source IP</b>	Source IP address, decimal point	
<b>Reverse network mask</b>	Source IP address mask, decimal point	
<b>Destination address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Destination IP</b>	Destination IP, decimal points	
<b>Reverse network mask</b>	Destination IP address mask, decimal point	
<b>tpid</b>	Label Protocol Identification, 0-65535	
<b>VLANID</b>	VLAN ID, 1-4094	
<b>VLANID mask</b>	VLAN mask, 0-4095	
<b>dcsp</b>	IP message priority 0-63	
<b>IP precedence</b>	IP priority, 0-7	
<b>TOS</b>	Service type, 0-15	
<b>Time range name</b>	Time period names to be applied must begin with alphabetic or numeric characters, 1-64 characters	
<b>ICMP type</b>	ICMP message type, 0-255	
<b>ICMP code</b>	ICMP message code, 0-255	

### 9.1.3. Delete Numeric ACL

Delete the digital access list module, where the user can delete the specified digital access list.

Delete Numeric ACL	
List name	<input type="text"/>
Apply	

<b>List name</b>	Specify numeric access list numbers, 1-3199
------------------	---

## 9.2. Name ACL

### 9.2.1. Standard name ACL

#### 9.2.1.1. IP standard ACL

Naming standard IP access list configuration module, where users can create or modify parameters for naming standard IP access list.

IP standard ACL	
List name	<input type="text"/>
Rule	permit ▼
Source address type	Any IP ▼
Source IP	<input type="text"/>
Reverse network mask	<input type="text"/>
tpid	<input type="text"/>
VLANID	<input type="text"/>
VLANID mask	<input type="text"/>
dscp	<input type="text"/>
<input type="button" value="Apply"/>	

<b>List name</b>	Nomenclature criteria IP access list names, strings must start with letters, 1-64 characters	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Source IP</b>	Source IP address, decimal point	
<b>Reverse network mask</b>	Source IP address mask, decimal point	
<b>tpid</b>	Label Protocol Identification, 0-65535	
<b>VLANID</b>	VLAN ID, 1-4094	
<b>VLANID mask</b>	VLAN mask, 0-4095	
<b>dcsp</b>	IP message priority 0-63	

### 9.2.2. Extended name ACL

#### 9.2.2.1. IP extended ACL

Name extension IP access list configuration module, where users can create or modify parameters for named extension IP access list.

## 9 ACL configuration

IP extended ACL	
Operation type	ICMP ▾
List name	<input type="text"/>
Rule	permit ▾
Source address type	Any IP ▾
Source IP	<input type="text"/>
Reverse network mask	<input type="text"/>
Destination address type	Any IP ▾
Destination IP	<input type="text"/>
Reverse network mask	<input type="text"/>
IP precedence	<input type="text"/>
TOS	<input type="text"/>
Time range name	<input type="text"/>

ICMP extended	
ICMP type	<input type="text"/>
ICMP code	<input type="text"/>
<input type="button" value="Apply"/>	

<b>Operation type</b>	Extension operation type: ICMP/IGMP/TCP/UDP/EIGRP/GRE/IGRP/IPINIP/OSPF/IP or Specified_protocol	
<b>List name</b>	Name extensions IP access list names, strings must start with letters, 1-64 characters	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Fragment packet</b>	Optional whether long messages are transmitted in pieces	
<b>Source address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Source IP</b>	Source IP address, decimal point	
<b>Reverse network mask</b>	Source IP address mask, decimal point	
<b>Destination address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Destination IP</b>	Destination IP, decimal points	
<b>Reverse network mask</b>	Destination IP address mask, decimal point	
<b>IP precedence</b>	IP priority, 0-7	
<b>TOS</b>	Service type, 0-15	
<b>Time range name</b>	Time period names to be applied must begin with alphabetic or numeric characters, 1-64 characters	

<b>ICMP type</b>	ICMP message type, 0-255
------------------	--------------------------

### 9.2.2.2. MAC extended ACL

Name extension MAC access list configuration module, where users can create or modify parameters for named extension MAC access list.

MAC extended ACL	
List name	<input type="text"/>
Rule	permit ▼
Source address type	Any MAC ▼
Source MAC	<input type="text"/>
Reverse network mask	<input type="text"/>
Destination address type	Any MAC ▼
Destination MAC	<input type="text"/>
Reverse network mask	<input type="text"/>
Packet type	none ▼
cos	<input type="text"/>
cos mask	<input type="text"/>
VLANID	<input type="text"/>
VLANID mask	<input type="text"/>
etherType	<input type="text"/>
etherType mask	<input type="text"/>
Apply	

<b>List name</b>	Digital Extension MAC-IP Access List Number, 3100-3199	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Any MAC	Match any MAC address
	Specified MAC	Match MAC specified address
	Host MAC	Match the specified host MAC
<b>Source MAC</b>	Source MAC address	
<b>Reverse network mask</b>	source MAC address inverse mask	
<b>Destination address type</b>	Any MAC	Match any MAC address
	Specified MAC	Match MAC specified address
	Host MAC	Match the specified host MAC
<b>Destination MAC</b>	Destination MAC address	
<b>Reverse network mask</b>	Destination MAC address inverse mask	

## 9 ACL configuration

<b>Packet type</b>	none	none
	tagged-802-3	Format of marked Ethernet 802-3 packets
	tagged-eth2	Format of marked Ethernet II packets
	untagged-802-3	Format of unmarked Ethernet 802-3 packets
	untagged-eth2	Format of unmarked Ethernet II packets
<b>cos</b>	Cos, 0-7	
<b>cos mask</b>	cos mask, 0-7	
<b>VLANID</b>	VLAN ID, 1-4094	
<b>VLANID mask</b>	VLAN mask, 0-4095	
<b>etherType</b>	Ethernet type field value, 1536-65535	
<b>etherType mask</b>	Ethernet type field value mask, 0-65535	

### 9.2.2.3. MAC-IP extended ACL

Name extension MAC-IP access list configuration module, where users can create or modify parameters for named extension MAC-IP access list.

MAC-IP extended ACL	
Operation type	ICMP ▾
List name	
Rule	permit ▾
Source address type	Any MAC ▾
Source MAC	
Reverse network mask	
Destination address type	Any MAC ▾
Destination MAC	
Reverse network mask	
Source address type	Any IP ▾
Source IP	
Reverse network mask	
Destination address type	Any IP ▾
Destination IP	
Reverse network mask	
tpid	
VLANID	
VLANID mask	
dscp	
IP precedence	
TOS	
Time range name	
ICMP extended	
ICMP type	
ICMP code	
Apply	

<b>Operation type</b>	Extension operation type: ICMP/IGMP/TCP/UDP/EIGRP/GRE/IGRP/IPINIP/OSPF/IP or Specified_protocol	
<b>List name</b>	Digital Extension MAC-IP Access List Number ,3100-3199	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Any MAC	Match any MAC address
	Specified MAC	Match MAC specified address
	Host MAC	Match the specified host MAC
<b>Source MAC</b>	Source MAC address	
<b>Reverse network mask</b>	source MAC address inverse mask	

## 9 ACL configuration

<b>Destination address type</b>	Any MAC	Match any MAC address
	Specified MAC	Match MAC specified address
	Host MAC	Match the specified host MAC
<b>Destination MAC</b>	Destination MAC address	
<b>Reverse network mask</b>	Destination MAC address inverse mask	
<b>Source address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Source IP</b>	Source IP address, decimal point	
<b>Reverse network mask</b>	Source IP address mask, decimal point	
<b>Destination address type</b>	Any IP	Match any IP address
	Specified IP	Match IP specified address
	Host IP	Match the specified host IP
<b>Destination IP</b>	Destination IP, decimal points	
<b>Reverse network mask</b>	Destination IP address mask, decimal point	
<b>tpid</b>	Label Protocol Identification, 0-65535	
<b>VLANID</b>	VLAN ID, 1-4094	
<b>VLANID mask</b>	VLAN mask, 0-4095	
<b>dcsp</b>	IP message priority 0-63	
<b>IP precedence</b>	IP priority, 0-7	
<b>TOS</b>	Service type, 0-15	
<b>Time range name</b>	Time period names to be applied must begin with alphabetic or numeric characters, 1-64 characters	
<b>ICMP type</b>	ICMP message type, 0-255	
<b>ICMP code</b>	ICMP message code, 0-255	

### 9.2.3. Delete Name ACL

Delete the named access list module, where users can delete the specified named access list.

Delete Name ACL	
List name	<input type="text"/>
<input type="button" value="Apply"/>	

<b>List name</b>	String must start with a letter, 1-64 characters
------------------	--

### 9.3. Filter configuration

#### 9.3.1. Firewall configuration

Firewall ACL configuration module in which users can operate switch firewall configuration.

Switch firewall configuration	
Packet filtering	open ▼
Firewall default action	permit ▼
Apply	

<b>Packet filtering</b>	open	open
	close	close
<b>Firewall default action</b>	permit	Rule permit
	deny	Rule deny

### 9.4. Show ACL configuration

#### 9.4.1. Show access list

The access control list module is displayed in which the user can display ACL specified information or all ACL information.

Show access list	
Access list	ALL
Apply	

<b>Access list</b>	Specify the ACL name or number to display ALL display all ACL
--------------------	---

#### 9.4.2. Show firewall

Display packet filtering function configuration information module, user in this module can display firewall status information.

Show firewall	
Refresh	

## 9 ACL configuration

### 9.4.3. Show time range

Display time range function configuration information module, where users can display configured custom time information.

Show time range	
Time-range name	ALL
Apply	

<b>Time-range name</b>	Specifies the time period name to display, ALL displays all time period information
------------------------	---

## 9.5. ACL binding configuration

### 9.5.1. Attach ACL to port

ACL port binding module, the user can bind and delete the access list of the specified port.

Attach ACL to port	
Port	Ethernet1/0/1
ACL type	IP
List name	
ACL Attached Direction	in
Operation type	Add
Apply	

<b>Port</b>	Designated port number	
<b>ACL type</b>	IP	IP type
	MAC	MAC type
	MAC-IP	MAC-IP type
<b>List name</b>	Specify access list name, 1-64 characters	
<b>ACL Attached Direction</b>	in	Application ACL only
	in and traffic-statistics	Application ACL and flow monitoring
<b>Operation type</b>	Add	Add operations
	Remove	Delete operations

### 9.5.2. Show access group

The configuration information module on ACL display port, where the user can display the ACL binding information of the specified port or all ports.

Show access group	
Port	ALL
ACL Attached Direction	in
Apply	

<b>Port</b>	Specifies the port number to display the information ALL displays all port information	
<b>ACL Attached Direction</b>	in	Application ACL only
	in and traffic-statistics	Application ACL and flow monitoring

### 9.5.3. Clear Pacl Statistic

The statistical information module ACL the port, where the user can clear the ACL statistics of the specified port.

Clear Pacl Statistic	
Port or Interface name	Ethernet1/0/1 ▼
ACL Attached Direction	in ▼
Apply	

<b>Port or Interface name</b>	Specifies the port number to clear statistics	
<b>ACL Attached Direction</b>	in	Application ACL only
	in and traffic-statistics	Application ACL and flow monitoring

### 9.5.4. Attach ACL to vlan

ACL vlan binding module, where users can bind and delete access lists to specified VLAN.

Attach ACL to vlan	
VLAN interface	Vlan1 ▼
ACL type	IP ▼
List name	
ACL Attached Direction	in ▼
Operation type	Add ▼
Apply	

<b>VLAN interface</b>	Specifies the VLAN number to operate on	
<b>ACL type</b>	Specifies the type of ACL to bind: IP.MAC.MAC-IP	
<b>List name</b>	Specify access list name, 1-64 characters	
<b>ACL Attached Direction</b>	in	Application ACL only
	in and traffic-statistics	Application ACL and flow monitoring
<b>Operation type</b>	Add	Add operations
	Remove	Delete operations

## 9 ACL configuration

### 9.5.5. show vacl configuration

The vlan acl configuration information module is displayed in which the user can display ACL binding information for the specified VLAN or all VLAN.

show vacl configuration	
VLAN interface	Vlan1 ▾
ACL Attached Direction	in ▾
<input type="button" value="Apply"/>	

### 9.5.6. clear vlan acl statistic

Clear the VLAN acl statistical information module, where the user can clear the ACL statistics of the specified VLAN.

clear vlan acl statistic	
VLAN interface	Vlan1 ▾
ACL Attached Direction	in ▾
<input type="button" value="Apply"/>	

<b>VLAN interface</b>	Specifies the VLAN number to clear statistics	
<b>ACL Attached Direction</b>	in	Application ACL only
	in and traffic-statistics	Application ACL and flow monitoring

## 10. IPv6 ACL configuration

### 10.1. IPv6 standard access-list configuration

IPv6 standard access list configuration module, users can create, delete or modify parameters for digital standard IPv6 access lists.

IPv6 standard access-list configuration	
Access list number	<input type="text"/>
Rule	permit ▼
Source address type	host-source ▼
IPv6 address	<input type="text"/>
Operation	Add ▼
<input type="button" value="Apply"/>	

<b>Access list number</b>	Digital Standard IPv6 Access List Number, 500-599	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Specifies IPv6 source host	Matches IPv6 specified source host
	All IPv6 source hosts	Match any IPv6 source host
	IPv6 source address	Match IPv6 specified source address
<b>IPv6 address</b>	IPv6 address to operate	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 10.2. IPv6 name access-list configuration

IPv6 named access table configuration module, the user can create, delete, or modify parameters on the named standard IPv6 access list.

IPv6 name access-list configuration	
IPv6 name access-list	<input type="text"/>
Rule	▼
Source address type	host-source ▼
IPv6 address	<input type="text"/>
Operation	Add ▼
<input type="button" value="Apply"/>	

## 10 IPv6 ACL configuration

<b>IPv6 name access-list</b>	Name of access list	
<b>Rule</b>	permit	Rule permit
	deny	Rule deny
<b>Source address type</b>	Specifies IPv6 source host	Matches IPv6 specified source host
	All IPv6 source hosts	Match any IPv6 source host
	IPv6 source address	Match IPv6 specified source address
<b>IPv6 address</b>	IPv6 address to operate	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 10.3. Show IPv6 access list

Show IPv6 access control list module where users can display IPv6 access list to create, delete, or modify parameters.

Show IPv6 access list	
List name	<input type="text"/>
<input type="button" value="Apply"/>	

<b>List name</b>	Specifies the ACL name or number to display, 0-64 characters
------------------	--

### 10.4. Attach IPv6 ACL to port

IPv6ACL port binding module, the user can bind and delete the IPv6 access list on the specified port.

Attach IPv6 ACL to port	
Port	Ethernet1/0/1 <input type="button" value="v"/>
List name	<input type="text"/>
ACL Attached Direction	in <input type="button" value="v"/>
Operation type	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Port</b>	Designated port number
<b>List name</b>	Specify access list name, 1-64 characters

<b>ACL Attached Direction</b>	in	Application ACL only
	in and traffic-statistics	Application ACL and flow monitoring
<b>Operation type</b>	Add	Add operations
	Remove	Delete operations

### 10.5. Attach IPv6 ACL to vlan

IPv6ACL VLAN binding module, the user can bind and delete the IPv6 access list to the specified VLAN.

Attach IPv6 ACL to vlan	
VLAN interface	Vlan1 <input type="button" value="v"/>
List name	<input type="text"/>
ACL Attached Direction	in <input type="button" value="v"/>
Operation type	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>VLAN interface</b>	VLAN number specified	
<b>List name</b>	Specify access list name, 1-64 characters	
<b>ACL Attached Direction</b>	in	Application ACL only
	in and traffic-statistics	Application ACL and flow monitoring
<b>Operation type</b>	Add	Add operations
	Remove	Delete operations

## 11 AM configuration

### 11. AM configuration

#### 11.1. AM global configuration

##### 11.1.1. Enable/Disable AM

AM switch configuration module, the user can start or close the global AM function in this module.

Enable/Disable AM	
AM status	Enable ▾
Apply	

Information feedback window	
AM status	Enable

#### 11.2. AM port configuration

##### 11.2.1. Enable/Disable AM port

AM port switch configuration module, where the user can start or close the AM function of the specified port.

Enable/Disable AM port	
Port	AM port status
Ethernet1/0/1 ▾	Enable ▾
Apply	

Information feedback window	
Port	AM port status
Ethernet1/0/1	Disable
Ethernet1/0/2	Disable
Ethernet1/0/3	Disable
Ethernet1/0/4	Disable

<b>Port</b>	Specifies the port number
<b>AM port status</b>	enable or disable

##### 11.2.2. AM IP-Pool configuration

AM IP-Pool configuration module, the user can set up an AM IP segment on the specified port, allowing / rejecting messages from within the segment to be forwarded through the port.

AM IP-Pool configuration	
Port	Ethernet1/0/1 ▾
IP address	
Count	
Operation	Add ▾
Apply	

<b>Port</b>	Designated port number	
<b>IP address</b>	Beginning IP address, decimal point	
<b>Count</b>	Number of consecutive addresses after starting IP address, 1-32	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 11.2.3. AM MAC-IP-Pool configuration

AM MAC-IP-Pool configuration module, the user can set up an AM MAC-IP segment on the specified port, allowing / rejecting messages from within the segment to be forwarded through the port.

AM MAC-IP-Pool configuration	
Port	Ethernet1/0/1 ▾
IP address	
MAC address	
Operation	Add ▾
Apply	

<b>Port</b>	Designated port number	
<b>IP address</b>	Beginning IP address, decimal point	
<b>MAC address</b>	Source MAC address	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

## 11.3. Show AM port configuration

### 11.3.1. Show AM port configuration

The AM port configuration module is displayed in which the user can display the AM function configuration information of the specified port.

Show AM port configuration	
Port	▾
Apply	

<b>Port</b>	Designated port number
-------------	------------------------

## 11 AM configuration

### 11.3.2. Clear port AM Pool

AM Pool address pool cleanup module, where users can configure the specified AM Pool to clear.

Clear port AM Pool	
Operation	all ▼
<input type="button" value="Apply"/>	

<b>Operation</b>	all	Clear all AM Pool
	IP-pool	Clear IP-pool only
	mac-ip-pool	Clear mac-IP-pool only

## 12. Port channel configuration

Configure port related features settings using the Port Channel configuration page.

### 12.1. LACP port group configuration

This section can be used to create convergent groups.

To display the "LACP port group configuration" page click Port channel configuration->LACP port group configuration click "Apply" to configure.

LACP port group configuration	
Group number	<input type="text"/>
Load balance mode	src-mac <input type="button" value="v"/>
<input type="button" value="set"/> <input type="button" value="Reset"/>	

entry	describe
<b>Group number</b>	Range: 1-128
<b>Load balance mode</b>	<p><b>src-mac:</b> Execute load balancing according to source MAC</p> <p><b>dst-mac:</b> Execute load balancing according to target MAC</p> <p><b>dst-src-mac:</b> Execute load balancing based on source and target MAC</p> <p><b>src-ip:</b> Execute load balancing according to source IP</p> <p><b>dst-ip:</b> Execute load balancing according to target IP</p> <p><b>dst-src-ip:</b> Execute load balancing according to target IP source</p> <p><b>dst-src-mac-ip:</b> Perform load balancing based on target and source Mac and source IP</p>

## 12 Port channel configuration

Port group table			
Group number	Group member size	Load balance	Operation
1	0	src-mac	<a href="#">Add member</a> <a href="#">Remove member</a> <a href="#">Show interface</a>

<b>entry</b>	describe
<b>Group number</b>	Convergence group created, size range: 1-128
<b>Group member size</b>	Number of members in convergent groups
<b>Load balance mode</b>	<p><b>src-mac:</b> Execute load balancing according to source MAC</p> <p><b>dst-mac:</b> Execute load balancing according to target MAC</p> <p><b>dst-src-mac:</b> Execute load balancing based on source and target MAC</p> <p><b>src-ip:</b> Execute load balancing according to source IP</p> <p><b>dst-ip:</b> Execute load balancing according to target IP</p> <p><b>dst-src-ip:</b> Execute load balancing according to target IP source</p> <p><b>dst-src-mac-ip:</b> Perform load balancing based on target and source Mac and source IP</p>
<b>Operation</b>	Click on the entry in the corresponding action bar and jump to the corresponding settings page

### 12.2. Delete port group

This page can be used to delete created convergent groups.

To display the "Delete port group" page click Port channel configuration->Delete port group, click "Apply" to configure.

Port group table			
Group number	Group member size	Load balance	Operation
1	0	src-mac	<a href="#">Delete</a>

<b>entry</b>	describe
<b>Group number</b>	Range: 1-128

<b>Group member size</b>	Number of members in convergent groups
<b>Load balance</b>	<p><b>src-mac:</b> Execute load balancing according to source MAC</p> <p><b>dst-mac:</b> Execute load balancing according to target MAC</p> <p><b>dst-src-mac:</b> Execute load balancing based on source and target MAC</p> <p><b>src-ip:</b> Execute load balancing according to source IP</p> <p><b>dst-ip:</b> Execute load balancing according to target IP</p> <p><b>dst-src-ip:</b> Execute load balancing according to target IP source</p> <p><b>dst-src-mac-ip:</b> Perform load balancing based on target and source Mac and source IP</p>

### 12.3. Show port group info

This page can view the information of the convergent group configuration. To display the “Show port group info” page, click Port channel configuration->Show port group info, click "Apply" to view.

```

Information feedback window
Switch# config
Switch(config)# show port-group brief
ID: port group number; Mode: port group mode such as on active or passive;
Ports: different types of port number of a port group,
      the first is selected ports number, the second is standby ports number, and
      the third is unselected ports number.
ID   Mode   Partner ID   Ports   Load-balance
-----
1                               src-mac
Switch(config)# show port-group detail
Flags:  A -- LACP_Activity, B -- LACP_timeout, C -- Aggregation,
        D -- Synchronization, E -- Collecting, F -- Distributing,
        G -- Defaulted, H -- Expired
Port-group number: 1, Mode: , Load-balance: src-mac
Port-group detail information:
System ID: 0x8000,00-1f-ce-10-b0-1b
Local:
Port           Status      Priority Oper-Key Flag
-----
Remote:
Actor          Partner    Priority Oper-Key SystemID      Flag
-----

```

## 12 Port channel configuration

### 12.4. Show interface port-channel

This page can view the information of the convergent group port.  
To display the “Show interface port-channel” page, click Port channel configuration->Show interface port-channel, click "Apply" to view.

```
Information feedback window
Switch# show interface port-channel 1
Interface brief:
  Port-Channell is down, line protocol is down
  Port-Channell is layer 2 port, alias name is (null), index is 53
  Port-Channell is LAG port, member is :
    Hardware is EtherChannel, address is 00-1f-ce-10-b0-1b
  PVID is 1
  MTU 1500 bytes, BW 10000 Kbit
  Time since last status change:0w-0d-3h-21m-9s (12069 seconds)
  Encapsulation ARPA, Loopback not set
  Force half-duplex, Auto-speed
  FlowControl is off, MDI type is auto
Statistics:
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
  The last 5 second input rate 0 bits/sec, 0 packets/sec
  The last 5 second output rate 0 bits/sec, 0 packets/sec
Input packets statistics:
  0 input packets, 0 bytes, 0 no buffer
  0 unicast packets, 0 multicast packets, 0 broadcast packets
  0 input errors, 0 CRC, 0 frame alignment, 0 overrun, 0 ignored,
  0 abort, 0 length error, 0 undersize 0 jabber, 0 fragments, 0 pause frame
Output packets statistics:
  0 output packets, 0 bytes, 0 underruns
  0 unicast packets, 0 multicast packets, 0 broadcast packets
  0 output errors, 0 collisions, 0 late collisions, 0 pause frame
```

### 12.5. Add member port

This page can be used to add port members to a convergence group.  
To display the “Add member port” page, click Port channel configuration->Add member port, click "Apply" to configure.

Port group add port	
Group number	1 ▾
Port list	Ethernet1/0/1 ▾
mode	on ▾
<input type="button" value="Add"/> <input type="button" value="Reset"/>	

<b>entry</b>	describe
<b>Group number</b>	To create a convergent group number
<b>Port list</b>	Ethernet port name

<b>mode</b>	<p>On: force port to join port channel without LACP. enabled</p> <p>Active: Enable the LACP on the port and set it to Active mode;</p> <p>Passive: Enable LACP on the port and set it to passive mode</p>
-------------	---

Port group port list	
Index	Port Name
1	Ethernet1/0/1

<b>entry</b>	describe
<b>Index</b>	To create a convergent group number
<b>Port Name</b>	Ethernet port name added to convergence group

## 12.6. Del member port

This page can be used to delete port members within the convergence group. To display the “Del member port” page, click Port channel configuration->Del member port, click "Apply" to configure.

Port group remove port	
Group number	1 ▾
Port list	Ethernet1/0/1 ▾
<input type="button" value="Remove"/> <input type="button" value="Reset"/>	

<b>entry</b>	describe
<b>Group number</b>	To create a convergent group number
<b>Port list</b>	Ethernet port name

## 12.7. Set lacp port priority

This page is available with setting port priority. To display the “Set lacp port priority” page, click Port channel configuration->Set lacp

## 12 Port channel configuration

port priority, click set "to set, click Reset" to restore default settings.

Set lacp port priority	
Group number	1 ▾
Port list	Ethernet1/0/1 ▾
Lacp port priority	
<input type="button" value="set"/> <input type="button" value="Reset"/>	

<b>entry</b>	describe
<b>Group number</b>	To create a convergent group number
<b>Port list</b>	Ethernet port name added to convergence group
<b>Lacp port priority</b>	Range :0-65535

### 12.8. Set lacp system priority

This page is available with setting system priorities.

To display the "Set lacp system priority" page, click Port channel configuration->Set lacp system priority, click set "to set, click Reset" to restore default settings.

Set lacp system priority	
Lacp system priority	
<input type="button" value="set"/> <input type="button" value="Reset"/>	

<b>entry</b>	describe
<b>Lacp system priority</b>	Range: 0-65535

## 13. DHCP configuration

### 13.1. DHCP management

#### 13.1.1. Enable DHCP

DHCP status configuration and query, the user configures the DHCP server status and address conflict log status in this module, and checks the DHCP server status and address conflict log status.

Enable DHCP	
DHCP server status	Close ▾
Conflict logging status	Open ▾
Apply	

<b>DHCP server status</b>	Close	Close DHCP server
	Open	Open DHCP server
<b>Conflict logging status</b>	Close	Close address conflict logging
	Open	Open address conflict logging
<b>Apply</b>	Apply the currently selected configuration to the switch to make the configuration effective	

Information feedback window	
DHCP server status	Conflict logging status
Close	Open

<b>DHCP server status</b>	Close	The current DHCP server is off
	Open	The current DHCP server is on
<b>Conflict logging status</b>	Close	The current address conflict log is off
	Open	The current address conflict log is open

## 13.2. DHCP server configuration

### 13.2.1. Dynamic pool configuration

#### 13.2.1.1. Dynamic address pool configuration

Switch DHCP address pool configuration, the user configures the DHCP address pool parameters.

DHCP IP address pool configuration	
DHCP pool name	<input type="text"/>
DHCP pool domain name	<input type="text"/> <input type="checkbox"/>
Address range	IP address: <input type="text"/>
	Network mask: <input type="text"/>
DHCP client node type	b-node <input type="text"/> <input type="checkbox"/>
Address lease timeout	<input type="radio"/> Infinite <input checked="" type="radio"/> Specified
	Day: <input type="text"/>
	Hour: <input type="text"/>
	Minute: <input type="text"/>
Operation	Add <input type="text"/> <input type="checkbox"/>
<input type="button" value="Apply"/>	

<b>DHCP pool name</b>	The name of the created address pool	
<b>DHCP pool domain name</b>	The domain name of the currently selected address pool. After configuration, you need to tick the box at the back to apply the domain name to the switch during application.	
<b>Address range</b>	IP address	Network number of the address pool
	Network mask	Netmask of the address pool
<b>DHCP client node type</b>	b-node	Broadcast node
	p-node	For point-to-point nodes
	m-node	Used for hybrid nodes to perform point-to-point communication after broadcasting
	h-node	Hybrid nodes that broadcast after peer-to-peer communication
	Designate	Hexadecimal node type, from 0 to 255

<b>Address lease timeout</b>	Infinite	The lease period of the address is unlimited, and the number of days/hours/minutes below do not need to be filled in
	Specified	There is a time limit for the lease of the address. You can rent it according to the lease time filled in below, and it will be automatically recovered if the time is exceeded
<b>Operation</b>	add	Add the above four parameters with check boxes to the switch, the parameters without check boxes will not be operated
	remove	Restore the four parameters with check boxes to the default configuration, and the parameters without check boxes will not be operated

```

Information feedback window
Switch# show ip dhcp pool config
dhcp pool 1
    Lease day:1, hour: 0, minute :0
  
```

Information display of the currently configured address pool

### 13.2.1.2. Client's default gateway configuration

The switch DHCP client default gateway configuration, the user configures the gateway parameters of the DHCP address pool.

Client's default gateway configuration	
DHCP pool name	1 ▼
Gateway 0	
Gateway 1	
Gateway 2	
Gateway 3	
Gateway 4	
Gateway 5	
Gateway 6	
Gateway 7	
Operation	Add ▼
Apply	

<b>DHCP pool name</b>	The name of the created address pool
-----------------------	--------------------------------------

**13 DHCP configuration**

<b>Gateway0-7</b>	Gateway IP address in dotted decimal format. Gateway 0 has the highest priority. The smaller the number, the higher the priority. The gateway can be set to zero or more, but the setting must start with 0 and no vacancies can appear in the middle, otherwise the gateway will be ignored. The following parameters, such as setting gateway 0-1 and gateway 7, only gateway 0-1 takes effect	
<b>Operation</b>	Add	Add the gateway effectively set above to the currently selected DHCP address pool
	Remove	Clear all gateways and restore to the default state

```

Information feedback window
Switch# config t
Switch(config)# ip dhcp pool 1
Switch(dhcp-1-config)# default-router 1.1.1.1
    
```

Information display after application

**13.2.1.3. Client DNS server configuration**

The switch DHCP client DNS server configuration, the user configures the DNS server parameters of the DHCP address pool.

Client DNS server configuration	
DHCP pool name	1 ▾
DNS server 0	1.1.1.1
DNS server 1	
DNS server 2	
DNS server 3	
DNS server 4	
DNS server 5	
DNS server 6	
DNS server 7	
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>DHCP pool name</b>	The name of the created address pool
-----------------------	--------------------------------------

<b>DNS server 0-7</b>	For the IP address in dotted decimal format, DNS server 0 has the highest priority. The smaller the number, the higher the priority. The DNS server can be set to zero or more, but the setting must start from 0 and there can be no vacancies in the middle, otherwise the DNS server The following parameters will be ignored, such as setting DNS server 0-1 and DNS server 7, only DNS server 0-1 takes effect	
<b>Operation</b>	Add	Add the DNS server effectively set above to the currently selected DHCP address pool
	Remove	Clear all DNS servers and restore to the default state

```

Information feedback window
Switch# config t
Switch(config)# ip dhcp pool 1
Switch(dhcp-1-config)# dns-server 1.1.1.1
  
```

Information display after application.

#### 13.2.1.4. Client WINS server configuration

The switch DHCP client WINS server configuration, the user configures the WINS server parameters of the DHCP address pool.

Client WINS server configuration	
DHCP pool name	1 ▾
WINS server 0	
WINS server 1	
WINS server 2	
WINS server 3	
WINS server 4	
WINS server 5	
WINS server 6	
WINS server 7	
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>DHCP pool name</b>	The name of the created address pool
-----------------------	--------------------------------------

**13 DHCP configuration**

<b>WINS server 0-7</b>	The WINS server IP address in dotted decimal format. WINS server 0 has the highest priority. The smaller the number, the higher the priority. The WINS server can be set to zero or more, but the setting must start from 0 and there can be no vacancies in the middle, otherwise WINS server will ignore the following parameters, such as setting WINS server 0-1 and WINS server 7, only WINS server 0-1 takes effect	
<b>Operation</b>	Add	Add the WINS server effectively set above to the currently selected DHCP address pool
	Remove	Clear all WINS servers and restore them to the default state

```

Information feedback window
Switch# config t
Switch(config)# ip dhcp pool 1
Switch(dhcp-1-config)# netbios-name-server 1.1.1.1
  
```

Information display after application.

**13.2.1.5. DHCP file server address configuration**

The switch client import file stores the address configuration, and the user configures the parameters of the DHCP address pool client import file.

DHCP file server address configuration	
DHCP pool name	1 ▾
DHCP client bootfile name	123.cfg
File server 0	1.1.1.1
File server 1	
File server 2	
File server 3	
File server 4	
File server 5	
File server 6	
File server 7	
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>DHCP pool name</b>	The name of the created address pool
-----------------------	--------------------------------------

<b>DHCP client bootfile name</b>	Specify the name of the file to be imported for the client. Usually used for diskless workstations, these workstations need to download configuration files from the server at startup.	
<b>File server 0-7</b>	The IP address in dotted decimal format has the highest priority for importing file server 0. The smaller the number, the higher the priority. The importing file server can be set to zero or more, but the setting must start from 0 and there should be no vacancies in the middle, otherwise Importing file server will ignore the following parameters, such as setting import file server 0-1 and import file server 7, only import file server 0-1 takes effect	
<b>Operation</b>	Add	Add the imported file server effectively set above to the currently selected DHCP address pool
	Remove	Clear all imported file servers and restore to the default state

```

Information feedback window
Switch# config t
Switch(config)# ip dhcp pool 1
Switch(dhcp-1-config)# bootfile 123.cfg
Switch# config t
Switch(config)# ip dhcp pool 1
Switch(dhcp-1-config)# next-server 1.1.1.1

```

Information display after application

### 13.2.1.6. DHCP network parameter configuration

Switch network parameter configuration, the user configures the network parameters of the DHCP address pool.

DHCP network parameter configuration	
DHCP pool name	1 ▾
Code	
Network parameter value type	IP ADDRESS ▾
Network parameter value(ASCII,HEX or IP)	
Operation type	Add ▾
Apply	

<b>DHCP pool name</b>	The name of the created address pool
-----------------------	--------------------------------------

## 13 DHCP configuration

<b>Code</b>	The code range of network parameters is 0-254, and each code corresponds to a different function in DHCP. The definition of option codes is described in detail in RFC2123.	
<b>Network parameter value type</b>	There are three types of network parameter values: ASCII, HEX, and IP ADDRESS.	
<b>Network parameter value (ASCII, HEX or IP)</b>	ASCII string, up to 255 characters; Hexadecimal value, not greater than 510, and must be an even number; IP address in decimal format, up to 63 IP addresses can be configured.	
<b>Operation</b>	Add	Add the network parameters of the selected address pool to the switch.
	Remove	Clear the network parameters filled in the selected address pool (delete according to the code of the network parameter).

```

Information feedback window
Switch# config t
Switch(config)# ip dhcp pool 1
Switch(dhcp-1-config)# option 82 ip 192.168.2.1
DHCPD: Option 82 has been added to pool 1

```

Information display after application

### 13.2.1.7. Excluded address configuration

Excluding the dynamic allocation address configuration, the user configures the addresses that are not used for dynamic allocation

Address allocation configuration	
Starting address	<input type="text"/>
Ending address	<input type="text"/>
Operation type	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Starting address</b>	Start address not used for dynamic allocation.	
<b>Ending address</b>	End address not used for dynamic allocation.	
<b>Operation type</b>	Add	Add the address range that is not used and dynamically allocated to the switch.
	Remove	Delete the address range that is not used and dynamically allocated from the switch.

Address list	
Starting address	Ending address
1.1.1.1	1.1.1.25
end of list	

Display the address range currently not used for dynamic allocation

### 13.2.2. Manual DHCP IP pool configuration

#### 13.2.2.1. Static address pool configuration

Switch static address pool configuration, and manually bind client parameters.

Hardware address	
DHCP pool name	1 ▾
Parameter choose	ethernet ▾
Hardware address	00-11-22-33-44-55
Operation	Add ▾
Apply	

<b>DHCP pool name</b>	The name of the created address pool	
<b>Parameter choose</b>	The protocol type used by the client is rfc\ethernet\ieee802. RFC ID: RFC protocol number, valid range is 1-255.	
<b>Hardware address</b>	Hardware address	
<b>Operation</b>	Add	Add manually bound hardware address and protocol type
	Remove	Remove the manually bound hardware address and protocol type

Client pool configuration	
Client pool configuration	1
Client IP address	
Client network mask	
Operation	Add ▾
Apply	

<b>Client pool configuration</b>	The name of the created address pool (modify the selection through the address pool name of the user's hardware address)
<b>Client IP address</b>	IP address assigned by the DHCP server to the client

**13 DHCP configuration**

<b>Client network mask</b>	The subnet mask assigned by the DHCP server to the client IP	
<b>Operation</b>	Add	Add manually bound IP address and subnet mask
	Remove	Delete the manually bound IP address and subnet mask

User name	
DHCP pool name	1
User	
Client identifier	
Operation	Add ▼
Apply	

<b>DHCP pool name</b>	The name of the created address pool (modify the selection through the address pool name of the user's hardware address)	
<b>user</b>	Client user name	
<b>Client identifier</b>	The identifier of the client, for example: 44-11-22-33-44-55 (MAC address)	
<b>Operation</b>	Add	Add manually bound client identifier and user name
	Remove	Delete the manually bound client identifier and user name

**13.2.3. Address pool name configuration**

DHCP server address pool name configuration, user settings add and delete the address pool name.

Address pool name configuration	
DHCP pool name	
Operation type	Add pool ▼
Apply	

<b>DHCP pool name</b>	The name of the created address pool	
<b>Operation type</b>	Add pool	Add the address pool of the DHCP server
	Remove pool	Delete the address pool of the DHCP server

```

Information feedback window
Switch# show ip dhcp pool config
dhcp pool 1
    Lease  day:1, hour: 0, minute :0
  
```

Display the address pool of the current DHCP server

### 13.2.4. DHCP packet statistics

DHCP server data packet statistics, users can view DHCP data packets.

DHCP packet statistics	
Address pool number	1
Proxy database	0
Dynamical assignment address	0
Manual binded address	0
Address conflict	0
Binding exceeding lease time	0
Errors	0
Received DHCP packet statistics	
Received	0
DHCP DISCOVER	0
DHCP REQUEST	0
DHCP DECLINE	0
DHCP RELEASE	0
DHCP INFORM	0
Transmitted DHCP packet statistics	
Transmitted	0
DHCP OFFER	0
DHCP ACK	0
DHCP NAK	0
DHCP RELAY	0
DHCP FORWARD	0
<input type="button" value="Clear"/> <input type="button" value="Show"/>	

It can be viewed in real time by clicking "Clear" and "Show"

## 13.3. DHCP relay configuration

### 13.3.1. DHCP relay configuration

The switch DHCP relay configuration, the user configures the port range, and the switch sends UDP broadcast messages to the port.

## 13 DHCP configuration

DHCP forward UDP configuration	
Range	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

Port
67

<b>Range</b>	Port used by DHCP to forward UDP packets	
<b>Operation</b>	Add	Add the port used by DHCP to forward UDP packets
	Remove	Delete the port through which DHCP forwards UDP packets

DHCP help-address configuration	
IP address	<input type="text"/>
L3 Interface	Vlan1 <input type="button" value="v"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

IP address	L3 Interface
192.168.2.1	Vlan1

<b>IP address</b>	IP address of the Layer 3 interface	
<b>L3 Interface</b>	Established Layer 3 interface	
<b>Operation</b>	Add	Add a Layer 3 interface for DHCP to forward UDP packets
	Remove	Delete the Layer 3 interface through which DHCP forwards UDP packets

### 13.4. DHCP debugging

#### 13.4.1. Delete record

##### 13.4.1.1. Delete binding log

DHCP binding record deletion, users can delete all binding records or delete specified binding records, static binding records need to be deleted in the static address pool configuration.

Delete DHCP binding log	
Delete binding area	Delete all binding log <input type="button" value="v"/>
IP Address	<input type="text"/>
<input type="button" value="Apply"/>	

<b>Delete binding area</b>	Delete all binding log	Delete all binding records, no need to fill in the IP address below
	Delete specify binding log	Delete the specified binding record, fill in the deleted IP in the IP address below

<b>IP Address</b>	IP address in dotted decimal notation
-------------------	---------------------------------------

### 13.4.1.2. Delete conflict log

The DHCP conflict record is deleted, and the user can delete all conflict records or delete the specified conflict record.

Delete conflict log	
Delete conflict address area	Delete all conflict log ▼
IP Address	<input type="text"/>
<input type="button" value="Apply"/>	

<b>Delete conflict log</b>	Delete all conflict log	Delete all conflict records, no need to fill in the IP address below
	Delete specify binding log	Delete the specified conflict record, fill in the deleted IP in the IP address below
<b>IP Address</b>	IP address in dotted decimal notation	

### 13.4.1.3. Delete DHCP server statistics log

Deleting the statistics records of the DHCP server, the user can delete all the statistics records of the DHCP server.

Delete DHCP server statistics log
<input type="text"/>
<input type="button" value="Apply"/>

After deleting the statistical record of the DHCP server, the statistical information of the DHCP packet will be cleared

### 13.4.2. Show IP-MAC binding

The DHCP server's IP and MAC binding status, the user can view the binding entries and the relationship between the bound IP and MAC.

```

Information feedback window
Switch# clear ip dhcp server statistics
Switch# show ip dhcp binding
Total dhcp binding items: 0, the matched: 0
IP address      Hardware address  Lease expiration  Type
  
```

<b>IP address</b>	Client's IP address	
<b>Hardware address</b>	The hardware address or MAC address of the client	
<b>Lease expiration</b>	Client IP expiration time	
<b>Type</b>	Manual	Manual binding
	Dynamic	Dynamic allocation

## 13 DHCP configuration

### 13.4.3. Show conflict-logging

The conflict record of the DHCP server, the user can view the conflict situation.

```
Information feedback window
Switch# show ip dhcp conflict
IP Address      Detection method  Detection Time
```

Display info	Description
IP Address	Conflicting IP address.
Detection method	The conflicting method was detected.
Detection Time	The time when the conflict was detected.

## 14. DHCP Snooping configuration

### 14.1. DHCP Snooping global configuration

#### 14.1.1. Enable/Disable DHCP Snooping

With the enabling and disabling of the DHCP Snooping module, users can view and operate the status of DHCP Snooping.

Enable/Disable DHCP Snooping	
DHCP Snooping status	Disable ▾
Apply	

<b>DHCP Snooping status</b>	Disable	Disable DHCP Snooping
	Enable	Enable DHCP Snooping

Information feedback window	
DHCP Snooping status	Enable

Display the current DHCP Snooping status

#### 14.1.2. DHCP Snooping binding configuration

When DHCP Snooping binding is enabled and disabled, users can view and operate the status of DHCP Snooping. When configuring this binding, users must ensure that the binding status is in the on state.

Enable/Disable DHCP Snooping binding	
DHCP Snooping binding status	Disable ▾
Apply	

<b>DHCP Snooping binding status</b>	Disable	Disable DHCP Snooping binding function
	Enable	Enable DHCP Snooping binding function

Information feedback window	
DHCP Snooping binding status	Disable

Shows whether the current DHCP Snooping binding status function is enabled.

#### 14.1.3. DHCP Snooping binding user configuration

When DHCP Snooping binding is enabled and disabled, users can view and operate the status of DHCP Snooping. When configuring this binding, users must ensure that the binding status is in the on state.

**14 DHCP Snooping configuration**

DHCP Snooping binding user configuration	
MAC address	<input type="text"/>
User IP address	<input type="text"/>
User mask	<input type="text"/>
VLAN ID	<input type="text"/>
Port	Ethernet1/0/1 <input type="button" value="v"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>MAC address</b>	The MAC address of the statically bound user is the only index of the bound user	
<b>User IP address</b>	Statically bind the user's IP address	
<b>User mask</b>	Statically bind the user's subnet mask	
<b>VLAN ID</b>	Statically bind the VLAN ID of the user	
<b>Port</b>	Bind the user's access port statically, the port is associated with the VLAN ID, and the port is required to allow the VLAN to pass	
<b>Operation</b>	Add	Add DHCP Snooping binding user relationship
	Remove	Delete DHCP Snooping binding user relationship

```

Information feedback window
Switch# config t
Switch(config)# no Ip dhcp snooping binding user 00-22-33-44-55-66 interface Ethernet1/0/1 vlan 1
Please enable dhcp snooping binding in global first!
    
```

Display the process and error messages or results generated during application execution

**14.1.4. DHCP Snooping action count config**

DHCP Snooping defense action number configuration, if the number of alarm messages is greater than the set number, it will force the restoration of the earliest defense measures to send new defense measures.

DHCP Snooping action count config	
DHCP Snooping action count	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>DHCP Snooping action count</b>	Set the maximum number of defense actions to avoid exhaustion of switch resources caused by attacks.
-----------------------------------	--

<b>Operation</b>	Add	Configure the number of defense actions filled in above
	Remove	Reduce the number of defense actions to 10

Information feedback window	
DHCP Snooping action count	10

Display the current number of DHCP Snooping defense actions

#### 14.1.5. DHCP Snooping limit-rate config

DHCP Snooping packet receiving rate limit sets the number of DHCP messages sent per second.

DHCP Snooping limit-rate config	
Packet per second	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Packet per second</b>	Range: 0-100	
<b>Operation</b>	Add	Configure the number of packets per second
	Remove	Restore the default number of packets per second, the default is 100

Information feedback window	
Packet per second	100

Display the number of packets per second configured for the current DHCP Snooping.

#### 14.1.6. DHCP Snooping helper-server config

DHCP snooping will send the monitored binding information to helper server for storage. If the switch starts abnormally, you can recover the bound data from the helper server.

## 14 DHCP Snooping configuration

DHCP Snooping helper-server config	
Helper-server address	<input type="text"/>
Helper-server UDP port	<input type="text"/>
Local IP address	<input type="text"/>
Second address	<input type="text"/> ▼
Operation	Add ▼ <input type="text"/>
<input type="button" value="Apply"/>	

<b>Helper-server address</b>	HELPER server address	
<b>Helper-server UDP port</b>	DHCP snooping and helper server use UDP protocol for communication, the port range is 1-65535.	
<b>Local IP address</b>	The effective management IP address of the switch	
<b>Second address</b>	Two helper server addresses are allowed, DHCP SNOOPING will first try to connect to the PRIMARY server. Only when the PRIMARY server cannot be accessed, the switch HELPER server will connect to the SECONDARY server. Set the PRIMARY server before setting up the SECONDARY server.	
<b>Operation</b>	Add	Add HELPER server address
	Remove	Delete the HELPER server address, you can leave it blank when deleting

```

Information feedback window
Switch# config t
Switch(config)# no ip user helper-address

```

Display the process and error messages or results generated during application execution

### 14.2. DHCP Snooping port configuration

#### 14.2.1. Enable/Disable DHCP Snooping binding dot1x

DHCP SNOOPING will notify the DOT1X module of the binding information captured by the user controlled by the DOT1X. DHCP Snooping port binding dot1x function needs to enable DHCP Snooping binding configuration first.

Enable/Disable DHCP Snooping binding dot1x	
Port	DHCP Snooping binding dot1x status
Ethernet1/0/1 ▼	Enable ▼ <input type="text"/>
<input type="button" value="Apply"/>	

Port	Port name	
<b>DHCP Snooping binding dot1x status</b>	Enable	Enable the dot1x status of DHCP Snooping port binding
	Disable	Disable the dot1x binding status of the DHCP Snooping port

Information feedback window	
Port	DHCP Snooping binding dot1x status
Ethernet1/0/1	Disable
Ethernet1/0/2	Disable
Ethernet1/0/3	Disable
Ethernet1/0/4	Disable
Ethernet1/0/5	Disable
Ethernet1/0/6	Disable
Ethernet1/0/7	Disable
Ethernet1/0/8	Disable

Display the dot1x binding status of each DHCP Snooping port of the switch

#### 14.2.2. Enable/Disable DHCP Snooping binding user

When this function is enabled on the port, DHCP SNOOPING will treat the captured binding information as a trusted user who is allowed to access all resources. The DHCP Snooping port binding user status function needs to enable the DHCP Snooping binding configuration first.

Enable/Disable DHCP Snooping binding user	
Port	DHCP Snooping binding user status
Ethernet1/0/1 ▾	Enable ▾
Apply	

Port	Port name	
<b>DHCP Snooping binding user status</b>	Enable	Enable DHCP Snooping port binding user status
	Disable	Disable DHCP Snooping port binding user status

**14 DHCP Snooping configuration**

Information feedback window	
Port	DHCP Snooping binding user status
Ethernet1/0/1	Disable
Ethernet1/0/2	Disable
Ethernet1/0/3	Disable
Ethernet1/0/4	Disable
Ethernet1/0/5	Disable
Ethernet1/0/6	Disable
Ethernet1/0/7	Disable
Ethernet1/0/8	Disable

Display the status of users bound to each DHCP Snooping port of the switch

**14.2.3. Enable/Disable DHCP Snooping trust**

When a port changes from an untrusted port to a trusted port, the original defense action of the port will be automatically deleted; all security history records will be cleared.

Enable/Disable DHCP Snooping trust	
Port	DHCP Snooping binding trust status
Ethernet1/0/1 ▼	Enable ▼
<input type="button" value="Apply"/>	

Port	Port name	
<b>DHCP Snooping binding trust status</b>	Enable	Enable DHCP Snooping port trust attribute status
	Disable	Disable the trust attribute status of the DHCP Snooping port

Information feedback window	
Port	DHCP Snooping binding trust status
Ethernet1/0/1	Disable
Ethernet1/0/2	Disable
Ethernet1/0/3	Disable
Ethernet1/0/4	Disable
Ethernet1/0/5	Disable
Ethernet1/0/6	Disable
Ethernet1/0/7	Disable
Ethernet1/0/8	Disable

Display the trust attribute status of each DHCP Snooping port of the switch.

#### 14.2.4. DHCP Snooping action config

Automatic port defense action, the port will detect the fake DHCP server, and the trusted port will not detect the fake DHCP server, so the corresponding defense action will never be triggered. When a port changes from an untrusted port to a trusted port, the original defense action of the port will be automatically deleted;

DHCP Snooping action config	
Port	Ethernet1/0/1 ▼
DHCP Snooping action	shutdown ▼
DHCP Snooping recovery time	<input type="text"/>
Operation	Add ▼
<input type="button" value="Apply"/>	

<b>Port</b>	Port name	
<b>DHCP Snooping action</b>	shutdown	Automatically close the port
	blackhole	Block traffic from fake DHCP server based on MAC
<b>DHCP Snooping recovery time</b>	The user can set the recovery after performing automatic defense operations	
<b>Operation</b>	Add	Add DHCP Snooping port automatic defense configuration
	Remove	Delete DHCP Snooping port automatic defense configuration

Information feedback window		
Port	DHCP Snooping action	DHCP Snooping recovery time
Ethernet1/0/1	none	0
Ethernet1/0/2	none	0
Ethernet1/0/3	none	0
Ethernet1/0/4	none	0
Ethernet1/0/5	none	0
Ethernet1/0/6	none	0
Ethernet1/0/7	none	0
Ethernet1/0/8	none	0

Display the automatic defense configuration of each DHCP Snooping port.

### 14.3. Show DHCP Snooping configuration

#### 14.3.1. Show DHCP Snooping configuration

Display detailed configuration of DHCP Snooping.

<b>DHCP Snooping show object</b>	All	All ports are displayed
	Ethernet 1/0/1-28	Only display information about one port

```

Information feedback window
Switch# show ip dhcp snooping interface Ethernet1/0/1
interface Ethernet1/0/1 user config:
trust attribute: untrust
action: none
binding dot1x: disabled
binding user: disabled
binding mab guard: disabled
recovery interval:0(s)
Driver user number 0 : Max user number 1024
Alarm info: 0
Binding info: 0
Static Binding info: 0
Static Binding info from shell: 0
Static Binding info from server: 0
flag: D - Dynamic ; U - already upload server ;
S - static binding info from shell; R - static binding info from server;
O - dhcp ack has option82; X - notify dot1x ok;
L - notify driver ok; E - notify dot1x error
P - binding protect;
Expired Binding: 0
Request Binding: 0
    
```

Select Ethernet1/0/1, only display the DHCP Snooping information of Ethernet1/0/1.

## 15. SNTP configuration

### 15.1. SNTP server configuration

SNTP the server settings module, the user can add or delete the specified time server as the clock source.

SNTP server and version configuration	
Server address	<input type="text"/>
Version	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

```

Information feedback window
SW1# config t
SW1(config)# show sntp
server address                version last receive
  
```

<b>Server address</b>	The specified time server address decimal point	
<b>Version</b>	Version number, range 1-4, default 4	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 15.2. Request interval configuration

Send request interval setting module, where the user can set the interval SNTP the client sends a request to the NTP/SNTP. By default, the interval is 64 seconds.

Request interval from SNTP client to SNTP server	
Interval	<input type="text"/>
Operation	Configuration <input type="button" value="v"/>
<input type="button" value="Apply"/>	

Interval	
Interval	64

<b>Interval</b>	Duration value, range 16-16284 s	
<b>Operation</b>	Configuration	Configuration operations
	Default	Do recovery default (default 64 s)

### 15.3. Time difference configuration

SNTP the time zone and UTC time difference setting module where the client is located, the user can set the switch's current time zone and name it.

Time difference configuration	
Time zone	<input type="text"/>
Time difference	<input checked="" type="radio"/> After-utc <input type="radio"/> Before-utc
Time value	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Time zone</b>	Time zone name, 1-16 characters	
<b>Time difference</b>	Add	Increased time zone behavior
	reduce	Reduced time zone behavior
<b>Time value</b>	Time zone specific change hours 0-23	Time zone specific change minute value 0-59
	<b>Operation</b>	Add operations
	Remove	Delete operations

### 15.4. Show SNTP

Display SNTP module, where users can view the current information status SNTP the switch.

```

Information feedback window
SW1# config t
SW1(config)# show sntp
server address          version last receive
    
```

## 16. NTP configuration

### 16.1. NTP global configuration

#### 16.1.1. NTP global switch configuration

NTP service global switch configuration module, user can NTP service global switch operation.

NTP global switch configuration	
Operation	Disable ▾
Apply	

NTP global switch configuration	
NTP global configuration	disable

<b>Operation</b>	Disable	Close operation
	Enable	Start (default)

#### 16.1.2. NTP server configuration

NTP the server configuration module, the user can configure the specified time server of the switch time source in this module.

NTP server and version configuration	
Server address	<input type="text"/>
Version	<input type="text"/>
Key	<input type="text"/>
Operation	Add ▾
Apply	

Information feedback window
SW1# config t SW1(config)# show ntp session ntp peer doesn't exist!

<b>Server address</b>	The specified time server address decimal point	
<b>Version</b>	Version number, range 1-4, default 4	
<b>Key</b>	Secret key value, range 1-4294967295	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

#### 16.1.3. NTP broadcast or multicast address count configuration

NTP service address number configuration module, the user can configure the maximum number of broadcast or multicast servers supported by the switch NTP client.

## 16 NTP configuration

NTP broadcast or multicast address count configuration	
Address max count	<input type="text"/>
Operation	Add <input type="text"/>
<input type="button" value="Apply"/>	

Address max count	
Address max count	50

<b>Address max count</b>	Maximum number of broadcast or multicast servers supported NTP clients, 1-100 (default 50)	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 16.1.4. NTP access group configuration

NTP access control list configuration module, where users can configure switch NTP access control list.

NTP access group configuration	
Access list	<input type="text"/>
Operation	Add <input type="text"/>
<input type="button" value="Apply"/>	

<b>Access list</b>	IPv4:1-99; IPv6: 50-599	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 16.1.5. NTP authenticate configuration

NTP verification configuration module, the user can configure the switch NTP authentication related items.

NTP authenticate configuration	
NTP authenticate switch	Disable <input type="text"/>
Key type	none <input type="text"/>
Key	<input type="text"/>
MD5	<input type="text"/>
Operation	Add <input type="text"/>
<input type="button" value="Apply"/>	

<b>NTP authenticate switch</b>	Disable	Close NTP validation (default)
	Enable	Enable NTP validation
<b>Key type</b>	none	none
	authentication-key	Authentication secret key
	trusted-key	Trust key
<b>Key</b>	Secret key value, range 1-4294967295	
<b>Md5</b>	The MD5 value of the secret key, which ranges from 1-16 of ascii code	

<b>Operation</b>	Add	Add operations
	Remove	Delete operations

## 16.2. NTP interface configuration

### 16.2.1. NTP interface switch configuration

NTP service interface switch configuration module, the user can specify the NTP service interface switch operation.

NTP interface configuration	
VLAN interface	Vlan1 ▾
NTP interface configuration	Disable ▾
NTP interface client	none ▾
Apply	

<b>VLAN interface</b>	VLAN1	VLAN interface for current switch configurable
<b>NTP interface configuration</b>	Disable	Close operation
	Enable	Start-up operation
<b>NTP interface client</b>	none	Interface NTP client type
	broadcast	
	no broadcast	
	multicast	
	no multicast	
	ipv6 multicast	
	no ipv6 multicast	

## 16.3. NTP configuration display

### 16.2.1. NTP status display

NTP status display module, where users can view NTP service current status information.

```
Information feedback window
SW1# show ntp status
ntp clock status: unsynchronized
```

## 17. QOS configuration

### 17.1. QOS port configuration

#### 17.1.1. QOS port trust state configuration

Configure port trust rules

QoS port trust state configuration	
Port	Ethernet1/0/1 ▾
Packet class rule	COS ▾
Operation	Add ▾
Apply	

<b>Port</b>	To configure the port name, click to expand the remaining ports	
<b>Packet class rule</b>	COS	Cos to int mapping based on intp field
	DSCP	Intp field based on dscp to intp mapping
<b>Operation</b>	add	Add a trust rule for the port
	Remove	Remove a trust rule for the port

Information feedback window	
Port	Trust class
Ethernet1/0/1	COS
Ethernet1/0/2	COS
Ethernet1/0/3	COS
Ethernet1/0/4	COS
Ethernet1/0/5	COS
Ethernet1/0/6	COS
Ethernet1/0/7	COS
Ethernet1/0/8	COS

#### 17.1.2. QOS port COS parameters configuration

Configure the COS value of the port, regardless of whether the trust rule of the current port is trusted.

QoS port cos parameters configuration	
Port	Ethernet1/0/1 ▾
Port related COS value	<input type="text"/>
Operation	Add ▾
Apply	

<b>Port</b>	To configure the port name, click to expand the remaining ports	
<b>Port related COS value</b>	The default COS value of the port, range: 0-7	
<b>Operation</b>	Add	Add the COS value of the port
	Remove	Delete the COS value of the port and restore it to 0

Information feedback window	
Port	Port related COS value
Ethernet1/0/1	0
Ethernet1/0/2	0
Ethernet1/0/3	0
Ethernet1/0/4	0
Ethernet1/0/5	0
Ethernet1/0/6	0
Ethernet1/0/7	0
Ethernet1/0/8	0

### 17.1.3. QoS port select queue schedule algorithm configuration

Configure the port to process the priority of packets according to different queue scheduling algorithms.

QoS port select queue schedule algorithm configuration	
Port	Ethernet1/0/1 ▼
Queue schedule algorithm	sp ▼
<input type="button" value="Apply"/>	

<b>Port</b>	To configure the port name, click to expand the remaining ports	
<b>Queue schedule algorithm</b>	sp	Strict queuing priority, packet transmission in order of priority.
	wrr	Weighted round-robin scheduling. Rotate scheduling between queues to ensure that each queue gets a certain amount of service time
<b>Queue schedule algorithm</b>	wdr	Weighted difference round-robin scheduling, based on message length transmission, based on the combined effect of weight and K value to generate the length of transmission in the message queue

## 17 QOS configuration

Information feedback window	
Port	Trust class
Ethernet1/0/1	sp
Ethernet1/0/2	wdrr
Ethernet1/0/3	wrr
Ethernet1/0/4	wrr
Ethernet1/0/5	wrr
Ethernet1/0/6	wrr
Ethernet1/0/7	wrr
Ethernet1/0/8	wrr

Display the queue scheduling algorithm trusted by the current port

### 17.1.4. QOS port wrr algorithm queue weight configuration

Configure the weight value of the eight queues of each port, and allocate the number of packets according to the weight value.

QoS port wrr algorithm queue weight configuration	
Port	Ethernet1/0/1 ▼
Weight1	<input type="text"/>
Weight2	<input type="text"/>
Weight3	<input type="text"/>
Weight4	<input type="text"/>
Weight5	<input type="text"/>
Weight6	<input type="text"/>
Weight7	<input type="text"/>
Weight8	<input type="text"/>
Operation	Add ▼
<input type="button" value="Apply"/>	

<b>Port</b>	To configure the port name, click to expand the remaining ports
<b>Weight1</b>	The weight value of queue 1, the range is 0-127
<b>Weight2</b>	The weight value of queue 2, the range is 0-127
<b>Weight3</b>	The weight value of queue 3, the range is 0-127
<b>Weight4</b>	The weight value of queue 4, the range is 0-127
<b>Weight5</b>	The weight value of queue 5, the range is 0-127
<b>Weight6</b>	The weight value of queue 6, the range is 0-127
<b>Weight7</b>	The weight value of queue 7, the range is 0-127
<b>Weight8</b>	The weight value of queue 8, the range is 0-127

<b>Operation</b>	Add	Add the weight of each queue to the port, and fill in all the weights of each queue before adding
	Remove	To restore the weight of each queue of the port to the default, you need to add the value of eight queues

Information feedback window	
Port	Queue weight
Ethernet1/0/1	1 2 3 4 5 6 7 8
Ethernet1/0/2	1 2 3 4 5 6 7 8
Ethernet1/0/3	1 2 3 4 5 6 7 8
Ethernet1/0/4	1 2 3 4 5 6 7 8
Ethernet1/0/5	1 2 3 4 5 6 7 8
Ethernet1/0/6	1 2 3 4 5 6 7 8
Ethernet1/0/7	1 2 3 4 5 6 7 8
Ethernet1/0/8	1 2 3 4 5 6 7 8

Information feedback window

### 17.1.5. QOS port wrr algorithm queue weight configuration

Configure the weight value of the eight queues of each port, transmit based on the length of the message, and generate the transmission length in the message queue based on the combined action of the weight and the K value.

QoS port wrr algorithm queue weight configuration	
Port	Ethernet1/0/1 <input type="text"/>
Weight1	<input type="text"/>
Weight2	<input type="text"/>
Weight3	<input type="text"/>
Weight4	<input type="text"/>
Weight5	<input type="text"/>
Weight6	<input type="text"/>
Weight7	<input type="text"/>
Weight8	<input type="text"/>
Operation	Add <input type="text"/>
<input type="button" value="Apply"/>	

<b>Port</b>	To configure the port name, click to expand the remaining ports
<b>Weight1</b>	The weight value of queue 1, the range is 0-32767
<b>Weight2</b>	The weight value of queue 2, the range is 0-32767
<b>Weight3</b>	The weight value of queue 3, the range is 0-32767

**17 QoS configuration**

<b>Weight4</b>	The weight value of queue 4, the range is 0-32767	
<b>Weight5</b>	The weight value of queue 5, the range is 0-32767	
<b>Weight6</b>	The weight value of queue 6, the range is 0-32767	
<b>Weight7</b>	The weight value of queue 7, the range is 0-32767	
<b>Weight8</b>	The weight value of queue 8, the range is 0-32767	
<b>Operation</b>	Add	Add the weight of each queue to the port, and fill in all the weights of each queue before adding
	Remove	To restore the weight of each queue of the port to the default, you need to add the value of eight queues

**17.1.6. QoS service policy configuration**

Configure the port's policy table, and the port will process packets according to the rules of the classification table in the policy table.

QoS service policy configuration	
Port	Ethernet1/0/1 <input type="button" value="v"/>
Policy map name	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Port</b>	To configure the port name, click to expand the remaining ports	
<b>Policy map name</b>	The name of the policy table, added by the policy table configuration	
<b>Operation</b>	Add	policy for adding ports
	Remove	Delete port policy

**17.2. QoS class-map configuration**

**17.2.1. Class map-configuration**

Create and delete classification tables, view the currently configured classification tables.

Class map-configuration	
Class-map name	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Class-map name</b>	Class-map name, range: 1-64 character	
<b>Operation</b>	Add	Add Class-map
	Remove	Remove Class-map

Information feedback window	
Class-map name	1

Display the currently created class-map name

### 17.2.2. Classification criteria configuration

Set the rules and corresponding parameters for classification matching.

Classification criteria configuration	
Classification criteria rule	access-group ▼
Class-map name	1 ▼
ACL list name	
Operation	Add ▼
Apply	

<b>Classification criteria rule</b>	access-group	Match the specified IP ACL, MAC ACL or IPv6 standard ACL or MAC-IP ACL
<b>Class-map name</b>	The name of the created class-matching table, select by clicking the drop-down	
<b>ACL list name</b>	Created ACL name, 1-64 characters	
<b>Operation</b>	Add	Add matching rules
	Remove	Remove matching rules

**17 QOS configuration**

Classification criteria configuration	
Classification criteria rule	ip dscp ▾
Class-map name	1 ▾
IP dscp0	
IP dscp1	
IP dscp2	
IP dscp3	
IP dscp4	
IP dscp5	
IP dscp6	
IP dscp7	
Operation	Add ▾
Apply	

<b>Classification criteria rule</b>	ip dscp	Match the specified DSCP value, this parameter is the DSCP list
<b>Class-map name</b>	The name of the created class-matching table, select by clicking the drop-down	
<b>IP dscp0-7</b>	One or more DSCP values can be set, up to 8 DSCP values can be set, the range is 0~63	
<b>Operation</b>	Add	Add matching rules
	Remove	Remove matching rules

Classification criteria configuration	
Classification criteria rule	ip precedence ▾
Class-map name	1 ▾
IP precedence0	
IP precedence1	
IP precedence2	
IP precedence3	
IP precedence4	
IP precedence5	
IP precedence6	
IP precedence7	
Operation	Add ▾
Apply	

<b>Classification criteria rule</b>	ip precedence	Match the specified ip priority, this parameter is the IP priority list
-------------------------------------	---------------	---

<b>Class-map name</b>	The name of the created class-matching table, select by clicking the drop-down	
<b>IP precedence0-7</b>	One or more ip priority values can be set, the list contains up to 8 IP priority values, and the valid range is 0~7;	
<b>Operation</b>	Add	Add matching rules
	Remove	Remove matching rules

Classification criteria configuration	
Classification criteria rule	vlan <input type="button" value="v"/>
Class-map name	1 <input type="button" value="v"/>
Vlan0	<input type="text"/>
Vlan1	<input type="text"/>
Vlan2	<input type="text"/>
Vlan3	<input type="text"/>
Vlan4	<input type="text"/>
Vlan5	<input type="text"/>
Vlan6	<input type="text"/>
Vlan7	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Classification criteria rule</b>	vlan	Match the specified vlan, this parameter is a list of vlan id
<b>Class-map name</b>	The name of the created class-matching table, select by clicking the drop-down	
<b>Vlan0-7</b>	One or more VLAN IDs can be set, including 8 VLAN IDs at most, ranging from 1 to 4094	
<b>Operation</b>	Add	Add matching rules
	Remove	Remove matching rules

17 QOS configuration

Classification criteria configuration	
Classification criteria rule	cos <input type="button" value="v"/>
Class-map name	1 <input type="button" value="v"/>
Cos0	
Cos1	
Cos2	
Cos3	
Cos4	
Cos5	
Cos6	
Cos7	
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Classification criteria rule</b>	cos	Match the specified CoS value, this parameter is a list of vlan id
<b>Class-map name</b>	The name of the created class-matching table, select by clicking the drop-down	
<b>Cos 0-7</b>	One or more cos values can be set, the parameter is a CoS list composed of up to 8 CoS, the range is 0~7;	
<b>Operation</b>	Add	Add matching rules
	Remove	Remove matching rules

Classification criteria configuration	
Classification criteria rule	ipv6 dscp <input type="button" value="v"/>
Class-map name	1 <input type="button" value="v"/>
IPv6 dscp0	
IPv6 dscp1	
IPv6 dscp2	
IPv6 dscp3	
IPv6 dscp4	
IPv6 dscp5	
IPv6 dscp6	
IPv6 dscp7	
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Classification criteria rule</b>	ipv6 dscp	Match the specified ipv6 DSCP value, this parameter is the ipv6 DSCP list
-------------------------------------	-----------	---

<b>Class-map name</b>	The name of the created class-matching table, select by clicking the drop-down	
<b>IPv6 dscp0-7</b>	One or more ipv6 DSCP values can be set, up to 8 DSCP values can be set, the range is 0~63	
<b>Operation</b>	Add	Add matching rules
	Remove	Remove matching rules

Classification criteria configuration	
Classification criteria rule	ipv6 flowlabel ▼
Class-map name	1 ▼
IPv6 flowlabel0	
IPv6 flowlabel1	
IPv6 flowlabel2	
IPv6 flowlabel3	
IPv6 flowlabel4	
IPv6 flowlabel5	
IPv6 flowlabel6	
IPv6 flowlabel7	
Operation	Add ▼
Apply	

<b>Classification criteria rule</b>	ipv6 flowlabel	Match the specified IPv6 flow label, this parameter is the value of the IPv6 flow label DSCP list
<b>Class-map name</b>	The name of the created class-matching table, select by clicking the drop-down	
<b>IPv6 flowlabel0-7</b>	One or more IPv6 flowlabel values can be set, ranging from 0 to 1048575;	
<b>Operation</b>	Add	Add matching rules
	Remove	Remove matching rules

```

Information feedback window
Switch# config t
Switch(config)# class-map c1
Switch(config-classmap-c1)# match access-group 1

```

Display configuration application execution process and return result

## 17.3. QoS policy configuration

### 17.3.1. QoS policy configuration

## 17 QOS configuration

Configure the policy table burst-group, provide the policy class-map to use

policy configuration	
policy burst id configuration:	1 ▾
policy burst size configuration	
Apply	

<b>Policy burst id configuration</b>	There are only two IDs, 1 and 2
<b>Policy burst size configuration</b>	The default is 1024, the range that can be set: 1-8192

### 17.4. QOS policy-map configuration

#### 17.4.1. Policy-map configuration

Create and delete policy tables, and collaborate with classification tables to create packet in and out rules

Policy-map configuration	
Policy-map name	
Operation	Add ▾
Apply	

<b>Policy-map name</b>	Policy-map name, range:1-64 character	
<b>Operation</b>	Add	Add policy-map
	Remove	Remove policy-map

Information feedback window	
Policy-map name	p1

Display the currently created policy-map.

#### 17.4.2. Class-map use to policy-map config

Apply the class-map to the policy-map.

Class-map use to policy-map configuration	
Policy-map name	p1 ▾
Class-map name	
Inserted before the class-map name	
Operation	Add ▾
Apply	

<b>policy-map name</b>	The name of the created policy-map	
<b>class-map name</b>	The name of the classification table created by the classification matching table, and this table will be applied to the policy -map	
<b>Inserted before the class-map name</b>	Prior to the insertion of the classification matching table, the name of the classification table that has been applied to the strategy table, and the priority of the newly applied classification matching table is increased	
<b>Operation</b>	Add	Add an association between the strategy table and the classification table
	Remove	Remove an association between the strategy table and the classification table

Information feedback window	
Policy-map name	Class-map name
p1	1

Display the association between the created policy table and the classification matching table

## 17.5. QoS policy-class-map configuration

### 17.5.1. Policy-class-map accounting configuration

Configure the statistics switch of the strategy table and the classification matching table, and display the association between the strategy table and the classification matching table.

Policy-class-map accounting configuration	
Policy-map name	p1 ▾
Class-map name	c1 ▾
Accounting switch	Disable ▾
Apply	

## 17 QOS configuration

<b>Policy-map name</b>	The name of the policy-map that has been created	
<b>class-map name</b>	The name of the classification matching table that has been created	
<b>accounting switch</b>	disable	Disable the traffic statistics function associated with the policy-map and class-map, and automatically establish an association if there is no association
	enabled	Start the traffic statistics function associated with the policy-map and class-map, and automatically establish an association if there is no association

Information feedback window		
Policy-map name	Class-map name	Accounting switch
p1	c1	Enable

Display the traffic statistics switch information of the associated policy-map and class-map table

### 17.5.2. Aggregate policy configuration

Configure the set strategy of the associated policy table and classification matching table. The policy mapping refers to the aggregation policy, and the aggregation policy is applied to the classified traffic. The same policy set can be referenced by different policy class mappings.

Aggregate policy configuration	
Policy-map name	p1 ▼
Class-map name	c1 ▼
Aggregate policy name	
Operation	Add ▼
Apply	

<b>Policy-map name</b>	Name of the created policy table
<b>Class-map name</b>	Classification match table created
<b>Aggregate policy name</b>	The name of the aggregation strategy, 1-64 characters in length

<b>Operation</b>	add	Start the set strategy associated with the strategy table and the classification matching table, and automatically establish the association if there is no associated strategy table and the classification matching table
	remove	Close the set strategy associated with the strategy table and the classification matching table, and automatically establish the association between the strategy table and the classification matching table without association

Information feedback window		
Policy-map name	Class-map name	Aggregate policy name
p1	c1	a1

Display the set policy information of the associated policy table and the classification matching table

### 17.5.3. Policy-class-map policy configuration

Configure the information rate in the policy mapping configuration mode.

Policy-class-map policy configuration	
Policy-map name	p1 ▾
Class-map name	c1 ▾
Committed information rate	
Committed burst id:	1 ▾
Operation	Add ▾
Apply	

<b>Policy-map name</b>	Name of the created policy table
<b>Class-map name</b>	Classification match table created
<b>Committed information rate</b>	Committed Information Rate-CIR (Committed Information Rate), in Kbps, ranging from 1 to 10,000,000;
<b>Committed burst ID</b>	The burst ID range is 1 and 2, and the main commitment is the burst size

<b>Operation</b>	add	Add the strategy information rate and burst size associated with the strategy table and the classification matching table, and automatically establish the association if there is no associated strategy table and the classification matching table
	remove	Delete the policy information rate and burst size associated with the policy table and the classification matching table, and automatically establish the association if there is no associated policy table and the classification matching table

#### 17.5.4. Policy-class-map set configuration

Configure the priority of packets in the policy mapping configuration mode. Assign a new DSCP and IP priority to the classified traffic. Only the classified traffic that meets the matching criteria will be assigned a new value.

Classification criteria configuration	
Classification criteria rule	ip dscp
Policy-map name	p1
Class-map name	c1
DSCP	
Operation	Add
Apply	

<b>Classification criteria rule</b>	ip dscp	Set the DSCP value again according to the rules defined in the policy-map and class-map
	ip precedence	Set the IP priority again according to the rules defined in the policy-map and class-map
	drop-precedence	Set the discarding priority again according to the rules defined in the policy-map and class-map
	internal-priority	Set the internal priority again according to the rules defined by the policy-map and class-map
	cos	Set the COS value again according to the rules defined by the policy table and the classification matching table
	ipv6 default nexthop vrf	Set the default next hop address again according to the rules defined in the policy table and classification matching table

<b>Policy-map name</b>	The name of the created policy table	
<b>Class-map name</b>	Created classification match table	
<b>DSCP</b>	DSCP value, range: 0-63	
<b>Precedence</b>	IP priority, range:0-7	
<b>Drop-precedence</b>	drop priority, range: 0-2	
<b>Internal-priority</b>	internal priority, range: 0-7	
<b>COS</b>	COS value, range: 0-7	
<b>Vrf</b>	Vrf value, range: 0-252	
<b>IPv6 Address (X:X::X:X)</b>	IPv6 default next hop address	
<b>Operation</b>	add	Add the priority and queue value associated with the strategy table and the classification matching table
	remove	Remove the priority and queue value associated with the strategy table and the classification matching table

## 17.6. QoS mapping configuration

### 17.6.1. COS-to-IntP mapping

Configure the value mapped from the COS value to the internal priority (queue).

CoS-to-IntP mapping								
CoS value	0	1	2	3	4	5	6	7
IntP value	0	1	2	3	4	5	6	7
Operation type	Configuration ▼							
								Apply

<b>CoS value</b>	The COS value carried in the message or the default COS value assigned when entering	
<b>IntP value</b>	The value of the internal priority (queue) to which the COS value will be mapped	
<b>Operation type</b>	Configuration	Configure the value of COS to IntP
	Default	Restore the mapping relationship to the default state

## 17 QOS configuration

```

Information feedback window
Switch# config t
Switch(config)# mls qos map cos-intp 2 1 2 3 4 5 6 7

Ingress COS-TO-Internal-Priority map:
COS:  0   1   2   3   4   5   6   7
-----
INTP:  2   1   2   3   4   5   6   7

```

Display the execution process and the current mapping relationship

### 17.6.2. COS-to-DP mapping

Configure the value mapped from the COS value to the drop priority (queue).

CoS-to-DP mapping									
CoS value	0	1	2	3	4	5	6	7	
DP value	0	0	0	0	0	0	0	0	0
Operation type	Configuration ▼								
									Apply

<b>CoS value</b>	The COS value carried in the message or the default COS value assigned when entering
<b>IntP value</b>	The value of the drop priority (queue) to which the COS value will be mapped

<b>Operation type</b>	Configuration	Configure COS to drop priority value
	default	Restore the mapping relationship to the default state

```

Information feedback window

Ingress COS-TO-Drop-Precedence map:
COS:  0   1   2   3   4   5   6   7
-----
DP:   0   0   0   0   0   0   0   0

```

Display the execution process and the current mapping relationship

### 17.6.3. DSCP-to-DSCP mapping

Configure the mapping from DSCP value to DSCP value.

DSCP-to-DSCP mapping	
DSCP value1	
DSCP value2(optional)	
DSCP value3(optional)	
DSCP value4(optional)	
DSCP value5(optional)	
DSCP value6(optional)	
DSCP value7(optional)	
DSCP value8(optional)	
DSCP value	
Operation type	Configuration ▾
Apply	

<b>DSCP value1-DSCP value8(optional)</b>	Up to eight DSCP values can be configured to the new DSCP value, among which DSCP value1 is required, DSCP value2-8 is optional, range: 0-63	
<b>DSCP value</b>	New DSCP value, range: 0-63	
<b>Operation type</b>	Configuration	Configure DSCP to DSCP value
	default	Restore the mapping relationship to the default state

```

Information feedback window
Switch# config t
Switch(config)# mls qos map dscp-dscp 63 60          to 1

Ingress DSCP-TO-DSCP map:
d1 : d2  0  1  2  3  4  5  6  7  8  9
0:      0  1  2  3  4  5  6  7  8  9
1:     10 11 12 13 14 15 16 17 18 19
2:     20 21 22 23 24 25 26 27 28 29
3:     30 31 32 33 34 35 36 37 38 39
4:     40 41 42 43 44 45 46 47 48 49
5:     50 51 52 53 54 55 56 57 58 59
6:      1 61 62  1
  
```

Shows the execution process and the current mapping relationship. The vertical d1 represents the tens digit of DSCP, and the horizontal d2 represents the single digit of DSCP. The value of the intersection of the two is the mapping value.

#### 17.6.4. DSCP-to-IntP mapping

Configure the value mapped from the DSCP value to the IntP value.

## 17 QOS configuration

DSCP-to-IntP mapping	
DSCP value1	
DSCP value2(optional)	
DSCP value3(optional)	
DSCP value4(optional)	
DSCP value5(optional)	
DSCP value6(optional)	
DSCP value7(optional)	
DSCP value8(optional)	
IntP value	
Operation type	Configuration ▾
Apply	

<b>DSCP value1-DSCP value8(optional)</b>	Up to eight DSCP values can be configured to the new IntP value, among which DSCP value1 is required, DSCP value2-8 is optional, range: 0-63	
<b>IntP value</b>	New IntP value, range: 0-7	
<b>Operation type</b>	Configuration	Configure DSCP to IntP value
	default	Restore the mapping relationship to the default state

```

Information feedback window
Switch# config t
Switch(config)# mls qos map dscp-intp 60 50 31      to 2

Ingress DSCP-TO-Internal-Priority map:
d1 : d2  0  1  2  3  4  5  6  7  8  9
0:      0  0  0  0  0  0  0  0  0  1  1
1:      1  1  1  1  1  1  1  2  2  2  2
2:      2  2  2  2  3  3  3  3  3  3  3
3:      3  2  4  4  4  4  4  4  4  4  4
4:      5  5  5  5  5  5  5  5  5  6  6
5:      2  6  6  6  6  6  6  7  7  7  7
6:      2  7  7  7  7

```

Shows the execution process and the current mapping relationship. The vertical d1 represents the tens digit of DSCP, and the horizontal d2 represents the single digit of DSCP. The value of the intersection of the two is the mapping value.

### 17.6.5. DSCP-to-DP mapping

Configure the value mapped from the DSCP value to the DP value.

DSCP-to-DP mapping	
DSCP value1	
DSCP value2(optional)	
DSCP value3(optional)	
DSCP value4(optional)	
DSCP value5(optional)	
DSCP value6(optional)	
DSCP value7(optional)	
DSCP value8(optional)	
DP value	
Operation type	Configuration ▾
Apply	

<b>DSCP value1-DSCP value8(optional)</b>	Up to eight DSCP values can be configured to the new DP value, among which DSCP value1 is required, DSCP value2-8 is optional, range: 0-63	
<b>DP value</b>	New DP value, range: 0-2	
<b>Operation type</b>	Configuration	Configure DSCP to DP value
	default	Restore the mapping relationship to the default state

Information feedback window											
Ingress DSCP-TO-Drop-Precedence map:											
d1 : d2	0	1	2	3	4	5	6	7	8	9	
0:	0	0	0	0	0	0	0	0	0	0	0
1:	0	0	0	0	0	0	0	0	0	0	0
2:	0	0	0	0	0	0	0	0	0	0	0
3:	0	0	0	0	0	0	0	0	0	0	0
4:	0	0	0	0	0	0	0	0	0	0	0
5:	0	0	0	0	0	0	0	0	0	0	0
6:	0	0	0	0							

Shows the execution process and the current mapping relationship. The vertical d1 represents the tens digit of DSCP, and the horizontal d2 represents the single digit of DSCP. The value of the intersection of the two is the mapping value.

### 17.6.6. EXP-to-IntP mapping

Configure the value mapped from EXP value to IntP.

## 17 QOS configuration

EXP-to-IntP mapping								
EXP value	0	1	2	3	4	5	6	7
IntP value	0	1	2	3	4	5	6	7
Operation type	Configuration ▼							
								Apply

<b>EXP value</b>	EXP value carried in the message, range: 0-7	
<b>IntP value</b>	New IntP value, range: 0-7	
<b>Operation type</b>	Configuration	Configure DSCP to IntP value
	default	Restore the mapping relationship to the default state

### 17.6.7. EXP-to-DP mapping

Configure the value mapped from EXP value to DP.

EXP-to-DP mapping								
EXP value	0	1	2	3	4	5	6	7
DP value	0	0	0	0	0	0	0	0
Operation type	Configuration ▼							
								Apply

<b>EXP value</b>	EXP value carried in the message, range: 0-7	
<b>DP value</b>	New DP value, range: 0-2	
<b>Operation type</b>	Configuration	Configure EXP to DP value
	default	Restore the mapping relationship to the default state

### 17.6.8. IntP-to-DSCP mapping

Configure the value mapped from IntP value to DSCP.

IntP-to-DSCP mapping								
IntP value	0	1	2	3	4	5	6	7
DSCP value	0	8	16	24	32	40	48	56
Operation type	Configuration ▼							
								Apply

<b>IntP value</b>	The value of the internal priority of the message, range: 0-7	
<b>DSCP value</b>	New DSCP value, range: 0-63	
<b>Operation type</b>	Configuration	Configure IntP to DSCP value
	default	Restore the mapping relationship to the default state

### 17.6.9. IntP-to-EXP mapping

Configure the value mapped from IntP value to EXP.

IntP-to-EXP mapping								
IntP value	0	1	2	3	4	5	6	7
EXP value	0	1	2	3	4	5	6	7
Operation type	Configuration ▾							
								Apply

<b>IntP value</b>	The value of the internal priority of the message, range: 0-7	
<b>EXP value</b>	New EXP value, range: 0-7	
<b>Operation type</b>	Configuration	Configure IntP to EXP value
	default	Restore the mapping relationship to the default state

### 17.7. QoS aggregate policy configuration

Configure the new aggregation strategy and the information rate and burst id of the aggregation strategy.

QoS aggregate policy configuration	
Aggregate policer name	<input type="text"/>
Committed Information Rate	<input type="text"/>
policy burst id configuration:	1 ▾
Operation	Add ▾
Apply	

<b>Aggregate policer name</b>	New aggregate policer name, range: 1-64 character.	
<b>Committed Information Rate</b>	Information Rate, range: 1-10000000kbit/s	
<b>Policy burst id configuration</b>	Burst id configuration, range: 1-2	
<b>Operation</b>	Add	Add aggregate policer
	Remove	Remove aggregate policer

```

Information feedback window
Switch# config t
Switch(config)# mls qos aggregate-policy aggl 10000 burst-group 1

```

Display the configuration process and results, no error will be reported after normal configuration.

## 17.8. QoS service policy configuration

Configure VLAN Association Policy.

QoS service policy configuration	
Policy-map name	p1 ▾
Vlan List	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>Policy-map name</b>	The name of the created strategy, select by clicking the drop-down	
<b>VLAN List</b>	VLAN ID, range: 1-4094	
<b>Operation</b>	add	Add VLAN-based policy
	remove	remove VLAN-based policy

```

Information feedback window
Switch# config t
Switch(config)# service-policy input p1 vlan 2
    
```

Display the configuration process and results, no error will be reported after normal configuration.

## 18. L3 forward configuration

### 18.1. IP route Aggregation configuration

#### 18.1.1. Route aggregate configuration

This page is used for enabled or disabled configuration of routing aggregation. To display the "Route aggregate configuration" page, click L3 forward configuration->IP route Aggregation configuration->Route aggregate configuration, click "Apply" to configure.

Enable route aggregation	
Enable route aggregation	Disable ▾
Apply	

entry	describe
<b>Enable route aggregation</b>	Enable: Enable routing aggregation Disable: Disable routing aggregation

Route aggregation status	
Route aggregation status	disable

entry	describe
<b>Routing aggregation state</b>	Enable: Enable routing aggregation Disable: Disable routing aggregation

### 18.2. ARP configuration

#### 18.2.1. ARP configuration

This page is used to configure ARP static entries. To display the "ARP configuration" page, click L3 forward configuration->ARP configuration->ARP configuration, click "Apply" to configure.

**18 L3 forward configuration**

ARP configuration	
IP address	<input type="text"/>
MAC address	<input type="text"/>
Operation type	Add <input type="button" value="v"/>
VLAN interface	Vlan1 <input type="button" value="v"/>
Port	Ethernet1/0/1 <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>IP address</b>	IP address, e.g., 1.1.1.1
<b>MAC address</b>	MAC address
<b>Operation type</b>	Add: Apply the above settings Remove: Delete the above
<b>VLAN interface</b>	VLAN id created
<b>Port</b>	Ethernet port name

**18.2.2. Clear ARP cache**

This page is used to clear ARP statistics.  
 To display the "Clear ARP cache" page, click L3 forward configuration->ARP configuration->Clear ARP cache, click "Apply" to configure.

Clear ARP cache	
<input type="button" value="Apply"/>	

**18.2.3. Show ARP**

This page is used to view the information of the ARP table.  
 To display the "Clear ARP cache" page, click L3 forward configuration->ARP configuration->Clear ARP cache.

ARP list				
Binding IP	Binding MAC	Interface	Port	flag
192.168.2.74	00-0e-c6-bf-ad-7a	Vlan1	Ethernet1/0/14	dynamic
Number of ARP entry				
Number of ARP entry			1	
				<input type="button" value="Refresh"/>

### 18.3. Gratuitous arp config

#### 18.3.1. gratuitous-arp interval time configuration

This page is used to configure the global free ARP send time interval. To display the “gratuitous-arp interval time configuration” page, click L3 forward configuration->Gratuitous arp config->gratuitous-arp interval time configuration, click "Apply" to configure.

gratuitous-arp interval time configuration	
interval time	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
interval time	Range: 5-1200 seconds
Operation	Add: Apply the above settings Remove: Recovery default interval 300 seconds

#### 18.3.2. interface gratuitous-arp interval time configuration

This page is used to set vlan interface free ARP send interval configuration. To display the “interface gratuitous-arp interval time configuration” page, click L3 forward configuration->Gratuitous arp config->interface gratuitous-arp interval time configuration, click "Apply" to configure.

interface gratuitous-arp interval time configuration	
Vlan ID	1 <input type="button" value="v"/>
interval time	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
VLAN ID	vlan ID created
interval time	Range :5-1200 seconds
Operation	Add: Apply the above settings Remove: Recovery default interval 300 seconds

## 18 L3 forward configuration

### 18.3.3. show gratuitous-arp configuration

This page is used to view ARP free configuration information.

To display the “show gratuitous-arp configuration” page, click L3 forward configuration->Gratuitous arp config->show gratuitous-arp configuration, click "Apply" to view.

gratuitous-arp interval time configuration	
Vlan ID	▼
<input type="button" value="Apply"/>	

```
Information feedback window
Switch# show ip gratuitous-arp
Gratuitous ARP send is Global disabled
Gratuitous ARP send enabled interface vlan information:
Name          Interval-Time(seconds)
```

## 18.4. ARP protection configuration

### 18.4.1. ARP GUARD configuration

#### 18.4.1.1. ARP GUARD configuration

This page is used for ARP GUARD configuration.

To display the “ARP GUARD configuration” page, click L3 forward configuration->ARP protection configuration->ARP GUARD configuration->ARP GUARD configuration, click "Apply" to configure.

ARP GUARD configuration	
Port	Ethernet1/0/1 ▼
IP address	<input type="text"/>
Operation	Add ▼
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>IP address</b>	IP address, e.g., 1.1.1.1
<b>Operation</b>	Add: Apply the above settings Remove: Delete the above settings

### 18.4.2. ANTI-ARPSCAN configuration

### 18.4.2.1. ANTI-ARPSCAN on-off configuration

This page is used to configure the anti ARP scan function switch.

To display the “ARP GUARD configuration” page, click L3 forward configuration->ARP protection configuration->ANTI-ARPSCAN configuration->ANTI-ARPSCAN on-off configuration, click "Apply" to configure.

ANTI-ARPSCAN on-off configuration	
ANTI-ARPSCAN on-off status	Disable ▾
Apply	

ANTI-ARPSCAN on-off status	
ANTI-ARPSCAN on-off status	Disable

entry	describe
<b>ANTI-ARPSCAN on-off status</b>	Enable: Function Enable Disable: Function disabled

### 18.4.2.2. ANTI-ARPSCAN port-based threshold configuration

This page is available for port-based configuration of anti-scan ARP thresholds.

To display the “ANTI-ARPSCAN port-based threshold configuration” page, click L3 forward configuration->ARP protection configuration->ANTI-ARPSCAN configuration->ANTI-ARPSCAN port-based threshold configuration, click "Apply" to configure.

ANTI-ARPSCAN port-based threshold configuration	
Range of threshold	<input type="text"/>
Operation	Configuration ▾
Apply	

entry	describe
<b>Range of threshold</b>	Size range: 2-200, unit pack/s
<b>Operation</b>	Configuration: Application settings Default: Restore default 10 packs/s

**18 L3 forward configuration**

ANTI-ARPSCAN port-based threshold configuration	
Range of threshold	16

entry	describe
Range of threshold	Current configured threshold, size range: 2-200, unit pack/second

**18.4.2.3. ANTI-ARPSCAN IP-based threshold configuration**

This page is used to configure the IP-based anti ARP scan threshold. To display the “ANTI-ARPSCAN IP-based threshold configuration” page, click L3 forward configuration->ARP protection configuration-> ANTI-ARPSCAN configuration->ANTI-ARPSCAN IP-based threshold configuration, click "Apply" to configure.

ANTI-ARPSCAN IP-based threshold configuration	
Range of threshold	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
Range of threshold	Size range: 2-200, unit pack/s
Operation	Configuration: Application settings Default: Restore default 6 packs/s

ANTI-ARPSCAN IP-based threshold configuration	
Range of threshold	8

entry	describe
Range of threshold	Current configured threshold, size range: 2-200, unit pack/second

#### 18.4.2.4. ANTI-ARPSCAN trust port configuration

This page is used to set the port to anti ARP scan trust port.

To display the “ANTI-ARPSCAN trust port configuration” page, click L3 forward configuration->ARP protection configuration->ANTI-ARPSCAN configuration->ANTI-ARPSCAN trust port configuration, click "Apply" to configure.

ANTI-ARPSCAN trust port configuration	
Port	Ethernet1/0/1 ▾
Port trust status	trust-port ▾
Operation	Add ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Port</b>	Ethernet port name
<b>Port trust status</b>	trust-port: Trust port supertrust-port: Super trust port iptrust-port: IP trust port
<b>Operation</b>	Add: Application settings Remove: Delete the corresponding settings

#### 18.4.2.5. ANTI-ARPSCAN trust IP configuration

This page can be used to prevent ARP scanning trust IP configuration.

To display the “ANTI-ARPSCAN trust IP configuration” page, click L3 forward configuration->ARP protection configuration->ANTI-ARPSCAN configuration->ANTI-ARPSCAN trust ip configuration, click "Apply" to configure.

ANTI-ARPSCAN trust IP configuration	
IP address	<input type="text"/>
Network mask	<input type="text"/>
Operation	Add ▾
<input type="button" value="Apply"/>	

entry	describe
<b>IP address</b>	IP address, e.g., 1.1.1.1
<b>Network mask</b>	Corresponding IP address mask
<b>Operation</b>	Add: Application settings Remove: Delete the corresponding

**18 L3 forward configuration**

	settings
--	----------

**18.4.2.6. ANTI-ARPSCAN recovery on-off configuration**

This page can be used to prevent ARP scanning automatic recovery switch configuration.

To display the “ANTI-ARPSCAN recovery on-off configuration” page, click L3 forward configuration->ARPprotection configuration-> ANTI-ARPSCAN configuration->ANTI-ARPSCAN recovery on-off configuration, click "Apply" to configure.

ANTI-ARPSCAN recovery on-off configuration	
ANTI-ARPSCAN recovery on-off status	Enable ▾
Apply	

ANTI-ARPSCAN recovery on-off status	
ANTI-ARPSCAN recovery on-off status	Enable

entry	describe
<b>ANTI-ARPSCAN recovery on-off status</b>	Enable: Enable automatic recovery function Disable: Disable automatic recovery function

**18.4.2.7. ANTI-ARPSCAN recovery time configuration**

This page can be used to configure the automatic recovery time against ARP scanning.

To display the “ANTI-ARPSCAN recovery time configuration” page, click L3 forward configuration->ARPprotection configuration-> ANTI-ARPSCAN configuration->ANTI-ARPSCAN recovery time configuration, click "Apply" to configure.

ANTI-ARPSCAN recovery time configuration	
Recovery time	<input type="text"/>
Operation	Configuration ▾
Apply	

ANTI-ARPSCAN recovery time configuration	
Recovery time	300

entry	describe
<b>Recovery time</b>	Size range :5-86400 per second
<b>Operation</b>	Configuration: Apply the above settings Default: Recovery default auto recovery 300 seconds

### 18.4.2.8. Show ANTI-ARPSCAN information

This page is used to view anti ARP scan run information.

To display the "Show ANTI-ARPSCAN information" page, click L3 forward configuration->ARP protection configuration-> ANTI-ARPSCAN configuration->Show ANTI-ARPSCAN information, click "Apply" to view.

```

Information feedback window
Switch# show anti-arpscan
Total port: 28
Name          Port-property  beShut  shutTime(seconds)
Ethernet1/0/1  untrust       N       0
Ethernet1/0/2  untrust       N       0
Ethernet1/0/3  untrust       N       0
Ethernet1/0/4  untrust       N       0
Ethernet1/0/5  untrust       N       0
Ethernet1/0/6  untrust       N       0
Ethernet1/0/7  untrust       N       0
Ethernet1/0/8  untrust       N       0

```

### 18.5. Show IP Traffic

This page can be used to view statistics for IP packets.

To display the "Show IP Traffic" page, click L3 forward configuration->ARP protection configuration -> Show IP Traffic, click "Apply" to view.

```

Information feedback window
Switch# show ip traffic
IP statistics:
  Rcvd:  134947 total, 135005 local destination
         0 header errors, 0 address errors
         0 unknown protocol, 0 discards
  Frags: 0 reassembled, 0 timeouts
         0 fragment rcvd, 0 fragment dropped
         0 fragmented, 0 couldn't fragment, 0 fragment sent
  Sent:  138810 generated, 0 forwarded
         0 dropped, 0 no route
ICMP statistics:
  Rcvd:  0 total 0 errors 0 time exceeded
         0 redirects, 0 unreachable, 0 echo, 0 echo replies
         0 mask requests, 0 mask replies, 0 quench
         0 parameter, 0 timestamp, 0 timestamp replies
  Sent:  0 total 0 errors 0 time exceeded
         0 redirects, 0 unreachable, 0 echo, 0 echo replies
         0 mask requests, 0 mask replies, 0 quench
         0 parameter, 0 timestamp, 0 timestamp replies
TCP statistics:
  TcpActiveOpens      6,  TcpAttemptFails      0
  TcpCurrEstab        3,  TcpEstabResets          3
  TcpInErrs           0,  TcpInSegs              135005
  TcpMaxConn          264,  TcpOutRsts              0
  TcpOutSegs          138868,  TcpPassiveOpens        1738
  TcpRetransSegs      167,  TcpRtoAlgorithm         1
  TcpRtoMax           120000,  TcpRtoMin               200
UDP statistics:
  UdpInDatagrams      0,  UdpInErrors             0
  UdpNoPorts          0,  UdpOutDatagrams        0

```

## 19. Route configuration

### 19.1. Policy based routing

The directory function is to be developed.

### 19.2. Static route configuration

#### 19.2.1. Static route configuration

This page can be used for the basic configuration of static routing.

To display the "Static route configuration" page, click Route configuration ->Static route configuration->Static route configuration, click "Apply" to configure.

Static IP route configuration	
Destination IP address	<input type="text"/>
Network mask or prefix-length	<input type="text"/>
Nexthop or Interface null0	<input type="text"/>
preference(optional)	<input type="text"/>
Operation type	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
<b>Destination IP address</b>	IP address, format: 10.10.11.11
<b>Network mask or prefix-length</b>	Subnet mask in the following format: 255.255.255.0; or mask length
<b>Nexthop or Interface null0</b>	IP address, format: 10.10.11.11. or null0
<b>preference(optional)</b>	Range: 1-255
<b>Operation type</b>	Add: Add the above settings Remove: Delete the above

## 20. IPv6 Route configuration

### 20.1. IPv6 configuration

#### 20.1.1. IPv6 basic configuration

This page is used to vlan the ipv6 address of the interface and the configuration of ipv6 routing.

If you want to display the “IPv6 Basic Configuration” page, click IPv6 Route configuration->IPv6 configuration->IPv6 basic configuration, click "Apply" to configure.

IPv6 basic configuration	
command	ipv6 address ▾
VLAN interface	Vlan1 ▾
IPv6 address(X:X::X:X/M)	<input type="text"/>
EUI-64	▾
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
<b>IPV6 address</b>	vlan interface ipv6 address configuration
<b>VLAN interface</b>	vlan created
<b>IPv6 address</b>	Example: 2001:3f:ed8::99/64
<b>EUI-64</b>	IPv6 address is automatically generated based on the eui64 interface identifier of the interface
<b>Operation</b>	Configure: User self-configuration Default: Restore default configuration

## 20 IPv6 Route configuration

IPv6 basic configuration	
command	ipv6 route ▾
IPv6 Destination address(X:X::X:X/M)	<input type="text"/>
IPv6 nexthop address(X:X::X:X)	<input type="text"/>
VLAN interface	▾
IPv6 tunnel number	<input type="text"/>
Precedence	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

**Note:** the switch does not support ipv6 routing configuration, the configuration of this page is not effective.

### 20.1.2. IPv6 ND configuration

This page is used for settings that can be used for neighbor discovery related functions.

If you display the “IPv6 ND Configuration” page, click IPv6 Route configuration->IPv6 configuration->IPv6 ND Configuration, click "Apply" to configure.

IPv6 ND configuration	
command	dad attempts ▾
VLAN interface	Vlan1 ▾
IPv6 dad-attempts	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Data attempts</b>	During duplicate address detection, the neighbor request message number continuously sent by the interface is set
<b>VLAN interface</b>	vlan created
<b>IPv6 dad-attempts</b>	Range :0-10

<b>Operation</b>	Configuration: Apply the above settings Default: Default request message number is 1
------------------	---

IPv6 ND configuration	
command	ns-interval ▾
VLAN interface	Vlan1 ▾
IPv6 ns-interval	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>ns-interval</b>	Time interval setting for neighbor request messages
<b>VLAN interface</b>	vlan created
<b>IPv6 ns-interval</b>	Size range: 1-3600, per second
<b>Operation</b>	Configuration: Apply the above settings Default: Default request message number is 1 second

IPv6 ND configuration	
command	neighbor ▾
VLAN interface	Vlan1 ▾
IPv6 address	<input type="text"/>
MAC address	<input type="text"/>
Port	Ethernet1/0/1 ▾
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Neighbor</b>	Set the Static Neighbor Table Item
<b>VLAN interface</b>	vlan created
<b>IPv6 address</b>	Static Neighbor IPv6 Address
<b>MAC address</b>	Static Neighbor MAC Address
<b>Port</b>	Ethernet port name

**20 IPv6 Route configuration**

<b>Operation</b>	Configuration: Apply the above settings Default: delete the corresponding static neighbor table item
------------------	---

IPv6 ND configuration	
command	clear ipv6 neighbors ▾
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Clear ipv6 neighbor</b>	Clear neighbor table items, but cannot delete static neighbor table items
<b>Operation</b>	Configuration: Delete neighbor table item Default: Delete Neighbor Table Item

**20.1.3. Show IPv6 neighbor**

This page is used to view ipv6 neighbor information.

To display the "Show IPv6 neighbor" page, click IPv6 Route configuration->IPv6 configuration->Show IPv6 neighbor, click "Apply" to view.

Show IPv6 neighbor	
Parameter choose	Address ▾
IPv6 address	<input type="text"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Address</b>	Based on address
<b>IPV6 address</b>	Ipv6 address

Show IPv6 neighbor	
Parameter choose	Count ▾
Apply	

<b>entry</b>	describe
<b>Count</b>	Display counter information

Show IPv6 neighbor	
Parameter choose	Vlan ▾
VLAN ID	<input type="text"/>
Apply	

<b>entry</b>	describe
<b>Vlan</b>	vlan Based Interface
<b>Vlan id</b>	vlan id created

Show IPv6 neighbor	
Parameter choose	Ethernet ▾
Ethernet port	<input type="text"/>
Apply	

<b>entry</b>	describe
<b>ethernet</b>	Based on Ethernet port
<b>Ethernet port</b>	Physical Port Name

## 20.2. Show IPv6 route

### 20.2.1. Show IPv6 route database

This page is used to view IPv6 routing table database information. To display the "Show IPv6 route database" page, click IPv6 Route configuration->Show IPv6 route->Show IPv6 route database, click "Apply" to view.

**20 IPv6 Route configuration**

Show IPv6 route database	
Parameter choose	destination ▾
IPv6 address	<input type="text"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Destination</b>	Based on ipv6 address
<b>IPv6 address</b>	ipv6 address in the routing table

Show IPv6 route database	
Parameter choose	prefix ▾
IPv6 address(X:X::X:X/M)	<input type="text"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Prefix</b>	Based on ipv6 address
<b>IPv6 address</b>	ipv6 address in the routing table

Show IPv6 route database	
Parameter choose	database ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>database</b>	Routing table database information

**20.2.2. Show IPv6 NSM route**

This page is used to view IPV6 NSM routing table information.

To display the "Show IPv6 NSM route" page, click IPv6 Route configuration->Show IPv6 route->Show IPv6 NSM route, click "Apply" to view.

Show IPv6 route database	
Parameter choose	<input type="text" value=""/>
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show ipv6 route database
IPv6 Routing Table
Codes: K - kernel route, C - connected, S - static, R - RIP, O - OSPF,
       I - IS-IS, B - BGP
       > - selected route, * - FIB route, p - stale info
Timers: Uptime
C*> ::1/128 via ::, Loopback, 03:55:41 tag:0
  
```

entry	describe
connected	IPv6 routing table information from NSM

Show IPv6 NSM route	
Parameter choose	database <input type="text" value=""/>
Parameter choose	connected <input type="text" value=""/>
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show ipv6 route nsm database connected
IPv6 Routing Table
Codes: K - kernel route, C - connected, S - static, R - RIP, O - OSPF,
       I - IS-IS, B - BGP
       > - selected route, * - FIB route, p - stale info
Timers: Uptime
C*> ::1/128 via ::, Loopback, 03:57:50 tag:0
  
```

entry	describe
database	IPv6 Routing Table Database
connected	Route table information

### 20.2.3. Show IPv6 FIB

This page is used to view IPv6 forward information.

To display the "Show IPv6 FIB" page, click IPv6 Route configuration->Show IPv6 route->Show IPv6 FIB, click "Apply" to view.

**20 IPv6 Route configuration**

Show IPv6 FIB	
Parameter choose	<input type="text" value=""/>
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show ipv6 route fib
Total IPv6 routes: 2 entries
Codes: C - connected, L - Local, S - static, R - RIP, O - OSPF,
       I - IS-IS, B - BGP
C   fe80::/64   via ::,   Vlan1   0
C   ff00::/8   via ::,   Vlan1   0
    
```

<b>entry</b>	describe
<b>Blank parameters</b>	Forwarding Information Database

Show IPv6 FIB	
Parameter choose	<input type="text" value="local"/>
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show ipv6 route fib local
Total IPv6 routes: 3 entries
::1/128   via ::,   Loopback
fe80::21f:ceff:fe10:b01a/128   via ::,   Loopback
    
```

<b>entry</b>	describe
<b>Local</b>	Local table

Show IPv6 FIB	
Parameter choose	<input type="text" value="vrf"/>
VRF ID(0-255)	<input type="text" value=""/>
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show ipv6 route fib vrf 0 statistics
Route statistics:
Total routes are : 4 item(s)
Total unspec routes are : 0 item(s)
Total boot routes are : 2 item(s)
Total kernel routes are : 2 item(s)
Total connected routes are : 0 item(s)
Total static routes are : 0 item(s)
Total rip routes are : 0 item(s)
Total bgp routes are : 0 item(s)
Total ospf routes are : 0 item(s)
Total ospf external routes are : 0 item(s)
Total dvmrp routes are : 0 item(s)
Total unknown routes are : 0 item(s)

```

<b>entry</b>	describe
<b>Vrf</b>	Virtual routing transponder
<b>VRF ID(0-255)</b>	Virtual Route Forwarder Number

**Show IPv6 FIB**

Parameter choose	statistics ▾
<input type="button" value="Apply"/>	

```

Information feedback window
Switch# show ipv6 route fib statistics
Route statistics:
Total routes are : 4 item(s)
Total unspec routes are : 0 item(s)
Total boot routes are : 2 item(s)
Total kernel routes are : 2 item(s)
Total connected routes are : 0 item(s)
Total static routes are : 0 item(s)
Total rip routes are : 0 item(s)
Total bgp routes are : 0 item(s)
Total ospf routes are : 0 item(s)
Total ospf external routes are : 0 item(s)
Total dvmrp routes are : 0 item(s)
Total unknown routes are : 0 item(s)

```

<b>entry</b>	describe
<b>statistics</b>	Routing table statistics

### 20.2.4. Show IPv6 route statistics

This page is used to view IPv6 routing statistics.

To display the "Show IPv6 route statistics" page, click IPv6 Route configuration->Show IPv6 route->Show IPv6 route statistics "Apply" to view.

Show IPv6 route statistics	
Parameter choose	▼
<input type="button" value="Apply"/>	

```
Information feedback window
Switch# show ipv6 route statistics
Route statistics:
Total routes are : 1 item(s)
Total default routes are : 0 item(s)
Total kernel routes are : 0 item(s)
Total connected routes are : 1 item(s)
Total static routes are : 0 item(s)
Total rip routes are : 0 item(s)
Total bgp routes are : 0 item(s)
Total ospf routes are : 0 item(s)
Total ospf intra area routes are : 0 item(s)
Total ospf inter area routes are : 0 item(s)
Total ospf nssa type 1 routes are : 0 item(s)
Total ospf nssa type 2 routes are : 0 item(s)
Total ospf external type 1 routes are : 0 item(s)
Total ospf external type 2 routes are : 0 item(s)
```

**Note:** The corresponding function of parameter vrf has not been realized.

## 21. DCSCM configuration

### 21.1. DCSCM Source-control enable/disable configuration

Configure DCSCM multicast source control configuration and view the configuration status.

DCSCM Source-control enable/disable configuration	
DCSCM Source-control enable/disable configuration	Enable ▾
Apply	

<b>DCSCM Source-control enable/disable configuration</b>	Enable	Enable DCSCM multicast source control configuration
	Disable	Disable DCSCM multicast source control configuration

DCSCM Source-control state	
DCSCM Source-control state	Disable

Display the current configuration status

### 21.2. DCSCM destination-control enable/disable configuration

Configure DCSCM multicast destination control configuration and view configuration status.

DCSCM destination-control enable/disable configuration	
DCSCM destination-control enable/disable configuration	Enable ▾
Apply	

<b>DCSCM destination-control enable/disable configuration</b>	Enable	Enable DCSCM multicast destination control configuration
	Disable	Disable DCSCM multicast destination control configuration

DCSCM destination-control enable/disable state	
DCSCM destination-control enable/disable state	Disable

Display the current configuration status

### 21.3. DCSCM Source-control access-group configuration

Configure DCSCM multicast source control list configuration and view the configuration status of the configuration list.

DCSCM Source-control access-group configuration	
Port	Ethernet1/0/1 ▾
DCSCM Source-control access-group number	
Operation	Add ▾
Apply	

Port	Port name	
<b>DCSCM destination-control access-group number</b>	Match the multicast data message imported from the interface according to the configured source control list number. The source control list number is derived from the ACL multicast source control configuration of ACL multicast control, range: 5000-5099	
<b>Operation</b>	Add	Add source control list number under port
	Remove	Delete the source control list from the port

DCSCM Source-control access-group	
Port	DCSCM Source-control access-group number
Ethernet1/0/1	5000

Display the currently configured port and the corresponding source control list number (there is no port configured by default)

### 21.4. DCSCM destination-control access-group configuration

Configure DCSCM multicast destination control list configuration and view configuration list configuration status.

DCSCM destination-control access-group configuration	
Port	Ethernet1/0/1 ▾
DCSCM destination-control access-group number	
Operation	Add ▾
Apply	

<b>Port</b>	Port name	
<b>DCSCM destination-control access-group number</b>	Match the multicast data message imported from the interface according to the configured destination control list number. The destination control list number is derived from the ACL multicast destination control configuration of ACL multicast control, range: 6000-7999	
<b>Operation</b>	Add	Add the destination control list number under the port
	Remove	Delete the destination control list from the port

DCSCM destination-control access-group	
Port	DCSCM destination-control access-group number
Ethernet1/0/1	6000

Display the currently configured port and the corresponding destination control list number (there is no port configured by default)

## 21.5. DCSCM destination-control access-group configuration(sip)

Configure the IP-based DCSCM port multicast destination control list configuration and view the configuration list configuration status.

DCSCM destination-control access-group configuration(sip)	
DCSCM destination-control IP-address/mask	<input type="text"/>
DCSCM destination-control access-group number	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>DCSCM destination-control IP-address/mask</b>	Determine the members of the multicast group according to the specified network end and mask. When the multicast group member matches the control list number, the interface can be added, otherwise the interface is not added
<b>DCSCM destination-control access-group number</b>	Match the multicast data message imported from the specified network according to the configured destination control list number. The destination control list number is configured from the ACL multicast destination control configuration of ACL multicast control, range: 6000-7999

## 21 DCSCM configuration

<b>Operation</b>	Add	Add the destination control list number under the designated network terminal
	Remove	Delete the destination control list from the specified network segment

DCSCM destination-control access-group(sip)	
DCSCM destination-control IP-address/mask	DCSCM destination-control access-group number
10.0.0.0/24	6000

Display the current configured destination IP address and the corresponding destination control list number (there is no configured port by default)

### 21.6. DCSCM destination-control access-group configuration(vMAC)

Configure VLAN-MAC based DCSCM multicast source control list configuration and view the configuration list configuration status.

DCSCM destination-control access-group configuration(vMAC)	
VLAN interface	Vlan1 ▾
MAC address	
DCSCM destination-control access-group number	
Operation	Add ▾
<input type="button" value="Apply"/>	

<b>VLAN interface</b>	VLAN interface	
<b>MAC address</b>	Transmit the source MAC address of IGMP-REPORT, the format is "xx-xx-xx-xx-xx-xx"	
<b>DCSCM destination-control access-group number</b>	Match the multicast data message imported from the interface according to the configured destination control list number. The destination control list number is derived from the ACL multicast destination control configuration of ACL multicast control, range: 6000-7999	
<b>Operation</b>	Add	Add the destination control list number to the host corresponding to the MAC address in the VLAN
	Remove	Delete the destination control list from the corresponding MAC address host under the VLAN

DCSCM destination-control access-group(vMAC)		
VLAN interface	MAC address	DCSCM destination-control access-group number
1	01-00-22-33-44-55	6000

Display the mac host and the corresponding destination control list number under the currently configured vlan (there is no configured port by default)

## 21.7. Multicast policy configuration

Configure multicast policy and view configuration status.

Multicast policy configuration	
Source IP-address/mask	<input type="text"/>
Destination IP-address/mask	<input type="text"/>
DCSCM priority	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Source IP-address/mask</b>	The source IP address range of multicast data packets, format: 192.168.2.0/24	
<b>Destination IP-address/mask</b>	The destination IP address range of multicast data packets, format: 224.0.0.0/8	
<b>DCSCM priority</b>	Specify priority, range: 0-7	
<b>Operation</b>	Add	Configure the switch matching priority of multicast data packets in a specified range to be modified to a specified value, and TOS is also specified to the same value
	Remove	Delete the priority policy of multicast data in the specified range

Multicast policy	
ip multicast-policy 192.168.2.0/24 224.168.2.0/24 cos 1	

Display the currently configured multicast policy

## 21.8. ACL multicast source control

Configure ACL access rules and view the configuration status of the configuration list.

## 21 DCSCM configuration

ACL multicast source control	
ACL number	<input type="text"/>
Rule	permit ▼
Source address type	Any IP ▼
Multicast source address	<input type="text"/>
Multicast source wildcard	<input type="text"/>
Source address type	Any IP ▼
Multicast destination address	<input type="text"/>
Multicast destination wildcard	<input type="text"/>
Operation type	Add ▼
<input type="button" value="Apply"/>	

<b>ACL number</b>	ACL number, range: 5000-5099	
<b>Rule</b>	permit	Allow the following rules to pass
	deny	Reject the following rules to pass
<b>Source address type</b>	Specified address	An address range determined by IP addresses and address wildcards
	Any IP	Any host address
	Host Address	A specified address (set in the multicast source/destination IP address)
<b>Multicast source/destination address</b>	The address type is the host address and the IP address set when specifying the address, for example: 10.1.1.0 or 192.168.5.1	
<b>Multicast source/destination wildcard</b>	The address type is the wildcard set when specifying the address, for example: 0.0.0.255	
<b>Operation type</b>	Add	Add the set rules to the ACL number, and other functions use the source control list number to use these rules
	Remove	Delete the rule of ACL number

ACL multicast destination control	
ACL number	<input type="text"/>
Rule	permit ▼
Source address type	Any IP ▼
Multicast source address	<input type="text"/>
Multicast source wildcard	<input type="text"/>
Source address type	Any IP ▼
Multicast destination address	<input type="text"/>
Multicast destination wildcard	<input type="text"/>
Operation type	Add ▼
<input type="button" value="Apply"/>	

<b>ACL number</b>	ACL number, range: 5000-5099	
<b>Rule</b>	permit	Allow the following rules to pass
	deny	Reject the following rules to pass
<b>Source address type</b>	Specified address	An address range determined by IP addresses and address wildcards
	Any IP	Any host address
	Host Address	A specified address (set in the multicast source/destination IP address)
<b>Multicast source/destination address</b>	The address type is the host address and the IP address set when specifying the address, for example: 10.1.1.0 or 192.168.5.1	
<b>Multicast source/destination wildcard</b>	The address type is the wildcard set when specifying the address, for example: 0.0.0.255	
<b>Operation type</b>	Add	Add the set rules to the ACL number, and other functions use the ACL number to use these rules
	Remove	Delete the rule of ACL number

```

Information feedback window
Switch# show ip multicast source-control access-list
access-list 5000 permit ip any-source any-destination
access-list 5093 permit ip any-source any-destination
Switch# show ip multicast destination-control access-list
access-list 6000 permit ip any-source any-destination
  
```

Display the currently configured multicast source control list number and multicast destination control list number rules

## 22. Spanning-tree configuration

### 22.1. Spanning-tree field configuration

#### 22.1.1. Instance configuration

This page can be used to configure the mapping relationship between the spanning tree instance and the VLAN.

To display the "Instance configuration" page, click Spanning-tree configuration ->Spanning-tree field configuration->Instance configuration, click "Apply" to configure.

Instance configuration	
Instance name	<input type="text"/>
VLAN name	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
<b>Instance name</b>	Generating tree instance ID, range 0-64
<b>VLAN name</b>	VLAN ID, range: 1-4094
<b>Operation</b>	Add: Add the above configuration information Remove: Delete the above configuration information

Instance configuration	
Instance name	VLAN name
0	1-4094

entry	describe
<b>Instance name</b>	Generating tree instance ID, size range 0-64
<b>VLAN name</b>	VLAN ID, range: 1-4094

### 22.1.2. Field name configuration

This page can be used to configure MSTP domain name.

To display the "Instance configuration" page, click Spanning-tree configuration ->Spanning-tree field configuration->Field name configuration, click "Apply" to configure.

Field name configuration	
Field name	<input type="text"/>
Operation	Configuration ▾
Apply	

Field name	
Field name	name

<b>entry</b>	describe
<b>Field name</b>	MSTP domain name, the length is 1-32 characters
<b>Operation</b>	Configuration: Use the above configuration Default: Default does not match domain name

### 22.1.3. Revision-level configuration

This page can be used to configure MSTP revision level.

To display the "Instance configuration" page, click Spanning-tree configuration ->Spanning-tree field configuration->Revision-level configuration, click "Apply" to configure.

Revision-level configuration	
Revision-level	<input type="text"/>
Operation	Default ▾
Apply	

<b>entry</b>	<b>describe</b>
<b>Revision-level</b>	Range: 0-65535
<b>Operation</b>	Configuration: Use the above configuration Default: Restore default configuration 0

**22 Spanning-tree configuration**

Revision-level	
Revision-level	0

entry	describe
Revision-level	MSTP revision level with configuration, size range: 0-65535

**22.2. Spanning-tree Port configuration**

**22.2.1. PortFast configuration**

This page can be used for the configuration of edge ports.

To display the "PortFast configuration" page, click Spanning-tree configuration

->Spanning-tree Port configuration->PortFast configuration, click "Apply" to configure.

PortFast configuration	
Port	Ethernet1/0/1 <input type="button" value="v"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
Port	Ethernet port name
Operation	Add: Configure the above port type to an edge port Remove: Configure the above port type to be a non-edge port

PortFast configuration	
Port	PortType(1/0)
Ethernet1/0/1	0
Ethernet1/0/2	0
Ethernet1/0/3	0
Ethernet1/0/4	0
Ethernet1/0/5	0
Ethernet1/0/6	0
Ethernet1/0/7	0
Ethernet1/0/8	0

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>PortType(1/0)</b>	1: Represents an edge port 0: Represents a non-edge port

### 22.2.2. Port priority configuration

This page can be used for configuration of instance port priority. To display the "PortFast configuration" page, click Spanning-tree configuration ->Spanning-tree Port configuration->Port priority configuration, click "Apply" to configure.

Port priority configuration	
Port	Ethernet1/0/1 <input type="button" value="v"/>
Instance name	<input type="text"/>
Priority	<input type="text"/>
Operation	Default <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>Instance name</b>	Generate tree instance name
<b>Priority</b>	The size range is: 0-240, multiple of 16
<b>Operation</b>	Configuration: Apply the above configuration Default: Restore default priority 32768

Port priority configuration	
Ethernet1/0/1 of Instance 0	Operation port path cost 20000, Port priority 32, Port Identifier 032.001

### 22.2.3. Port cost configuration

This page can be used to configure port path costs.

To display the "Port cost configuration" page, click Spanning-tree configuration ->Spanning-tree Port configuration->Port cost configuration, click "Apply" to configure.

**22 Spanning-tree configuration**

Port cost configuration	
Port	Ethernet1/0/1 ▾
Instance name	
Cost	
Operation	Default ▾
Apply	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>Instance name</b>	Generate tree instance name
<b>Cost</b>	Size range: 0-200000000
<b>Operation</b>	Configuration: Apply the above configuration Default: Recovery port default path cost

**22.2.4. Spanning-tree port mode**

This page can be used to configure the spanning tree running mode where the port is located.

To display the "Spanning-tree port mode" page, click Spanning-tree configuration ->Spanning-tree Port configuration->Spanning-tree port mode, click "Apply" to configure.

Spanning-tree port mode	
Port	Ethernet1/0/1 ▾
Apply	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name

**22.2.5. Link-type configuration**

This page can be used to configure port link types.

To display the "Link-type configuration" page, click Spanning-tree configuration ->Spanning-tree Port configuration->Link-type configuration, click "Apply" to configure.

Link-type configuration	
Port	Ethernet1/0/1 ▾
Link type	auto ▾
Operation	Default ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>Link type</b>	Auto: Automatic consultations Force-true: Point-to-point type Force-false: Non-point-to-point type
<b>Operation</b>	Configuration: Apply the above configuration Default: Auto is the default link type for the recovery port

Link-type configuration	
Port	Link type
Ethernet1/0/1	auto
Ethernet1/0/2	auto
Ethernet1/0/3	auto
Ethernet1/0/4	auto
Ethernet1/0/5	auto
Ethernet1/0/6	auto
Ethernet1/0/7	auto
Ethernet1/0/8	auto

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>Link type</b>	Auto: Automatic consultations Force-true: Point-to-point type Force-false: Non-point-to-point type

## 22 Spanning-tree configuration

### 22.2.6. Spanning-tree agreement port configuration

This page can be used to configure enable or disable the tree generation function under the port.

To display the "Spanning-tree agreement port configuration" page, click Spanning-tree configuration->Spanning-tree Port configuration -> Spanning-tree agreement port configuration, click "Apply" to configure.

Spanning-tree agreement port configuration	
Port	Ethernet1/0/1 ▾
Operation	Disable ▾
<input type="button" value="Apply"/>	

entry	describe
Port	Ethernet port name
Operation	Enable: Port enable spanning tree function Disable: Port disables spanning tree functionality

### 22.3. Spanning-tree global configuration

#### 22.3.1. Spanning-tree global agreement port configuration

This page uses the build tree function with global enable.

To display the "Spanning-tree global agreement port configuration" page, click Spanning-tree configuration -> Spanning-tree global configuration->Spanning-tree global agreement port configuration, click "Apply" to configure.

Spanning-tree global agreement port configuration	
Operation	Disable ▾
<input type="button" value="Apply"/>	

entry	describe
Operation	Enable: enable spanning tree function Disable: disables spanning tree functionality

### 22.3.2. Forward-time configuration

This page can be used to configure forwarding delay time.

To display the "Forward-time configuration" page, click Spanning-tree configuration -> Spanning-tree global configuration ->Forward-time configuration, click "Apply" to configure.

Forward-time configuration	
Forward-time	<input type="text"/>
Operation	Default <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
<b>Forward-time</b>	Size range :4-30, in seconds, the following conditions shall be met: $2 * (\text{Bridge\_Forward\_Delay} - 1.0 \text{ seconds}) \geq \text{Bridge\_Max\_Age}$ $\text{Bridge\_Max\_Age} \geq 2 * (\text{Bridge\_Hello\_Time} + 1.0 \text{ seconds})$
<b>Operation</b>	Configuration: Configure the above settings Default: Restore default 15s

Forward-time configuration	
Forward-time configuration	15

entry	describe
<b>Forward-time configuration</b>	Configuration of current forwarding delay time

### 22.3.3. Hello-time configuration

This page can be used to bpdv the configuration of the sending interval.

To display the "Hello-time configuration" page, click Spanning-tree configuration -> Spanning-tree global configuration->Hello-time configuration, click "Apply" to configure.

**22 Spanning-tree configuration**

Hello-time configuration	
Bridge hello time	<input type="text"/>
Operation	Default <input type="button" value="v"/>
<input type="button" value="Apply"/>	

entry	describe
<b>Bridge hello time</b>	Size range: 1-10, in seconds, the following conditions shall be met: $2 * (\text{Bridge\_Forward\_Delay} - 1.0 \text{ seconds}) \geq \text{Bridge\_Max\_Age}$ $\text{Bridge\_Max\_Age} \geq 2 * (\text{Bridge\_Hello\_Time} + 1.0 \text{ seconds})$
<b>Operation</b>	Configuration: Configure the above settings Default: Restore default 2s

Hello-time configuration	
Bridge hello time	<input type="text" value="2"/>

entry	describe
<b>Bridge hello time</b>	Current HELLO Maximum Survival Time Configuration

**22.3.4. Max age time configuration**

This page can be used to configure the maximum aging time of BPDU messages. To display the "Max age time configuration" page, click Spanning-tree configuration -> Spanning-tree global configuration-> Max age time configuration, click "Apply" to configure.

Max age time configuration	
Max age time	<input type="text"/>
Operation	Default <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Max age time</b>	Size range :6-40, in seconds, the following conditions shall be met: $2 * (\text{Bridge\_Forward\_Delay} - 1.0 \text{ seconds}) \geq \text{Bridge\_Max\_Age}$ $\text{Bridge\_Max\_Age} \geq 2 * (\text{Bridge\_Hello\_Time} + 1.0 \text{ seconds})$
<b>Operation</b>	Configuration: Configure the above settings Default: Restore default 20s

Max age time configuration	
Max age time	20

<b>entry</b>	describe
<b>Max age time</b>	Configuration of current maximum ageing time

### 22.3.5. Max hop time configuration

This page can be used to BPDUs the maximum number of hops that packets are forwarded in the spanning tree domain.

To display the "Max hop time configuration" page, click Spanning-tree configuration -> Spanning-tree global configuration-> Max hop time configuration, click "Apply" to configure.

Max hop time configuration	
Max hop time	
Operation	Default <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Max hop time</b>	Numerical range: 1-40
<b>Operation</b>	Configuration: Configure the above settings Default: Restore default 20s

**22 Spanning-tree configuration**

Max hop time configuration	
Max hop time	20

<b>entry</b>	describe
<b>Max hop time</b>	Maximum number of hops currently configured

**22.3.6. Spanning tree mode configuration**

This page is used to set the running mode of the switch spanning tree. To display the “Spanning tree mode configuration” page, click Spanning-tree configuration -> Spanning-tree global configuration-> Spanning tree mode configuration, click "Apply" to configure.

Spanning tree mode configuration	
Mode	Mstp ▾
Operation	Default ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Mode</b>	Generating tree protocol type: Mstp.Stp.Rstp
<b>Operation</b>	Configuration: Configure the above settings Default: Restore default configuration mode to mstp

Spanning tree mode configuration	
Mode	mstp

<b>entry</b>	describe
<b>Mode</b>	Current run spanning tree protocol type

**22.3.7. Spanning tree cost-format configuration**

This page is used to set the global configuration path cost format. To display the “Spanning tree cost-format configuration” page, click Spanning-tree configuration -> Spanning-tree global configuration -> Spanning tree cost-format configuration, click "Apply" to configure.

Spanning tree cost-format configuration	
Mode	dot1t ▾
Apply	

<b>entry</b>	describe
<b>Mode</b>	Path cost format: Dot1t.Dot1d

### 22.3.8. Priority configuration

This page is used to set the bridge priority of the spanning tree instance.

To display the "Priority configuration" page, click Spanning-tree configuration -> Spanning-tree global configuration -> Priority configuration, click "Apply" to configure.

Priority configuration	
Instance name	<input type="text"/>
Priority	<input type="text"/>
Operation	Default ▾
Apply	

<b>entry</b>	describe
<b>Instance name</b>	Generate tree instance name
<b>Priority</b>	Numerical range: 0-61440, and an integer multiple of 4096
<b>Operation</b>	Configuration: Configure the above settings Default: Restore default configuration priority 32768

## 22.4. Show spanning-tree

### 22.4.1. Instance information

This page can be used to view information for the specified instance.

To display the "Instance information" page, click Spanning-tree configuration -> Show spanning-tree -> Instance information, click "Apply" to view.

## 22 Spanning-tree configuration

Instance information	
Instance name	<input type="text"/>
<input type="button" value="Apply"/>	

entry	describe
Instance name	Generate tree instance name

```

Information feedback window
Switch# show spanning-tree mst 0 detail
***** Process 0 *****
##### Instance 0 #####
vlans mapped: 1-4094
Root Id      : this switch
Root Times   : Max Age 20, Hello Time 2, Forward Delay 15, Max hops 20
Port 14 (Ethernet1/0/14) of Instance 0 is DSGN forwarding
Port info:   port id 128.14  priority 128  cost 0
Designated root has priority 32768, address 001f.ce10.b01b
Designated bridge has priority 32768, address 001f.ce10.b01b
BPDU: sent   2348(TCN 0, CONFIG 0, MST 2348)
          received 0(TCN 0, CONFIG 0, MST 0)

```

### 22.4.2. Revision-Level information

This page can be used to view configuration information for the spanning tree domain. To display the "Revision-Level information" page, click Spanning-tree configuration -> Show spanning-tree -> Revision-Level information, click "Apply" to view.

```

Information feedback window
Switch# show spanning-tree mst config
Name          name
Revision      0
Instance      Vlans Mapped
-----
00            1-4094
-----

```

## 23. MRPP configuration

### 23.1. MRPP global configuration

#### 23.1.1. MRPP global switch configuration

This page is used to enable or disable MRPP protocols.

To display the “MRPP global switch configuration” page, click MRPP configuration->MRPP global configuration->MRPP global switch configuration, click "Apply" to configure.

MRPP global switch configuration	
Operation	Disable ▾
Apply	

entry	describe
Operation	Enable: Enable MRPP protocol functionality Disable: Close MRPP Protocol Function

MRPP global switch configuration	
MRPP global configuration	disable

entry	describe
MRPP global configuration	disable: Current mrpp protocol status is closed enable: Current mrpp protocol status opens

#### 23.1.2. MRPP poll time configuration

This page can be used to configure MRPP query time.

To display the “MRPP poll time configuration” page, click MRPP configuration->MRPP global configuration->MRPP poll time configuration, click "Apply" to configure.

**23 MRPP configuration**

MRPP poll time configuration	
MRPP poll time	<input type="text"/>
Operation	Default <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>MRPP poll time</b>	Range: 20-200, unit milliseconds
<b>Operation</b>	Configuration: Apply the above settings Default: Restore default ms 100

MRPP poll time configuration	
MRPP poll time	100

<b>entry</b>	describe
<b>MRPP poll time</b>	Current configured query time

**23.1.3. MRPP domain id configuration**

This page is used to set the ID number of the MRPP domain.  
 To display the "MRPP domain id configuration" page, click MRPP configuration->MRPP global configuration->MRPP domain id configuration, click "Apply" to configure.

MRPP domain id configuration	
MRPP domain	<input type="text"/>
Operation	Remove <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>MRPP domain</b>	ID range: 1-4096
<b>Operation</b>	Configuration: Apply the above settings Remove: Delete configured domain ID

MRPP domain id configuration	
Index	Domain ID

<b>entry</b>	describe
<b>Domain ID</b>	Domain ID range: 1-4096

## 23.2. MRPP port configuration

### 23.2.1. MRPP port property configuration

This page can be used to configure the primary and secondary ports of the MRPP ring.

To display the "MRPP port property configuration" page, click MRPP configuration->MRPP port configuration->MRPP port property configuration, click "Apply" to configure.

MRPP port property configuration	
Port	Ethernet1/0/1 <input type="button" value="v"/>
MRPP domain	<input type="text"/>
MRPP port property	primary <input type="button" value="v"/>
Operation	Remove <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>MRPP domain</b>	MRPP domain ID, range: 1-4096
<b>MRPP port property</b>	Primary: Main port Secondary: Secondary port
<b>Operation</b>	Configuration: Apply the above configuration Remove: Delete the above configuration

MRPP port property configuration			
Index	Domain ID	Port Name	Property

<b>entry</b>	describe
<b>Domain ID</b>	MRPP domain ID, range: 1-4096

## 23 MRPP configuration

<b>Port Name</b>	Ethernet port
<b>Property</b>	Primary: Main port Secondary: Secondary port

### 23.3. MRPP domain configuration

#### 23.3.1. MRPP control vlan config

This page can be used to configure control VLAN for MRPP rings  
To display the "MRPP control vlan configuration" page, click MRPP configuration->MRPP domain configuration->MRPP control vlan configuration, click "Apply" to configure.

MRPP control vlan config	
MRPP domain	▼
VLAN ID	
Operation	Remove ▼
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>MRPP domain</b>	MRPP domain ID, range created: 1-4096
<b>VLAN ID</b>	VLAN ID, range: 1-4094
<b>Operation</b>	Configuration: Apply the above configuration Remove: Delete the above configuration

MRPP control vlan config		
Index	Domain ID	Control-VLAN

<b>entry</b>	describe
<b>Domain ID</b>	MRPP domain ID, range: 1-4096
<b>Control-VLAN</b>	Scope of control VLAN, for current MRPP domain configuration: 1-4094

### 23.3.2. MRPP node mode config

This page can be used to configure MRPP nodes.

To display the "MRPP node mode configuration" page, click MRPP configuration->MRPP domain configuration->MRPP node mode configuration, click "Apply" to configure.

MRPP node mode config	
MRPP domain	▼
MRPP node mode	master ▼
Apply	

<b>entry</b>	describe
<b>MRPP domain</b>	MRPP domain ID, range: 1-4096
<b>MRPP node mode</b>	master: Master node transit: Transmission node

MRPP node mode config		
Index	Domain ID	Node mode

<b>entry</b>	describe
<b>Domain ID</b>	MRPP domain ID, range: 1-4096
<b>Node mode</b>	master: Master node transit: Transmission node

### 23.3.3. MRPP hello timer config

This page can be used to MRPP Hello the configuration of message sending intervals.

To display the "MRPP hello timer configuration" page, click MRPP configuration->MRPP domain configuration->MRPP hello timer configuration, click "Apply" to configure.

MRPP hello timer config	
MRPP domain	▼
MRPP hello timer range	
Operation	Remove ▼
Apply	

<b>entry</b>	describe
--------------	----------

**23 MRPP configuration**

<b>MRPP domain</b>	MRPP domain ID, range: 1-4096
<b>MRPP hello timer range</b>	Interval time range: 1-100 seconds
<b>Operation</b>	Configuration: Apply the above configuration Remove: Delete the above configuration and restore the default configuration to 1 second

MRPP hello timer config		
Index	Domain ID	Hello-Timer

<b>entry</b>	describe
<b>Domain ID</b>	MRPP domain ID, range: 1-4096
<b>Hello-Timer</b>	Hello message sending interval when the current configuration takes effect

**23.3.4. MRPP fail timer config**

This page is used MRPP configure the health message receive timeout. To display the "MRPP fail timer configuration" page, click MRPP configuration->MRPP domain configuration->MRPP fail timer configuration, click "Apply" to configure.

MRPP fail timer config	
MRPP domain	<input type="text" value="v"/>
MRPP fail timer range	<input type="text"/>
Operation	Remove <input type="text" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>MRPP domain</b>	MRPP domain ID, range: 1-4096
<b>MRPP fail timer range</b>	Interval time range: 1-300 seconds
<b>Operation</b>	Configuration: Apply the above configuration Remove: Delete the above configuration and restore the default configuration to 3 seconds

MRPP fail timer config		
Index	Domain ID	FAIL-Timer

<b>entry</b>	describe
<b>Domain ID</b>	MRPP domain ID, range: 1-4096
<b>FAIL-Timer</b>	Receive timeout when the current configuration takes effect

### 23.3.5. MRPP domain switch config

This page can be used to enable or disable MRPP rings.

To display the “MRPP domain switch config” page, click MRPP configuration->MRPP domain configuration->MRPP domain switch config, click "Apply" to configure.

MRPP domain switch config	
MRPP domain	▼
Operation	Disable ▼
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>MRPP domain</b>	MRPP domain ID, range: 1-4096
<b>Operation</b>	Enable: Enable the corresponding MRPP ring Disable: Disable the corresponding MRPP ring

MRPP domain switch configuration		
Index	Domain ID	Flag

<b>entry</b>	describe
<b>Domain ID</b>	MRPP domain ID, range: 1-4096
<b>Flag</b>	The enable state disable or enable of the currently configured active MRPP domain

## 23.4. MRPP configuration display

### 23.4.1. MRPP display

This page can be used to view configuration information for MRPP domains. To display the “MRPP display” page, click MRPP configuration->MRPP domain configuration->MRPP display, click "Apply" to view.

MRPP display	
MRPP domain	all ▾
Apply	

---

Information feedback window
Switch# show mrpp
Poll time : 100 (ms)

<b>entry</b>	describe
<b>Domain ID</b>	MRPP domain ID, range: 1-4096

### 23.4.2. MRPP statistics display

This page can be used to view statistics of MRPP domain data and status changes. To display the “MRPP statistics display” page, click MRPP configuration->MRPP domain configuration->MRPP statistics display, click "Apply" to view.

MRPP statistics display	
MRPP domain	all ▾
Apply	

---

Information feedback window
Switch# show mrpp statistics
Poll time : 100 (ms)

entry	describe
Domain ID	MRPP domain ID, range: 1-4096

### 23.4.3. Clear MRPP statistics

This page can be used to clear statistics for MRPP domains.

To display the "Clear MRPP statistics" page, click MRPP configuration->MRPP domain configuration->Clear MRPP statistics, click "Apply" to configure.

Clear MRPP statistics	
MRPP domain	all ▾
<input type="button" value="Apply"/>	

## 24. ULPP configuration

### 24.1. ULPP global configuration

#### 24.1.1. ULPP group configuration

This page can be used to add or delete ULPP groups.

To display the “ULPP group configuration” page, ULPP configuration ->ULPP global configuration->ULPP group configuration, click "Apply" to configure.

ULPP group configuration	
ULPP group	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>ULPP group</b>	Group ID size range: 1-48
<b>Operation</b>	Add: Add ULPP groups Remove: Delete ULPP groups

ULPP group configuration	
ULPP group	<b>1</b>

<b>entry</b>	describe
<b>ULPP group</b>	ULPP groups created

### 24.2. ULPP port configuration

#### 24.2.1. ULPP port property configuration

This page can be used to set the port as the master-slave port of the ULPP group. It can also enable or disable receiving MAC address and ARP update packets, can also configure a control VLAN for the port.

To display the “ULPP port prperty configuration” page, ULPP configuration ->ULPP port configuration->ULPP port prperty configuration, click "Apply" to configure.

ULPP port property configuration	
Port	Ethernet1/0/1 ▾
ULPP port flush mode	mac ▾ <input type="checkbox"/>
ULPP port control vlan	<input type="text"/> <input type="checkbox"/>
ULPP group	1 ▾
ULPP port mode	master ▾ <input type="checkbox"/>
Operation	Remove ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Port</b>	Ethernet port name
<b>ULPP port flush mode</b>	mac: Receive mac update packets arp: Receive arp more packets
<b>ULPP port control vlan</b>	vlan created
<b>ULPP group</b>	ULPP groups created
<b>ULPP port mode</b>	master: Main port slave: Slave port
<b>Operation</b>	Configuration: Apply the above configuration Remove: Delete the above configuration

## 24.3. ULPP group configuration

### 24.3.1. ULPP group description configuration

This page can be used to configure the description name for ULPP group.

To display the "ULPP group description configuration" page, ULPP configuration

->ULPP group configuration->ULPP group description configuration, click "Apply" to configure.

ULPP group description configuration	
ULPP group	1 ▾
ULPP group description	
Operation	Remove ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>ULPP group</b>	ULPP groups created
<b>ULPP group description</b>	1-128 characters in length
<b>Operation</b>	Configuration: Apply the above configuration Remove: Delete the above configuration

ULPP group description configuration	
ULPP group	ULPP group description
1	

<b>entry</b>	describe
<b>ULPP group</b>	ULPP groups created
<b>ULPP group description</b>	Description of ULPP groups currently set

### 24.3.2. ULPP group property configuration

This page can be used to configure the ULPP group properties of preemption mode, preemption delay, protection VLAN, control VLAN, flush mode, etc.

To display the "ULPP group description configuration" page, ULPP configuration ->ULPP group configuration->ULPP group property configuration, click "Apply" to configure.

ULPP group property configuration		
ULPP group	1 ▾	
ULPP group preemption mode	on ▾	<input type="checkbox"/>
ULPP group preemption delay		<input type="checkbox"/>
ULPP group control vlan		<input type="checkbox"/>
ULPP group protect vlan		<input type="checkbox"/>
ULPP group flush mode	mac ▾	<input type="checkbox"/>
Operation	Remove ▾	
		<input type="button" value="Apply"/>

entry	describe
<b>ULPP group</b>	ULPP groups created
<b>ULPP group preemption mode</b>	on: Preemptive mode enabled off: Disable Preemptive Mode
<b>ULPP group preemption delay</b>	Delay time range: 1-600, per second
<b>ULPP group control vlan</b>	Created VLAN, VLAN ID between 1-4094
<b>ULPP group protect vlan</b>	MSTP instance list, value range: 1-4094
<b>ULPP group flush mode</b>	mac: Send mac update packet arp: Send arp update packet
<b>Operation</b>	Configuration: Apply the above configuration Remove: Delete the above configuration

ULPP group property configuration				
ULPP group	ULPP group preemption mode	ULPP group preemption delay	ULPP group control vlan	ULPP group flush mode
1	OFF	30	1	ALL

entry	describe
<b>ULPP group</b>	ULPP group created
<b>ULPP group preemption mode</b>	on: Preemptive mode enabled off: Disable Preemptive Mode
<b>ULPP group preemption delay</b>	Delay time for current configuration
<b>ULPP group control vlan</b>	ULPP group control VLAN currently set

<b>ULPP group flush mode</b>	mac: Send mac update packet arp: Send arp update packet ALL: Send mac and arp update packet
------------------------------	---

**24.4. ULPP configuration display**

**24.4.1. ULPP group configuration display**

This page can be used to view configuration information for ULPP groups. To display the “ULPP group description configuration” page, ULPP configuration ->ULPP configuration display->ULPP group configuration display, click "Apply" to view.

**ULPP group configuration display**

ULPP group  Apply

```

Information feedback window
Switch# show ulpp group
ULPP group 1 information:
Description:
Preemption mode: OFF
Preemption delay: 30s
Control VLAN: 1
Flush packet: MAC ARP
Protected VLAN: Reference Instance
Member          Role          State          Track-cfm-level
-----
  
```

**24.4.2. ULPP port statistics display**

This page can be used to view ULPP port statistics. To display the “ULPP group description configuration” page, ULPP configuration ->ULPP configuration display->ULPP port statistics display, click "Apply" to view.

**ULPP port statistics display**

Port  Apply

**24.4.3. ULPP port property display**

This page can be used to view ULPP port configuration information. To display the “ULPP group description configuration” page, ULPP configuration ->ULPP configuration display->ULPP port property display, click "Apply" to view.

```
Information feedback window
Switch# show ulpp flush-receive-port
ULPP flush-receive portlist:
Portname          Type          Control Vlan
-----
-----
```

## 24 ULPP configuration

### 24.4.4. ULPP port statistics clear

This page can be used to clear statistics of ULPP related data on the port.

To display the “ULPP group description configuration” page, ULPP configuration ->ULPP configuration display->ULPP port statistics clear, click "Apply" to view.

ULPP port statistics clear	
Port	Ethernet1/0/1 ▾
<input type="button" value="Apply"/>	

## 25. ULSM configuration

### 25.1. ULSM global configuration

#### 25.1.1. ULSM group configuration

This page can be used to create or delete ULSM groups.

To display the “ULSM group configuration” page, click ULSM configuration ->ULSM global configuration->ULSM group configuration, click "Apply" to configure.

ULSM group configuration	
ULSM group	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>ULSM group</b>	Group ID range: 1-32
<b>Operation</b>	Add: Create a ULSM group Remove: Removing ULSM groups of corresponding ID

ULSM group configuration	
ULSM group	<b>1</b>

<b>entry</b>	describe
<b>ULSM group</b>	ULSM groups created

### 25.2. ULSM port configuration

#### 25.2.1. ULSM port property configuration

This page can be used to add uplink or downlink ports for ULSM groups that have been created.

To display the “ULSM group configuration” page, click ULSM configuration ->ULSM port configuration->ULSM port property configuration, click "Apply" to configure.

ULSM port property configuration	
Port	Ethernet1/0/1 ▾
ULSM group	1 ▾
ULSM port property	downlink ▾
Operation	Remove ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>ULSM group</b>	ULSM groups created
<b>ULSM port property</b>	uplink: Uplink port downlink: Downlink port
<b>Operation</b>	Configuration: Apply the above settings Remove: Delete the above

ULSM port property		
Port	ULSM group	ULSM port property
Ethernet1/0/1	1	uplink

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>ULSM group</b>	ULSM groups created
<b>ULSM port property</b>	Current ULSM groups correspond to configured upper and lower ports uplink: Uplink port downlink: Downlink port

## 25.3. ULSM configuration display

### 25.3.1. ULSM display

This page can be used to view the current status of the ULSM group and the status of the upper and lower ports within the group.

To display the “ULSM group configuration” page, click ULSM configuration ->ULSM port configuration->ULSM port property configuration, click "Apply" to view.

**ULSM display**

ULSM group

all ▾

```

Information feedback window
Switch# show ulsm group
ULSM group 1 state: Down
-----
      Port           Role           State           ShutDown-by-ULSM
-----
      Ethernet1/0/1   UpLink        Down
  
```

## 26. Authentication configuration

### 26.1. RADIUS client configuration

#### 26.1.1. RADIUS global configuration

RADIUS global configuration module, users in this module can configure the global RADIUS function services.

RADIUS configuration	
Authentication status	Disable ▾
Accounting	Disable ▾
Radius key operation	▾
RADIUS key	<input type="text"/>
System recovery time	5 <input type="text"/>
RADIUS Retransmit times	3 <input type="text"/>
RADIUS server timeout	3 <input type="text"/>
<input type="button" value="Apply"/>	

AAA server status	
the status of the aaa	disable
the status of the radius accounting	disable
radius-server timeout	3
radius-server retransmit	3
radius-server dead-time	5
radius-server authentication host	192.168.2.200 port:23 primary

<b>Authentication status</b>	Enable	Enable RADIUS certification services
	Disable	Disabling RADIUS certification services
<b>Accounting</b>	Enable	Enable RADIUS billing services
	Disable	Disabling RADIUS billing services
<b>Radius key operation</b>	Add	Add RADIUS key
	Remove	Delete RADIUS key
<b>RADIUS key</b>	Key string, 1-64 characters	
<b>System recovery time</b>	Radius service recovery time from downtime to accessibility, 1-255 minutes	
<b>RADIUS Retransmit times</b>	Radius authentication packet retransmission time, 1-100 seconds	
<b>RADIUS server timeout</b>	The corresponding time of the radius server, 1-100 seconds	

#### 26.1.2. RADIUS authentication configuration

RADIUS authentication configuration module, users in this module can configure the RADIUS authentication server.

RADIUS authentication server configuration	
Authentication server IP	<input type="text"/>
Authentication server port(optional)	<input type="text"/>
Primary authentication server	Primary authentication server ▾
Operation	Add ▾
<input type="button" value="Apply"/>	

RADIUS server configuration list		
Server IP	Port num	Primary server

<b>Authentication server IP</b>	The address of IPv4 or IPv6 of the radius authentication server	
<b>Authentication server port</b>	Port number of radius authentication server (optional), 0-65535	
<b>Primary authentication server</b>	Primary authentication server	Specify radius server as primary authentication server
	Non-Primary authentication server	Specify radius server as non-primary authentication server
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 26.1.3. RADIUS accounting configuration

Radius authentication and accounting module, users in this module can configure the RADIUS billing server.

RADIUS accounting server configuration	
Accounting server IP	<input type="text"/>
Accounting server port(optional)	<input type="text"/>
Primary accounting server	Primary accounting server ▾
Operation	Add ▾
<input type="button" value="Apply"/>	

RADIUS accounting server configuration list		
Server IP	Port num	Primary server

<b>Accounting server IP</b>	Radius authentication server IPv4 or IPv6 address
<b>Accounting server port</b>	Radius authentication server port number (optional), 0-65535

## 26 Authentication configuration

<b>Primary accounting server</b>	Primary accounting server	Specify radius server as primary accounting server
	Non-Primary accounting server	Specify radius server as non-primary accounting server
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

## 26.2. TACACS server configuration

### 26.2.1. TACACS global configuration

TACACS global configuration module, users in this module can configure the global TACACS function services.

TACACS configuration	
TACACS key	<input type="text"/>
TACACS server timeout	3
Operation	Remove <input type="button" value="v"/>
<input type="button" value="Apply"/>	

TACACS server status	
the status of the tacacs	
tacacs-server timeout	3

<b>TACACS key</b>	TACACS authentication key, 1-16 characters	
<b>TACACS server timeout</b>	TACACS authentication timeout, 1-60 seconds, default 3 seconds	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 26.2.2. TACACS server host configuration

TACACS server configuration module, users in this module can configure the TACACS authentication server.

TACACS server configuration	
Authentication server IP	<input type="text"/>
Authentication server port(optional)	<input type="text"/>
Primary authentication server	Primary authentication server <input type="button" value="v"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

<b>Authentication server IP</b>	TACACS authentication server IPv4 address, decimal point	
<b>Authentication server port</b>	TACACS authentication server port number (optional), 0-65535	
<b>Primary authentication server</b>	Primary accounting server	Specify TACACS server as primary accounting server
	Non-Primary accounting server	Specify TACACS server as non-primary accounting server
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

## 26.3. 802.1x configuration

### 26.3.1. 802.1x Global configuration

802.1 x Global Configuration Module, users in this module can configure the global 802.1 x function services.

802.1x configuration	
802.1x status	Disable ▾
Maximum retransmission times of EAP-request/identity	2
Reauthenticate client periodically	Disable ▾
Holddown time for authentication failure	10
Reauthenticate client interval	3600
Resending EAP-request/identity interval	30
EAP relay authentication mode	forbid ▾
Private client	forbid ▾
MAC filtering	forbid ▾
802.1x unicast	Disable ▾
Apply	

<b>802.1x status</b>	Boot or turn off 802.1 x function
<b>Maximum retransmission times of EAP-request/identity</b>	Scope 1-10
<b>Reauthenticate client periodically</b>	Start or close periodic recertification
<b>Holddown time for authentication failure</b>	Range 1-65535 seconds, default 10 seconds
<b>Reauthenticate client interval</b>	Range 1-65535 seconds, default 3600 seconds

## 26 Authentication configuration

<b>Resending EAP-request/identity interval</b>	Range 1-65535 seconds, default 30 seconds
<b>EAP relay authentication mode</b>	Ban or permit EAP relay authentication
<b>Private client</b>	Prohibit or allow private clients
<b>MAC filtering</b>	Ban or permit MAC address filtering
<b>802.1x unicast</b>	Disable or enable 802.1 x unicast teleport function

### 26.3.2. 802.1x port authentication configuration

802.1 x port authentication configuration module. In this module, users can configure the 802.1x function of the specified port

802.1x port configuration	
Port	Ethernet1/0/1 ▾
802.1x status	Disable ▾
Authentication type	force-unauthorized ▾
Authentication mode	Port-based ▾
Port maximum user	1
Guest VLAN ID	0
<input type="button" value="Apply"/>	

<b>Port</b>	Designated port number	
<b>802.1x status</b>	Boot or close 802.1 x on this port	
<b>Authentication type</b>	force-unauthorized	Mandatory Unauthorized
	force-authorized	Mandatory authorization
	Auto (802.1x)	automatism (802.1x authorization)
<b>Authentication mode</b>	Port-based	Based on port
	Mac-based	Based on MAC
<b>Port maximum user</b>	Maximum number of users allowed to connect to ports, 1-256, default 1	
<b>Guest VLAN ID</b>	Guest VLAN, 0-4094, default 0	

### 26.3.3. 802.1x port MAC configuration

802.1x port MAC configuration module, users in this module can add or delete port 802.1 x functions MAC specified ports.

802.1x port MAC configuration	
Port	Ethernet1/0/1 ▾
Mac	<input type="text"/>
Operation	Add MAC filter entry ▾
<input type="button" value="Apply"/>	

<b>Port</b>	Specifies the port number
<b>MAC</b>	MAC address to operate
<b>Operation</b>	Add or delete port MAC address filter table items

### 26.3.4. 802.1x port status list

802.1x port MAC status list, the user can view 802.1 status information on x specified port and authenticate 802.1 x in this module.

802.1x port status list	
Port	Ethernet1/0/1 ▾
802.1x status	Disable
Authentication type	NULL
Authentication status	Unauthenticated
Authentication mode	No authentication mode
<input type="button" value="Reauthenticate"/>	

## 26.4. MAB configuration

### 26.4.1. MAB ENABLE configuration

MAB enable configuration module, users in this module can MAB the function of global enable and specified port enable operation.

MAB global enable configuration	
MAB global enable	Enable ▾
<input type="button" value="Apply"/>	

MAB port enable configuration	
Port	Ethernet1/0/1 ▾
MAB port enable	Enable ▾
<input type="button" value="Apply"/>	

<b>MAB global enable</b>	Global enable or disable MAB function
<b>Port</b>	Specifies the port number
<b>MAB port enable</b>	Function on or off MAC specified port

## 26 Authentication configuration

### 26.4.2. MAB Authentication configuration

MAB user authentication configuration module, users in this module can configure the MAB user authentication mode.

MAB Authentication configuration	
MAB Authentication TYPE	MAC address <input type="button" value="v"/>
username	<input type="text"/>
password	<input type="text"/>
<input type="button" value="Apply"/>	

<b>MAB Authentication TYPE</b>	Mac address	Authentication based on MAC address
	Username and password	Authentication based on username and password (to be configured)
<b>username</b>	user name for authentication, 1-32 characters	
<b>password</b>	password for authentication, 1-32 characters	

### 26.4.3. MAB parameter configuration

MAB parameter configuration module, users in this module can configure the parameters of the MAB function.

MAB parameter configuration	
Port	Ethernet1/0/1 <input type="button" value="v"/>
parameter type	guest vlan range <input type="button" value="v"/>
value	<input type="text"/>
Enable <input type="button" value="v"/>	<input type="text"/>
<input type="button" value="Apply"/>	

<b>Port</b>	Specify port name	
<b>parameter type</b>	guest vlan range	VLAN operation for guest
	Max binding value	Operation of maximum binding on ports
<b>value</b>	After the parameter type is selected, the corresponding parameter value range can be set	
<b>Enable/Disable</b>	Boot or close port MAB parameter configuration	

MAB parameter configuration	
parameter type	reauth-period ▾
value	<input type="text"/>
Enable ▾	
<input type="button" value="Apply"/>	

<b>parameter type</b>	reauth period	MAB time interval for re-authentication after failed authentication
	Offline-detect	Detect the scan time of each port online status, 0 does not detect
	Quiet-period	Configure the silence time after mAb authentication failure
	Stale-period	Configure the time to delete bound users after the mAb port is closed
	Linkup-period	Configure the restart time range after mAb port shutdown
<b>value</b>	After the parameter type is selected, the corresponding parameter value can be set	
<b>Enable/Disable</b>	Boot or close global MAB parameter configuration	

authentication mab	
check type	radius ▾
Enable ▾	
<input type="button" value="Apply"/>	

<b>Check type</b>	MAC address authentication uses radius or none to verify user login
<b>Enable/Disable</b>	Start or close validation mode configuration

spoofing-garp-check	
spoofing-garp-check	Enable ▾
<input type="button" value="Apply"/>	

<b>spoofing-garp-check</b>	Activate or close check fake free ARP configuration
----------------------------	---

## 26 Authentication configuration

### 26.4.4. MAB show

MAB display module, users can display mAb status of specified port or all ports in this module

MAB show	
Port	all <input type="button" value="v"/>
<input type="button" value="Apply"/>	

Information feedback window			
Switch# show mac-authentication-bypass			
The Number of all binding is 0			
MAC	Interface	Vlan ID	State
-----			

<b>Port</b>	Displays information MAB the specified port or all ports
-------------	--

## 27. PoE Config

### 27.1. PoE Global Config

#### 27.1.1 PoE Global Config

This page can be used to globally configure POE properties and view POE global property information.

To display the "PoE Global Config" page, click PoE Config ->PoE Global Config->PoE Global Config, click "Apply" to configure.

PoE Global Config	
PoE Work Status	online
PoE Port Max Number	24
PoE Support Type	802.3at/802.3af
PoE MCU Software Version	V2.1
PoE Power Available(37-370 W)	370
PoE Power Used	0 W
PoE Power Remaining	370 W
PoE Main Voltage	54.4 V
PoE Min Voltage	44 V
PoE Max Voltage	57 V
PoE Police	Off ▾
PoE Legacy	Off ▾
PoE High-inrush Status	Enable ▾
PoE Monitor interval(30-36000 s)	150
PoE Reset Interval(1-600 s)	5
Apply	

entry	describe
<b>PoE Power Available</b>	Maximum power supported by current switches
<b>PoE Police</b>	Enable status of priority power supply policy: Off: disable On: enable
<b>PoE Legacy</b>	Current status of standard PD detection function: Off: disable On: enable
<b>PoE High-inrush Status</b>	Enable/Disable
<b>PoE Monitor interval</b>	Check whether the PD connected to the current port is in the detection interval of normal communication, range: 30-36000 seconds

PoE Reset Interval	Port reset time range: 1-600 per second
--------------------	---

## 27.2 PoE Port Config

### 27.2.1 PoE Port Config

This page can be used to configure POE properties under ports.

To display the "PoE Port Config" page, click PoE Config ->PoE Port Global Config->PoE Port Config, click "Apply" to configure.

PoE Port Config			
Interface	Status	Priority	PoE Monitor Status
Ethernet1/0/1 ▾	auto ▾	low ▾	off ▾
			Apply

<b>entry</b>	describe
<b>Interface</b>	Current configured Ethernet ports
<b>Status</b>	Auto: Normal power supply Static: Forced power supply Disable: No power supply
<b>Priority</b>	Low: low priority High: high priority Critical: highest priority
<b>PoE Monitor Status</b>	Off: Disable port monitoring ON: Enable port monitoring

Max Power	
Interface	Max Power(1-32000mW)
Ethernet1/0/1 ▾	32000 mW
Apply	

<b>entry</b>	describe
<b>Interface</b>	Current configured Ethernet ports
<b>Max Power</b>	Sets the maximum output power supported by the current port, size range: 1-32000, unit mW; For example: 100, 200, 3000

Time range name	
Interface	Time range name
Ethernet1/0/1 ▾	▾
Apply	

Time range name	
Interface	Time range name
Ethernet1/0/1 ▾	▾
Apply	

<b>entry</b>	describe
<b>Interface</b>	Current configured Ethernet ports
<b>Time range name</b>	The time range name defined by the switch

Unset Time range name	
Interface	Ethernet1/0/1 ▾
Default	

<b>entry</b>	describe
<b>Interface</b>	Current configured Ethernet ports

## 28. DOS attack protection configuration

### 28.1. Source IP equal destination IP DOS attack protection configuration

Source IP equal to destination IP anti DoS attack configuration module, the user can start or turn off the DOS attack function IP equal to the destination in this module.

Source IP equal destination IP DOS attack protection configuration	
DOS attack protection status	Disable ▾
Apply	

DOS attack protection status	
DOS attack protection status	Disable

Information feedback window
Switch# config t Switch(config)# no dosattack-check srcip-equal-dstip enable

### 28.2. Source port equal destination port DOS attack protection configuration

Source port equal to destination port anti DoS attack configuration module, users in this module can start or close the source port equal to the destination port DOS attack function.

Source port equal destination port DOS attack protection configuration	
DOS attack protection status	Disable ▾
Apply	

DOS attack protection status	
DOS attack protection status	Disable

Information feedback window
Switch# config t Switch(config)# no dosattack-check srcport-equal-dstport enable

### 28.3. TCP DOS attacks on invalid flags configuration

TCP DoS attack invalid flag bit configuration module, users in this module can start or close the DOS attack function to check unauthorized TCP tags.

TCP DOS attacks on invalid flags configuration	
DOS attack protection status	Disable ▾
Apply	
DOS attack protection status	
DOS attack protection status	Disable
Information feedback window	
Switch# config t	
Switch(config)# no dosattack-check tcp-flags enable	

### 28.4. ICMP DOS attack protection configuration

ICMP anti DoS attack configuration module, the user can start or turn off the DOS attack check function of the anti- ICMP fragment in this module.

ICMP DOS attack protection configuration	
DOS attack protection status	Enable ▾
Apply	
DOS attack protection status	
DOS attack protection status	Enable
Information feedback window	
Switch# config t	
Switch(config)# dosattack-check icmp-attacking enable	

### 28.5. ICMP packet-size configuration

The maximum ICMP message configuration module is allowed, users can configure the maximum net length of icmpv4 packets in this module.

## 28 DOS attack protection configuration

ICMP packet-size configuration	
Packet-size	<input type="text" value="64"/>
<input type="button" value="Apply"/>	

Packet-size	
Packet-size	64

Information feedback window	
Switch# config t	
Switch(config)# dosattack-check icmpV4-size 64	

<b>Packet-size</b>	Maximum net length of allowed ICMPv4 packets, 64-1023, Default 512
--------------------	--

### 28.6. First fragment IP packet DOS attack protection configuration

The first IP packet fragment anti DoS attack configuration module, the user can start or turn off the DOS attack function against the first IP message fragment in this module.

First fragment IP packet DOS attack protection configuration	
DOS attack protection status	<input type="button" value="Enable"/> ▾
<input type="button" value="Apply"/>	

DOS attack protection status	
DOS attack protection status	Enable

Information feedback window	
Switch# config t	
Switch(config)# dosattack-check ipv4-first-fragment enable	

## 29. SSL config

### 29.1. IP HTTP server configuration

HTTP server configuration module, the user can start or stop the HTTP service of the switch by using this module again.

IP HTTP server configuration	
IP HTTP server status	Enable ▾
Apply	

Information feedback window	
IP HTTP server status	Enable

```

Information feedback window
Switch# config t
Switch(config)# ip http server
web server has worked

```

### 29.2. SSL global configuration

SSL function switch configuration module, users in this module can start or close the switch SSL service function.

SSL global configuration	
SSL status	Enable ▾
Apply	

Information feedback window	
SSL status	Enable

```

Information feedback window
Switch# config t
Switch(config)# ip http secure-server
web server is on

```

### 29.3. SSL server monitor port configuration

SSL server monitor port number start configuration module, users can configure SSL server listening port number in this module.

SSL server monitor port configuration	
port number	<input type="text"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

Information feedback window	
port number	443

<b>Port</b>	Specifies the port number	
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

### 29.4. SSL secure-ciphersuite configuration

SSL encryption suite configuration module, users can configure the encryption suite type of SSL service in this module.

secure-ciphersuite configuration	
secure-ciphersuite type	aes256-sha <input type="button" value="v"/>
Operation	Add <input type="button" value="v"/>
<input type="button" value="Apply"/>	

Information feedback window	
ip http secure-ciphersuite aes256-sha	

<b>secure-ciphersuite type</b>	aes256-sha	aes256-sha encryption is used
	ecdhe-rsa-aes256-sha	ecdhe-rsa-aes256-sha encryption is used
<b>Operation</b>	Add	Add operations
	Remove	Delete operations

## 30. sFlow configuration

### 30.1. sFlow collector global address configuration

This page can be used to configure the global sFlow analyzer address. To display the “sFlow collector global address configuration” page, sFlow configuration->sFlow collector global address configuration, click "Apply" to configure.

sFlow collector global address configuration	
IP address	<input type="text"/>
destination port NO.	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
IP address	sFlow Analyzer Address
destination port NO.	Range between 1025 and 65535
Operation	Configuration: User self-configuration Default: Restore default configuration

### 30.2. sFlow collector port address configuration

This page can be used to configure port sFlow analyzer address. To display the “sFlow collector port address configuration” page, sFlow configuration->sFlow collector port address configuration, click "Apply" to configure.

sFlow collector port address configuration	
Port	Ethernet1/0/1 ▾
IP address	<input type="text"/>
destination port NO.	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
<b>Port</b>	Ethernet port number
<b>IP address</b>	sFlow Analyzer Address
<b>destination port NO.</b>	Range between 1025 and 65535
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration

### 30.3. sFlow agent address configuration

This page can be used for sFlow agent configuration.

To display the “sFlow agent address configuration” page, sFlow configuration->sFlow agent address configuration, click "Apply" to configure.

**sFlow agent address configuration**

<b>IP address</b>	<input style="width: 90%;" type="text"/>
<b>Operation</b>	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
<b>IP address</b>	sFlow agent address
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration

### 30.4. sFlow priority configuration

This command is used to set the priority of the sample message.

To display the “sFlow priority configuration” page, sFlow configuration->sFlow priority configuration, click "Apply" to configure.

sFlow priority configuration	
agent priority value	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>agent priority value</b>	Range: 0-3
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration

### 30.5. sFlow header length configuration

This page can be used to configure the length of header packets copied in sFlow data sampling.

To display the “sFlow header length configuration” page, sFlow configuration->sFlow header length configuration, click "Apply" to configure.

sFlow header length configuration	
Port	Ethernet1/0/1 ▾
header length	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>header length</b>	Length range: 32-256
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration

### 30.6. sFlow data length configuration

This page is used to configure sflow packet length.

To display the “sFlow header length configuration” page, sFlow configuration->sFlow data length configuration, click "Apply" to configure.

sFlow data length configuration	
Port	Ethernet1/0/1 ▾
data length	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

entry	describe
Port	Ethernet port name
data length	Length range :500-1470
Operation	Configuration: User self-configuration Default: restore default configuration, default value is 1400

### 30.7. sFlow rate configuration

This page can be used to configure port hardware sampling rates.

To display the “sFlow rate configuration” page, sFlow configuration->sFlow rate configuration, click "Apply" to configure.

sFlow rate configuration	
Port	Ethernet1/0/1 ▾
direction	input ▾
rate value	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>direction</b>	Input: receive data Output: send data
<b>rate value</b>	Rate range: 1000-16383500
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration

### 30.8. sFlow counter interval configuration

This page can be used to configure sFlow statistical sampling intervals.

To display the “sFlow counter interval configuration” page, sFlow configuration->sFlow counter interval configuration, click "Apply" to configure.

sFlow counter interval configuration	
Port	Ethernet1/0/1 ▾
counter interval	<input type="text"/>
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Port</b>	Ethernet port name
<b>counter interval</b>	Sampling interval range: 20-120
<b>Operation</b>	Configuration: User self-configuration Default: Restore default configuration

### 30.9. sFlow analyzer configuration

This page can be used for globally enabled sFlow analyzers.

To display the “sFlow analyzer configuration” page, sFlow configuration->sFlow analyzer configuration, click "Apply" to configure.

sFlow analyzer configuration	
Operation	Configuration ▾
<input type="button" value="Apply"/>	

<b>entry</b>	describe
<b>Operation</b>	Configuration: Function Enable Remote: Function disabled

## 31. IPv6 security ra configuration

### 31.1. IPv6 security ra global configuration

Launch the global IPv6 security RA module, the user can start or close the global IPv6 security RA function in this module.

IPv6 security ra global configuration	
Operation	Enable ▾
Apply	

```

Information feedback window
Switch# config
Switch(config)# ipv6 security-ra enable
    
```

### 31.2. IPv6 security ra port configuration

Start port IPv6 security RA module, the user can start or close the security RA function IPv6 the specified port in this module.

IPv6 security ra port configuration	
Port	Ethernet1/0/1 ▾
Operation	Enable ▾
Apply	

```

Information feedback window
Switch# config
Switch(config)# interface Ethernet1/0/1
Switch(config-if-ethernet1/0/1)# ipv6 security-ra enable
    
```

<b>Port</b>	Specifies the port number	
<b>Operation</b>	Enable	Start operation
	Disable	Close operation

### 31.3. show IPv6 security ra

Show IPv6 security RA configuration module, the user can display the specified port or global IPv6 security RA function configuration information in this module.

show IPv6 security ra	
Port	Ethernet1/0/1 ▾
Apply	

```

Information feedback window
Switch# config
Switch(config)# show ipv6 security-ra interface Ethernet1/0/1
IPv6 security RA information:
Global IPv6 Security RA State: enabled
IPv6 Security RA State: Yes
Switch# config
Switch(config)# show ipv6 security-ra interface Ethernet1/0/1
IPv6 security RA information:
Global IPv6 Security RA State: enabled
IPv6 Security RA State: Yes
    
```

<b>Port</b>	Specifies the port number ALL represents all
-------------	--

## 32. Device log message

### 32.1. Show device log message

View device log information module, where users can view system key logs and warning logs.

Show device log message	
Level	critical <input type="button" value="v"/>
Begin	<input type="text"/>
End	<input type="text"/>
<input type="button" value="Apply"/>	

<b>Level</b>	critical	Key-level log information
	warnings	Warning Level Log Information
<b>Begin</b>	To see where the log information starts	
<b>End</b>	To see the end location of the log information	

### 32.2. Clear logging in logbuff channel

Clears all log message modules in the buffer, users in this module can clear all log messages in the buffer.

Clear logging in logbuff channel	
Clear logging in logbuff channel?	
<input type="button" value="Apply"/>	

Information feedback window	
Switch# clear logging sdram	

## 33. ONVIF configuration

### 33.1. ONVIF server config

This page can view onvif server config module, where users can set onvif server config enable or disable.

Onvif server config

Onvif server config    Disable ▾

Apply

### 33.2. ONVIF detect config

This page can view onvif detect config module, where users can click apply to send onvif detect package.

Onvif detect config

Send onvif detect package    Apply

<input type="checkbox"/>	MAC Addr	IP Addr	Port	Model	Description	Location

delete

Onvif detect config

Send onvif detect package    Apply

<input type="checkbox"/>	MAC Addr	IP Addr	Port	Model	Description	Location
<input type="checkbox"/>	48:ea:63:60:69:83	192.168.19.8	47	NVR304-32E-B-DT	NVR304-32E-B-DT	country

delete

Information feedback window


```
Switch# config
Switch(config)# onvif detect enable
```

## Appendix: DHCP Settings

To enable DHCP for your switch, it is required to create a new VLAN to help configure DHCP settings for the default VLAN. Before proceeding with the configurations on the Switch, first connect your computer to the Switch through one of the PoE ports. We use port 45 as an example for the following instructions.


### Create a new VLAN and enable DHCP for the default VLAN

1. Select **VLAN configuration > VLAN configuration > Create /Remove VLAN > VLAN ID configuration** to create a VLAN. Fill in the necessary fields as shown in the figure below. Here we use VLAN ID 100 as an example.




## Appendix


2. Select **Port configuration > VLAN interface configuration > Add interface VLAN** to add the VLAN created at Step 1 (VLAN 100) to Layer 3 interface. Specify the options as shown in the figure below.




3. Select **Port configuration > VLAN interface configuration > L3 interface IP address mode configuration** to create an IP address for the VLAN created at Step 1 (VLAN 100). Specify the options as shown in the figure below. Make sure your computer's IP address is in the same subnet as the switch. Here we use the IP address (192.168.2.1) as the example.



4. Select **VLAN configuration > VLAN configuration > Assign ports for VLAN** to assign the switch port connected to your computer to the VLAN. Specify the options as shown in the figure below.



5. Re-log in the switch using the set IP address: 192.168.2.1.
6. Select **Port configuration > VLAN interface configuration > L3 interface IP address mode configuration**, and select **Specify IP address** and **Remove** to remove the IP address of the default VLAN (VLAN 1).



## Appendix

- On the same page, select **dhcp-client** and **Add** for the default VLAN (VLAN 1). The IP address assigned by DHCP for VLAN 1 appears in the **Interface IP address** column on the right.

L3 interface IP address mode configuration		VLAN interface	IP mode	Interface IP address	Interface network mask
VLAN interface	Vlan1	Vlan1	dhcp-client	192.168.19.75	255.255.255.0
IP mode	dhcp-client	Vlan100	Specify IP address	192.168.2.1	255.255.255.0
Interface IP address					
Interface network mask					
Operation	Add				
		Apply			

Information feedback window
Switch# config t Switch(config)# interface Vlan1 Switch(config-if-vlan1)# ip dhcp-client enable please disable dhcp client first!

- Connect your computer to the Switch using a port other than port 45 in the example (Step 4) and re-log in your switch using the DHCP assigned IP address acquired at Step 7.

DHCP is successfully set up. You can now use the DHCP assigned IP address acquired to log in your switch.

### Remove VLAN created at step 1 (VLAN 100)

Now that DHCP is successfully set up for the default VLAN (VLAN 1), the VLAN created at the previous steps is redundant and is suggested to be removed.

1. Select **VLAN configuration > VLAN configuration > Assign ports for VLAN** to re-assign port 45 to VLAN 1.

Assign ports for VLAN	
VLAN ID	1 ▼
Port	Ethernet1/0/45 ▼
Operation	Add ▼
Apply	

2. Select **Port configuration > VLAN interface configuration > L3 interface IP address mode configuration** to remove the specify IP address from VLAN 100. **No designate** will appear in the columns of **Interface IP address** and **Interface network mask** for VLAN 100.

L3 interface IP address mode configuration		VLAN interface	IP mode	Interface IP address	Interface network mask
VLAN interface	Vlan100 ▼	Vlan1	dhcp-client	192.168.19.75	255.255.255.0
IP mode	Specify IP address ▼	Vlan100	Specify IP address	No designate	No designate
Interface IP address					
Interface network mask					
Operation	Remove ▼				
Apply					

## Appendix

3. Select **Port configuration > VLAN interface configuration > Add interface VLAN** to remove VLAN 100 from Layer 3 interface. **Non layer 3 interface** will appear in the column of **State** in the table below for VLAN100.

### Add interface VLAN

VLAN ID	100 ▾
Operation	Remove ▾

Apply

Vlan ID	State
Vlan1	Layer 3 interface
Vlan100	Non layer 3 interface

### Information feedback window

```
Switch# config t
Switch(config)# no interface vlan 100
```

4. Select **VLAN configuration > VLAN configuration > Create/Remove VLAN > VLAN ID configuration** to remove VLAN 100.

### VLAN ID configuration

VLAN ID	100
VLAN Name	
VLAN Type	default ▾
Operation	Remove ▾

Apply

### VLAN ID information

VLAN ID	VLAN Name	VLAN Type
1	default	universal vlan
100	VLAN0100	universal vlan

The newly-created VLAN (VLAN 100) is now successfully removed.