BOGEN

Substituting the WMT1A Line Matching Transformer for the TL600 Plug-In Transformer

for use with BPA and HTA Series Power Amplifiers



Instructions:

- 1. Confirm that the WMT1A jumper is installed for LINE input as shown in Figure 1.
- 2. At the RCA inputs of either the BPA or HTA amplifiers, connect the WMT1A RCA plug to either of the HI-Z RCA inputs. The low-impedance screw terminal inputs on the rear of these amplifiers will not be used for this application.
- 3. Turn the amplifier input level control fully CCW, or off.
- **4.** Connect your signal source cable to the outer two balanced 600-ohm input screw terminals on the WMT1A, with ground being the center terminal, if used **(Figure 2).**
- **5.** With the signal source live, adjust the input level of the amplifier as needed.



