

Overview:

ALSD1 and ALS2 are high output, very low current draw dual channel siren drivers designed to work with alarm panels with limited current capability.

Specifications:
Operation:

- 6VDC or 12VDC operation.
Parallel or series speaker wiring
113 db @ 10' @ 6V - 8 Ohms
115 db @ 10' @ 6V - 4 Ohms
116 db @ 10' @ 12V - 8 Ohms
120 db @ 10' @ 12V - 4 Ohms

Current Draw:

- See *Current Draw/Load Table*.

Additional Features:

- Two (2) channel operation - steady or yelp.
- Very low current draw.

Board Dimensions (W x L x H approx.):
ALSD1:

3" x 2.5" x 1.125" (72.6mm x 63.5mm x 28.6mm)

ALSD2:





2.5" x 1.9" x 1.1" (63.5mm x 48.3mm x 27.9mm)

Current Draw/Load Table:

Voltage	Current Draw		Load
	ALSD1	ALSD2	
6V	0.48A	0.3A	8 Ohms
6V	0.50A	0.61A	4 Ohms
12V	0.92A	0.55A	8 Ohms
12V	1.86A	1.22A	4 Ohms

Installation Instructions:

1. Mount the SirenDriver in desired location (mounting hardware included).
2. Connect 4 Ohm or 8 Ohm speakers to terminals marked [SPKR] (*Figs. 1, 2 below*).
See suggested speaker wiring diagrams below.
3. Connect 6VDC to 12VDC from output terminals on control panel or other desired power source (observing polarity) to [GND] and [STY+] or [YLP+] on siren driver.
Note: Steady tone overrides yelp tone if both channels are triggered simultaneously.

Typical Speaker Wiring Diagrams:
Two (2) Speakers, 8 Ohms each

Three (3) Speakers, 8 Ohms each

Four (4) Speakers, 4 or 8 Ohms each

Two (2) Internal/External Hook-up

Fusing External Speakers:

Speakers that are accessible from outside the building should have a 2.5A fuse placed in series with the speaker leads so that any attempt to short the speaker leads will blow the fuse on that speaker while other speakers will continue to operate.