

User Guide Kasa Smart Wi-Fi Power Strip, 6-Outlet HS300

Contents

About This Guide1
Introduction
Appearance 3
Set Up Your Smart Power Strip
Main Device Controls 5
Configure Your Smart Power Strip
Create Scenes 8
Discover Kasa9
Authentication

About This Guide

This guide provides a brief introduction to Kasa Smart Wi-Fi Power Strip and the Kasa app, as well as regulatory information.

Please note that features of Kasa Smart Wi-Fi Power Strip may vary slightly depending on the model and software version you have, and on your location, language and internet service provider. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

Conventions

In this guide, the following convention is used:

Convention	Description
Teal	Key information appears in teal, including management page text such as menus, items, buttons and so on.
<u>Underline</u>	Hyperlinks are in teal and underlined. You can click to redirect to a website.

More Info

- Specifications can be found on the product page at <u>https://www.tp-link.com</u>.
- Our Technical Support and troubleshooting information can be found at https://www.tp-link.com/support.

Introduction

With independent control of 6 smart outlets and always-on USB ports to charge 3 others, the Kasa Smart Wi-Fi Power Strip is ideal for family rooms, home offices and small businesses. Download the Kasa app and control your outlets remotely. The Kasa app provides easy step-by-step installation instructions and convenient remote control from anywhere.


- 6 Smart Outlets Independently control 6 smart outlets from your smartphone with the Kasa Smart app.
- Surge Protection ETL certified surge protection shields electronics from power surges and overloading.
- 3 USB Ports Charge your tablet, smartphone, or other devices using the always-on USB ports.
- Energy Monitoring Monitor energy consumption of devices plugged into your smart power strip.
- No Hub Required Connect to your existing Wi-Fi router.
- Scheduling Set a schedule to automatically turn devices on and off.
- Voice Control Use Alexa, Google Assistant, or Microsoft Cortana to control your devices with voice commands.
- Works with IFTTT Have your smart power strip work together with other devices through support from IFTTT.

Supported Load Types:

Coffee Maker: 800 WHeater: 1500 WToaster: 850 WDesk Lamp: 235.2 WHumidifier: 260 WTower Fan: 50 WLCD: 270 WIron: 1500 W

Appearance


Smart Power Strip has 6 individual smart outlets, with control buttons to turn on/off devices plugged in and LEDs to show you the current status. SYS, Grounded and Protected LEDs change color according to its status. See the explanation below:



Position Your Power Strip

Put your power strip within the Wi-Fi range of your home Wi-Fi network and control the plugged-in devices individually and easily with the Kasa Smart app.

Generally, the power strip is placed on a horizontal surface, such as a shelf or desktop. The device also can be mounted on the wall as shown below.



Set Up Your Smart Power Strip

Follow the steps below to set up your Smart Power Strip via Kasa Smart app.

1. Download and install Kasa app

Go to Google Play or the App Store or scan the QR code below to download the Kasa app on your Android or iOS smartphone or tablet.












2. Log in or sign up with TP-Link ID

Open the app. Use your TP-Link ID to log in.

If you don't have a TP-Link ID, tap Create Account and the Kasa app will guide you through the rest.



3. Add Device

Tap the + button in the Kasa app, select Smart Power Strip and then follow step-by-step app instructions to complete the setup.


<	Add a Smart Plug	
	Smart Plug HS100, HS110	>
l I n	Smart Plug Lite / Mini HS103, HS105, KP100, KP115	>
0 8 2	Smart Plug, 2-Outlet	>
	Smart Outlet	>
<u></u>	Smart Power Strip HS300, KP303	>
	Smart Outdoor Plug KP400	>

Main Device Controls

After you successfully set up your Smart Wi-Fi Power Strip, you will see the home page of the Kasa Smart app. Here you can view and manage all devices that you've added to Kasa. Tap a smart power strip to control and manage it.


Home Page

You can see all your Kasa devices listed in the Home page.




Turn on/off the smart outlet

Turn on/off any outlet of your Smart Wi-Fi Power Strip quickly by tapping the switch of each device. Tapping in the device, you can also check or change its status.



Set Schedules

Schedule: Set schedules to automatically turn on/off the devices plugged in to the smart outlets of your Smart Power Strip respectively according to your daily routine.



4. You can also choose to turn on/off the smart outlet simply at Sunrise or Sunset. Please note that the Sunrise and Sunset times are based on your location.

SIM 🗢	4:59 PM	۰ 🛃
\times	New Schedule	Save
ACTION		
Turn Off Powe	r	۲
Turn On Power		0
TIME		
Time	Sunrise	Sunset
	59 min	
	At Sunrise	
	1 min 2 min	
REPEAT		

5. Tap Save and you'll see your schedule listed in the Schedule Page. You can add more schedules following the same steps.



6. You can turn off your schedule any time at the Schedule page.

No SIM 奈	5:04 PM	۹ 🛃
\leftarrow	Schedule	+
	At Sunrise S M T W T F S	
OFF	11:00 pm s m t w t f s	

Set Timer


Timer: Set the timer for your smart outlet to automatically turn on/off after the time ends.

1. Tap a smart outlet that you want to set a timer for in the Home page, and then tap \oint_{Timer}




2. Set the time after which the smart outlet will be automatically turned on/off.

For example, when I start cooking rice, I want it to turn off after 30 minutes.




2. Tap START and you'll see the timer is counting down. Tap Stop to stop the Timer at any time.



Set Away Mode

Away Mode: Set Away Mode for the smart outlet of your power strip to turn on/off automatically at random intervals while you are away to make the appearance that someone is at home.


1. Tap a smart outlet that you want to set Away Mode for in the Home page, and then tap . 2. Set the start and end time during which the smart outlet will be automatically turned on and off at random intervals, then choose the repeating frequency. For example, I want my Night Light to turn on and off between 7:00 PM to 11:50 PM every Friday and Saturday.



Note: The start and end end time must be on the same day.

Check Runtime

Runtime: Check runtime to keep track of how long each outlet of your Smart Power Strip has been working.



2. Check the runtime for today, the past 7 days, or the past 30 days.




Manage Device Settings

1. Tap any outlet of your smart power strip and then tap ~~

No SIM 🗢 3:14 PM @ 🗲 Plug3-Air Cleanser ÷ \leftarrow Plug 3 C Schedule Timer Away Energy


2. Change the name and icon of each outlet.



3. Tap Re-Order to change the order of the devices connected to the six outlets of your Smart Power Strip.

۹ 🛃

4. Toggle on/off Status LED to turn on/off the LEDs of the six smart outlets altogether.



o SIM 🗢	3:52 PM	e 🎫
\leftarrow	Device Settings	
NAME AN	ND ICON	
	Plug2-Cooker Plug1	>
	Plug1-Water Pot	>
•	Plug3-Air Cleanser	>
	Plug4-Night Light	>
	Plug5-Fan Plug5	>
	Plug6-Desk Lamp	>
CUSTON	IZE	
Re-Ord	ler	>
Status	LED	


3. Tap Feature Tutorial to have a glance of the advanced features of your Smart Power Strip. More details on configuring these features

No SIM 🗢 3:54 PM 💿 🚱	No SIM 🗢 10:14 AM @ 🕬	No SIM 🗢 10:14 AM © 🐨	No SIM 🗢 10:14 AM 🕑 🚱
Welcome to Smart Power Strip	Groups	Scenes and Actions	Beyond Kasa
Swipe on for tips on how to use your new Smart Power Strip.	With groups, you can control multiple outlets simultaneously; just select Add a Group when adding a device.	Integrate your Smart Power Strip with other Kasa devices using Scenes and Smart Actions.	You can control your Power Strip from Amazon Alexa, Google Assistant, IFTTT and Samsung SmartThings; just check the Works with Kasa section when adding a device.
• • • • • •	• • • •	• • •	• • •
Exit	Exit	Exit	Get Started

Reset Your Smart Power Strip

TP-Link provides three methods to reset your Smart Power Strip. Method 1

Swipe left any of the outlets of your Smart Power Strip and tap Delete. Then tap Remove Device. Your Smart Power Strip will be removed from your Kasa account and restored to factory settings.



Method 2

Tap any of the outlets of your Smart Power Strip and go to the Devices Settings page. Then tap Remove Device in the bottom. Your Smart Power Strip will be removed from your Kasa account and restored to factory settings.

	3:52 PM	e 📂	
\leftarrow	Device Settings		X Remove Smart Power Strip
<u> </u>	Plug4-Night Light Plug4	>	The following actions will be performed upon removing your Smart Power Strip:
	Plug5-Fan Plug5	>	1 Your Smart Power Strip will be removed from your Kasa account and restored to factory
	Plug6-Desk Lamp	>	settings.
_	Flugo		2 All configured smart actions and schedules will be removed.
CUSTON	1IZE		3 All devices connected to your Smart Power Strip will be removed.
e-Orc	ler	>	
tatus	LED		
DVANC	ED		
eature	e Tutorial	>	
evice	Info	>	
_			

Method 3

Press and hold any of the control buttons of the six smart outlets for 10s to restore your Smart Power Strip to factory default settings..




Create Groups

With groups, ypu can control mutiple outlets simultaneously. This page allows you to add the outlets of your Smart Power Strip to a group for unified management.

1. Create groups for your Smart Power Strip

1. Tap the \oplus button in the Home page of the Kasa Smart app, and select Group.

2. Select the smart outlets that you want to add in a group and tap Save. For example, I want to group the Cooker and the Fan together for unified control. 2. Name the group.




←	Add a Group	2;
	Add a Group	
	GHTING KI130	\checkmark
SMART PL	UGS	
	Hs100	\checkmark
	Plug1-Water Pot	\checkmark
- <u>C</u> -	Plug2-Cooker	~
	Plug3-Air Cleanser	\checkmark
	Plug4-Night Light	\checkmark
Ś	Plug5-Fan	~
	Plug6-Desk Lamp	\checkmark
	Save	

C)
← Name the Group
Let's give your device group a name.
Crown Name
Group Name Cooking
Save
qwertyuiop
asdfghjkl
123

4. The created group is listed in the Home page. You can tap ON or OFF to turn on or off the smart outlets together in the group.

For example, if I turn off the Cooking Group, the following Cooker and Fan devices, which are in the Light Group, will also show the status as off.




2. Manage the group

1. Tap the group you want to manage.

No SIM 🗢	4:11 PM	۰ 🚺
\equiv	Devices 2.30.0.10 -dev	+
GROUPS		
	Cooking	ON OFF
SMART PL	JGS	
	Plug1-Water Pot 🛱 2:30 am OFF	\bigcirc
	Plug2-Cooker	\bigcirc
	Plug3-Air Cleanser	\bigcirc
	Plug4-Night Light	\bigcirc
	Plug5-Fan	\bigcirc
Devices	Cameras Scenes Smart Action	Activity

2. Turn on or off the Group in the status page.





3. Tap 🔅 in the top right corner to enter the settings page.

GROUP PROPERTIES	
Group Name Coc	oking
Devices	


4. Tap Group Name to rename the group.

5. Tap Devices to add devices to or detele devices from the group.





6. Tap Remove Group if you want to remove the group from your device list. All devices in the group will remain accessible on the device list.




Create Scenes


A scene is a preset group of smart devices that can be programmed, customized and activated simultaneously at the touch of a button from your smartphone or tablet, allowing you to easily set your mood, activity or fit any special occasion. This page allows you to preset how your smart home devices should act automatically at special occasions.


1. Tap 🔮 at the bottom, then tap + at the top right corner.

2. Select a scene or create your own scene.


For example: I want to turn off Air Cleanser light and turn on Fan simultaneously with just a tap in the Kasa Smart app. 2. Select devices for the scene to work on and set their status respectively.








4. Pick an icon for your scene.




2. Name your scene.

2. Your scene is created and is displayed in the scene list. Just tap the scene to activate it.



Smart Actions

Smart Actions is a function provided that enables device interconnections and home automations. With Smart Actions, your Kasa devices can work together to create a smarter smart home. From the moment you wake up to the moment you drift asleep, Smart Actions make your home safer and more comfortable.



Motion Sensing: Take actions when a Kasa camera senses a motion.

Control With a Switch: Extending the Smart Switch control to other Kasa Smart devices. Turn on/off a group of devices with the Smart Switch all together.

Schedule a Scene: Schedule a "Scene" to be turned on automatically at the time specified.


Auto-off Timer: Whenever a Smart device is turned on, turn it off after the designated amount of time.

1. Configure Motion Sensing If you already have a Kasa Smart Camera

e.g.: I want to turn the living room light on when my Kasa camera senses a motion.


1. Tap Motion Sensing then select a camera.

2. Select the outlet of your Smart Power Strip which your living room light is plugged in.




3. Set the time when you want to be notified. You can choose Always or tap Custom to choose time according to your needs.


For example: I want the motion to trigger the light on from 11:00 PM to 7:00 AM every day.



4. (Optional) Set an auto-off timer then tap Complete. Then your living room light will be turned off after the time you set.

5. Name your action for easy identification.





No SIM 🗢	3:05 PM	۹ 🚮
<	Name Your Action	
Let's s	give your action a name to help y remember its function	∕ou ⊗
	DONE	
q w a s	ertyui dfghjk	o p I
순 Z	x c v b n m	
123	↓ space	done


6. The Smart Action is created successfully and displayed in the Smart Actions list.

No SIM 🗢	:	۹ 🌠		
\equiv	Smart Action	ns 2.28	3.0.17 -dev	+
\bigcirc	Motion-light ·Ô・Living Room Light	ē 3	mins	
1.1	0	Ċ.	*	
Devices	Cameras	Scenes	Smart Actions	Activity

2. Configure Control With a Switch If you already have a Kasa Smart Switch


e.g.: I want to turn the living room light on when I turn on my switch, and turn the light off when I turn off the switch.


1. Tap Control With a Switch.




2. Add a Kasa smart switch. Then select the outlet of your Smart Power Strip which your living room light is plugged in.

3. Name your action for easy identification.





4. Now Your Smart Action is created successfully.




3. Configure Schedule a Scene

e.g.: I want to turn on the scene I have created automatically at scheduled time.

1. Tap Schedule a Scene then select a scene you have created.

For example: I want to turn on my Good Morning scene, which turns on my bedroom and kitched light with just a tap, at 7: 20 AM every weekday.


2. Set the time and frequency at which you want your scene to be turned on .



3. Name your action for easy identification.

4. The Smart Action is created successfully and displayed in the Smart Actions list.

No SIM 🧟	2			4:18 PN	1			و 🛃
<		N	ame	Your	Actio	on		
	et's gi	ren	nemb	tion a per its			elp yo	u 🔊
				DONE				
٩V	N e	e I		ty	/ l	<u>ا</u>	i o	р
а	s	d	f	g	h	j	k	Ι
Ŷ	z	x	С	V	b	n	m	$\overline{\langle}$
123		Ŷ	space done				one	




4. Configure Auto-Off Timer

e.g.: I want to turn off my air cleaner is plugged in after 30 minutes whenever it is turn on.

1. Tap Auto-Off Timer then select a device.

2. Set the time.



3. Name your action for easy identification.

No SIM 🗢	•		4	1:20 PM	N			و 🛃
<		Na	ame	Your	Actio	on		
	0	ren			. name funct		elp yo	
				DONE				
qv	v e			t]]	y l			
а	S	d	f	g	h	j	k	1
Ŷ	z	x	С	V	b	n	m	\otimes
123		Ŷ	space done				one	


4. The Smart Action is created successfully and displayed in the Smart Actions list.

No SIM 🗢	4:20 PM	۹ 🛃
\equiv	Smart Actions 2.28.0.17 -dev	+
	Clean Air ð Off after 30 minutes	
	Morning-Light H At 7:20 AM, Every Weekday	
	Motion-light .츳- Living Room 경 3 mins Light	
Devices	Cameras Scenes Smart Actions	Activity

Discover Kasa

Use the Kasa Smart app to pair your Smart Wi-Fi Power Strip with Amazon Alexa or Google Home Assistant, and enjoy a full hands-free experience. Kasa helps manage the rest of your smart home too, working with Samsung SmartThings to trigger changes when you arrive home or leave for the day.

Launch the Kasa Smart app. Go to the sidebar and tap Work with Kasa. You can choose Amazon Alexa / Google Assistant/ IFTTT / Samsung SmartThings for detailed instructions.



FCC compliance information statement

FC

Product Name: Kasa Smart Wi-Fi Power Strip,6-Outlet

Model Number: HS300

Responsible party:

TP-Link USA Corporation, d/b/a TP-Link North America, Inc.

Address: 145 South State College Blvd. Suite 400, Brea, CA 92821

Website: http://www.tp-link.com/us/

Tel: +1 626 333 0234

Fax: +1 909 527 6803

E-mail: sales.usa@tp-link.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

"To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter."

We, **TP-Link USA Corporation**, has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no unauthorized change is made in the equipment and the equipment is properly maintained and operated.

Issue Date: 2021.03.09

NCC Notice

注意!

依據 低功率電波輻射性電機管理辦法

LP0002低功率射頻器材技術規範_章節3.8.2

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。

前述合法通信,指依電信管理法規定作業之無線電通信。

低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

BSMI Notice

安全諮詢及注意事項

- 請使用原裝電源供應器或只能按照本產品注明的電源類型使用本產品。
- 清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清潔。
- 注意防潮,請勿將水或其他液體潑灑到本產品上。
- 插槽與開口供通風使用,以確保本產品的操作可靠並防止過熱,請勿堵塞或覆蓋開口。
- 請勿將本產品置放於靠近熱源的地方。除非有正常的通風,否則不可放在密閉位置中。
- 不要私自拆開機殼或自行維修,如產品有故障請與原廠或代理商聯繫。

限用物質含有情況標示聲明書

設備名稱: Equipment name Kasa Smart Wi-Fi Po	ower Strip, 6-Outlet		型號(型式 Type desi HS300	式): gnation (Type)				
		限用物質及其化學符號 Restricted substances and its chemical symbols						
單元 Unit	鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr+6)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)		
РСВ	0	0	0	0	\bigcirc	0		
外殼	0	0	0	0	0	0		
電源供應板		0	0	0	0	0		
其他及其配件		0	0	0	0	0		
備考1. [*] 超出 0.1 wt % [*] 及 [*] 超出 0.01 wt % [*] 係指限用物質之百分比含量超出百分比含量基準值 Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition. 備考 2. [*] ○ [*] 係指該項限用物質之百分比含量未超出百分比含量基準值。 Note 2: "○" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence. 備考 3. [*] − [*] 係指該項限用物質為排除項目。 Note 3: The "−" indicates that the restricted substance corresponds to the exemption.								
Note 3: The "—"	indicates that the	e restricted substan	ice corresponds to '	the exemption.				

Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use the device where wireless devices are not allowed.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- Operating temperature: 0°C ~40°C (32 °F ~104 °F); Storage Temperature: -40°C~60°C (-40 °F ~140 °F)

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.



CAUTION Electronic switch integrated in this product is only intended for functional purposes. Unplug the appliance before servicing.

CAUTION

- Do not install this device if there is not at least 10 meters (30 feet) or more of wire between the electrical outlet and the electrical service panel.
- To reduce the risk of electric shock Use only indoors.
- Risk of electric shock. Do not plug into another relocatable power tap or an extension cord.
- Use only in dry locations.
- USB for charging IT Equipment Only.
- Not intended to be mounted on a desk or similar furnishing surface.
- WARNING: Timer could turn on unexpected without the user being present. To reduce the hazardous condition Unplug the appliance that is plugged into the receptacle(s) controlled by the timer before servicing.

Explanation of the symbols on the product label

Symbol	Explanation
	Indoor use only
\sim	AC voltage
	DC voltage

Symbol	Explanation
	RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.
μ	Switch of micro-gap construction (for US version) Switch of micro-gap / micro-disconnection construction (for other versions except US)