

Altronix/Kisi Kits

Models Include:

T1KE3F4

4 Door Kit with Fused Outputs Fully assembled kit includes:

- Trove1 enclosure with TLU1 backplane
- One (1) eFlow6NB Power Supply/Charger
- One (1) ACM4 Fused Access Power Controller

T1KE3F8

8 Door Kit with Fused Outputs Fully assembled kit includes:

- Trove1 enclosure with TLU1 backplane
- One (1) eFlow6NB Power Supply/Charger
- Two (2) ACM4 Fused Access Power Controllers

T2KE33F16

16 Door Kit with Fused Outputs Fully assembled kit includes:

- Trove2 enclosure with TLU2 backplane
- Two (2) eFlow6NB Power Supply/Charger
- Two (2) ACM8 Fused Access Power Controllers

T1KE3F4D

4 Door Kit with PTC Outputs Fully assembled kit includes:

- Trove1 enclosure with TLU1 backplane
- One (1) eFlow6NB Power Supply/Charger
- One (1) ACM4CB PTC Access Power Controller

T1KE3F8D

8 Door Kit with PTC Outputs Fully assembled kit includes:

- Trove1 enclosure with TLU1 backplane
- One (1) eFlow6NB Power Supply/Charger
- Two (2) ACM4CB PTC Access Power Controllers

T2KE33F16D

16 Door Kit with PTC Outputs Fully assembled kit includes:

- Trove2 enclosure with TLU2 backplane
- Two (2) eFlow6NB Power Supply/Charger
- Two (2) ACM8CB PTC Access Power Controllers

All components of these Trove kits are UL Listed sub-assemblies.

Please refer to the included corresponding Sub-Assembly Installation Guides for further information.

Installation Guide

CE

All registered trademarks are property of their respective owners.



Kev. 111/22			
Installing Company:	Service Rep. Name:		
G . 5			
Address:		Phone #·	

Overview:

Altronix Trove Kisi kits are pre-assembled and consist of Trove1LU1 or Trove2LU2 enclosure/backplane with factory installed Altronix power supply/charger(s) and sub-assemblies. Trove Kisi kits also accommodates up to four (4) Kisi Pro Controllers for up to sixteen (16) doors in a single enclosure.

Configuration Chart:

		Dower	Dower	Movimum Cunnhy	Nomir Output	nal DC Voltage		ACMA(CD)/	ACM4/ ACM8	ACM4CB/ ACM8CB
	120VAC	Power Supply	Power Supply	Maximum Supply Current for Main and Aux.	[DC]	[Aux]		ACM4(CB)/ ACM8(CB)		
Altronix Model Number	60Hz Input Current (A)	Board Input Fuse Rating	Board Battery Fuse Rating	Outputs on Power Supply board(s) and ACM4/ACM8 Access Power Controllers' outputs	Output Range (VDC)	Output Range (VDC)	Fail-Safe/ Fail-Secure Outputs	Board Input Fuse Rating	Board Output Fuse Rating	Board Output PTC Rating
T1KE3F4	3.5	5A/ 250V	10A/ 32V	24VDC @ 5.7A	20.17- 26.4 26.4		4	10A/32V	3A/32V	_
T1KE3F4D						4	104/32/	_	2.5A	
T1KE3F8						8	10A/32V	3A/32V	_	
T1KE3F8D								_	2.5A	
T2KE33F16							16	10A/250V	3.5A/250V	_
T2KE33F16D									_	2.5A


Installation Instructions:

Wiring methods shall be in accordance with the National Electrical Code/NFPA 70/ANSI, and with all local codes and authorities having jurisdiction. Product is intended for indoor use only.

- 1. Remove backplane from enclosure. Do not discard hardware.
- 2. Mark and predrill holes in the wall to line up with the top two/three keyholes in the enclosure. Install two/three upper fasteners and screws in the wall with the screw heads protruding. Place the enclosure's upper keyholes over the two/three upper screws, level and secure. Mark the position of the lower two/three holes. Remove the enclosure. Drill the lower holes and install the two/three fasteners. Place the enclosure's upper keyholes over the two/three upper screws. Install the two/three lower screws and make sure to tighten all screws refer to pages 6-7.
- 3. Mount included UL Listed tamper switch (Altronix Model TS112 or equivalent) in desired location, opposite hinge. Slide the tamper switch bracket onto the edge of the enclosure, approximately 2" from the right side (Fig. 1, pg. 2). Connect tamper switch wiring to the Access Control Panel input or the appropriate UL Listed reporting device. To activate alarm signal open the door of the enclosure.
- 4. Mount Kisi Pro Controllers to TLU1 or TLU2 backplane, refer to pages 3-5.
- 5. Refer to the *eFlow Power Supply/Charger Installation Guide* for eFlow6NB and corresponding *Sub-Assembly Installation Guides* for ACM4(CB) and ACM8(CB) for further installation instructions.

Hardware:





- 2 - Trove KE eFlow Kits Installation Guide

T1KE3F4 and T1KE3F4D: Configuration of Kisi Pro Controllers:

- 1. Fasten mounting magnets (provided) to Kisi Pro Controllers with screws and spacers (provided) using the controllers' mounting holes (Fig. 2, pg. 3).
- 2. Attach mounting magnets to TLU1 in the approximate position as shown below (Fig. 2a, pg. 3).

Note: Kisi Pro Controllers should be properly oriented.


Please make sure that they are mounted correctly, as shown in Fig. 2 below.


3. Fasten TLU1 backplane to Trove1 enclosure utilizing hardware (provided).

Access Controller Position Chart for the Following Models:

Kisi	Pem Mounting
Pro Controller	(A)

Fig. 2 - T1KE3F4(D) Configuration





Trove KE eFlow Kits Installation Guide - 3 -

T1KE3F8 and T1KE3F8D: Configuration of Kisi Pro Controllers:

- 1. Fasten mounting magnets (provided) to Kisi Pro Controllers with screws and spacers (provided) using the controllers' mounting holes (Fig. 3, pg. 4).
- 2. Attach mounting magnets to TLU1 in the approximate position as shown below (Fig. 3a, pg. 4).

bte: Kisi Pro Controllers should be properly oriented.


Please make sure that they are mounted correctly, as shown in Fig. 3 below.


3. Fasten TLU1 backplane to Trove1 enclosure utilizing hardware (provided).

Access Controller Position Chart for the Following Models:

Kisi	Pem Mounting
Pro Controller	(A)

Fig. 3 - T1KE3F8(D) Configuration





Trove KE eFlow Kits Installation Guide

T2KE33F16 and T2KE33F16D: Configuration of Kisi Pro Controllers:

- 1. Fasten mounting magnets (provided) to Kisi Pro Controllers with screws and spacers (provided) using the controllers' mounting holes (Fig. 4, pg. 5).
- 2. Attach mounting magnets to TLU2 in the approximate position as shown below (Fig. 4a, pg. 5).


Note: Kisi Pro Controllers should be properly oriented.


- Please make sure that they are mounted correctly, as shown in Fig. 4 below.
- 3. Fasten TLU2 backplane to Trove2 enclosure utilizing hardware (provided).

Access Controller Position Chart for the Following Models:

Kisi	Pem Mounting
Pro Controller	(A)

Fig. 4 - T2KE33F16(D) Configuration






Trove KE eFlow Kits Installation Guide

T1KE3F4(D) and T1KE3F8(D) Enclosure Dimensions (H x W x D approximate):


18" x 14.5" x 4.625" (457mm x 368mm x 118mm)



- 6 - Trove KE eFlow Kits Installation Guide

T2KE33F16(D) Enclosure Dimensions (H x W x D approximate):

27.25" x 21.5" x 6.5" (692.2mm x 552.5mm x 165.1mm)



Notes:

Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.



- 8 -