



Chime, Chime Plus and Chime Pro setup guide

You can plug your Ring Chime, Chime Plus and Chime Pro into an outlet to hear customizable audio alerts when motion is detected or someone rings your doorbell. [Learn more about customizing your Chime here.](#)

Setting up Chime, Chime Plus and Chime Pro devices

Connect your Chime, Chime Plus or Chime Pro to your home's wifi network using the below steps in the Ring app:

1. Open the Ring app to the main dashboard.
2. Tap **Set Up a Device** at the bottom of the screen.
3. Follow the in-app prompts to the complete setup.

If your mobile device is not scanning the QR code, tap **Set up a non-Ring device or choose manually** to continue through the setup process.

4. Allow Location Services when prompted.
5. Select the location where you are adding Chime, Chime Plus or Chime Pro or tap **Add a New Location** to enter a new address.
6. Choose a name for your Chime.
7. Tap **I Have My Password**.
8. Tap **I Am Near The Device**.
9. Plug your Chime into a wall outlet.

If the light is flashing, tap **The light is flashing**

If the light is not flashing, press and hold the button on the side of the chime for five seconds.

10. Have your wifi password ready to enter.
11. When prompted, join the Ring wifi network.

Connect with Bluetooth for Chime (3rd Gen) and Chime Plus.

12. Select your wifi network from the list and enter your wifi password.
13. Wait for the device to connect to the network, then complete the setup.

Connect to the Chime Pro network

Connect your Ring devices to the Chime Pro network to improve wifi signal strength. You can select which Ring devices you want to connect to Chime Pro during the setup process or from the device's settings in the Ring app. If you are using Chime Pro as a wifi extender, choose a location that is halfway between your wifi router and the Ring device that is farthest away.

Add a Ring device to the Chime Pro during setup:

1. Tap **Connect** when prompted.
2. Tap the Ring device that should be connected to the Chime Pro network.
3. Tap **Switch to Chime Pro Network**.
4. Tap **Connect to Chime Pro**.
5. Wait for the Ring device to go into setup mode. If the Ring device does not go into setup mode, firmly press and hold the setup button for one or two seconds, then release it.
6. When the Ring device is in setup mode, tap **Continue**.
7. After the Ring video doorbell connects, tap **Got it**.
8. Tap **I'm Done**.

Add a Ring device to the Chime Pro from the Device Settings:

1. Open the Ring app to the main dashboard.
2. Tap the **menu** (≡).
3. Tap **Devices**.
4. Tap the device you want to adjust.
5. Tap **Device Health**.
6. Tap **Change Network**.

- 7. Tap **Change Wifi Network**.
- 8. Tap **Connect to Chime Pro**.

Last updated 2 weeks ago

Related Articles

In-home chime kit compatibility list for Wired Doorbell Plus and Pro >

Safety and Compliance Information for Chime Plus >

Safety and Compliance Information for Chime Pro (2nd Gen) >

©2026 Ring LLC or its affiliates

[Privacy](#) | [Licenses](#) | [Terms of Service](#)